



SERVICE BULLETIN

AFTERSALES SERVICE OFFICE, MITSUBISHI MOTORS CORPORATION

PURPOSE : CORRECTION	ISSUE NO. : MSB-08E27-502	DATE : 2008-01-05
SUBJECT : DATA LIST REFERENCE TABLE FOR ELECTRONIC CONTROL 4WD	<div><MODEL> (EUR/RUSSIA) OUTLANDER (GS45X)(CW0W), LANCER (GS41)(CY0A)</div> <div><M/Y> 07-08</div>	
GROUP : REAR AXLE		
<div><div>1. Description:</div><div>The data list reference table for the electronic control 4WD has been incorrect in the applicable Workshop Manuals. This Service Bulletin contains the corrected list.</div><div>2. Applicable Manuals:</div><div>See Attachment 1.</div><div>3. Corrected Specifications:</div><div>See Attachments 2 to 9.</div></div>		

<EUR>

Manual	Pub. No.	Title (Info-ID)	Attachment
2007 OUTLANDER Workshop Manual CD-ROM	CGXE07E1-CD (English) CGXS07E1-CD (Spanish) CGXF07E1-CD (French) CGXG07E1-CD (German)	Data List Reference Table (M274-00-100-03100-01)	Attachment 2–5
2008 OUTLANDER Workshop Manual CD-ROM	CGXE08E2-CD (English) CGXS08E2-CD (Spanish) CGXF08E2-CD (French) CGXG08E2-CD (German)		
2008 LANCER Workshop Manual CD-ROM	CG1E08E2-CD (English) CG1S08E2-CD (Spanish) CG1F08E2-CD (French) CG1G08E2-CD (German)	Data List Reference Table (M274-00-100-05300-02)	Attachment 6–9

<RUSSIA>

Underneath Manual	Underneath Pub. No.	Title (Info-ID)	Attachment
2007 OUTLANDER Workshop Manual CD-ROM	N/A	Data List Reference Table (M274-00-100-03100-01)	Attachment 2–5
2008 OUTLANDER Workshop Manual CD-ROM	N/A		
2008 LANCER Workshop Manual CD-ROM	N/A	Data List Reference Table (M274-00-100-05300-02)	Attachment 6–9

ELECTRONIC CONTROL 4WD TROUBLESHOOTING

DATA LIST REFERENCE TABLE

M1274001000031

M.U.T.-III can read the following items among various control data (input data from each ECU and switch) used by the electronic control 4WD system.

THE SYSTEM IS NORMAL.

<Marking area has been changed.>

<Incorrect>

Item No.	Check items	Check conditions		Normal conditions
01	Vehicle speed (4WD calculated value)	Perform a test run of the vehicle.		The speedometer display and the M.U.T.-III display almost agree with each other.
02	Ignition power supply voltage	Ignition switch: ON		0 to 16 V
03	Coupling torque	Ignition switch: ON		0 to 1200 N·m
04	Coupling current (command value)	<ul style="list-style-type: none"> • Drive mode selector: 4WD • Perform a test run of the vehicle. 		The current changes between 0 and 5 A. (Command value and actual value agree with each other.)
05	Coupling current (monitor value)	<ul style="list-style-type: none"> • Drive mode selector: 4WD • Perform a test run of the vehicle. 		The current changes between 0 and 5 A. (Command value and actual value agree with each other.)
06	Coupling temperature	Perform a test run of the vehicle.		0 to 200°C
07	CAN system (ABS/ASC)	Ignition switch: ON	When ASC-ECU data is correctly received	OK
			When ASC-ECU data reception error occurs	No reception
08	CAN system (engine)	Ignition switch: ON	When engine-ECU data is correctly received	OK
			When engine-ECU data reception error occurs	No reception
09	CAN system (ETACS)	Ignition switch: ON	When ETACS-ECU data is correctly received	OK
			When ETACS-ECU data reception error occurs	No reception
10	2WD SW	Ignition switch: ON	Drive mode selector: 2WD	OFF/ON
11	LOCK SW	Ignition switch: ON	Drive mode selector: LOCK	OFF/ON

ELECTRONIC CONTROL 4WD TROUBLESHOOTING

Item No.	Check items	Check conditions	Normal conditions
15	4WD mode	Ignition switch: ON Shifting in progress 4WD LOW 4WD HIGH 2WD Neutral 4WD (part-time)	—
16	FL wheel speed sensor	Perform a test run of the vehicle. Check that there is difference between the right wheel speed and the left wheel speed when the vehicle turns.	The speedometer display and the M.U.T.-III display almost agree with each other.
17	FR wheel speed sensor		
18	RL wheel speed sensor		
19	RR wheel speed sensor		
21	Engine speed	Perform a test run of the vehicle.	The tachometer display and the M.U.T.-III display almost agree with each other.
23	Ignition position	<ul style="list-style-type: none"> • LOCK • OFF • ACC • ON • START 	—
24	Engine torque	Perform a test run of the vehicle.	The torque changes between 0 and 300 N·m.
26	Throttle position	Ignition switch: ON	Release the accelerator pedal. Approximately 0%
		Gradually depress the accelerator pedal.	0 – 100%
		Fully depress the accelerator pedal.	Approximately 100% (within 100%)
28	Limited torque	—	0 to 2500 N·m

SYSTEM SHUT-DOWN

M.U.T.-III display data does not agree with the actual data when 4WD-ECU deactivates the 4WD control function by the fail-safe function.

<Incorrect>

<Replace with Attachment 4, 5>

ELECTRONIC CONTROL 4WD TROUBLESHOOTING

DATA LIST REFERENCE TABLE

M.U.T.-III can read the following items among various control data (input data from each ECU and switch) used by the electronic control 4WD system.

THE SYSTEM IS NORMAL.

<Marking area has been changed.>

<Correct>

Item No.	Check items	Check conditions		Normal conditions
01	Vehicle speed (4WD calculated value)	Perform a test run of the vehicle.		The speedometer display and the M.U.T.-III display almost agree with each other.
02	Ignition power supply voltage	Ignition switch: ON		0 to 16 V
03	Coupling torque	<ul style="list-style-type: none">• Drive mode selector: 4WD• Perform a test run of the vehicle.		0 to 730 N·m
04	Coupling current (command value)	<ul style="list-style-type: none">• Drive mode selector: 4WD• Perform a test run of the vehicle.		The current changes between 0 and 5 A. (Command value and actual value agree with each other.)
05	Coupling current (monitor value)	<ul style="list-style-type: none">• Drive mode selector: 4WD• Perform a test run of the vehicle.		The current changes between 0 and 5 A. (Command value and actual value agree with each other.)
06	Coupling temperature	<ul style="list-style-type: none">• Drive mode selector: 4WD• Perform a test run of the vehicle.		0 to 200°C <i>NOTE: Due to road surface condition the load to coupling varies, thus the temperature indication changes.</i>
07	CAN system (ABS/ASC)	Ignition switch: ON	When ASC-ECU data is correctly received	OK
			When ASC-ECU data reception error occurs	No reception
08	CAN system (engine)	Ignition switch: ON	When engine-ECU data is correctly received	OK
			When engine-ECU data reception error occurs	No reception

ELECTRONIC CONTROL 4WD TROUBLESHOOTING

Item No.	Check items	Check conditions		Normal conditions
09	CAN system (ETACS)	Ignition switch: ON	When ETACS-ECU data is correctly received	OK
			When ETACS-ECU data reception error occurs	No reception
10	2WD SW	Ignition switch: ON	Drive mode selector: 2WD	ON
11	LOCK SW	Ignition switch: ON	Drive mode selector: LOCK	ON
15	4WD mode	Ignition switch: ON	Drive mode selector: 2WD	2WD
			Drive mode selector: 4WD	4WD
			Drive mode selector: LOCK	4WD LOCK
16	FL wheel speed sensor	Perform a test run of the vehicle. Check that there is difference between the right wheel speed and the left wheel speed when the vehicle turns.		The speedometer display and the M.U.T.-III display almost agree with each other.
17	FR wheel speed sensor			
18	RL wheel speed sensor			
19	RR wheel speed sensor			
21	Engine speed	Perform a test run of the vehicle.		The tachometer display and the M.U.T.-III display almost agree with each other.
23	Ignition position	ON		ON
		START		START
26	Throttle position	Ignition switch: ON	Release the accelerator pedal.	Approximately 0%
			Gradually depress the accelerator pedal.	0 – 100%
			Fully depress the accelerator pedal.	Approximately 100% (within 100%)
28	Limited torque	Perform a test run of the vehicle.	In case of traction control does not operate	–
			In case of traction control operates	0 to 730 N·m

SYSTEM SHUT-DOWN

M.U.T.-III display data does not agree with the actual data when 4WD-ECU deactivates the 4WD control function by the fail-safe function.

<Correct>

<Item No.24 has been deleted.>

ELECTRONIC CONTROL 4WD TROUBLESHOOTING

DATA LIST REFERENCE TABLE

M1274001000053

M.U.T.-III can read the following items among various control data (input data from each ECU and switch) used by the electronic control 4WD system.

THE SYSTEM IS NORMAL.

<Marking area has been changed.>

<Incorrect>

Item No.	Check items	Check conditions		Normal conditions
01	Vehicle speed (4WD calculated)	Perform a test run of the vehicle.		The speedometer display and the M.U.T.-III display almost agree with each other.
02	Ignition voltage	Ignition switch: ON		0 to 16 V
03	Coupling torque	Ignition switch: ON		0 to 730 N·m
04	Desired current of coupling	<ul style="list-style-type: none">• Drive mode selector: 4WD• Perform a test run of the vehicle.		The current changes between 0 and 5 A. (Command value and actual value agree with each other.)
05	Monitored current of coupling	<ul style="list-style-type: none">• Drive mode selector: 4WD• Perform a test run of the vehicle.		The current changes between 0 and 5 A. (Command value and actual value agree with each other.)
06	Temperature of coupling	Perform a test run of the vehicle.		0 to 200°C
07	CAN data (ABS/ASC)	Ignition switch: ON	When ABS/ASC-ECU data is correctly received	OK
			When ABS/ASC-ECU data reception error occurs	No reception
08	CAN data (engine)	Ignition switch: ON	When engine-ECU data is correctly received	OK
			When engine-ECU data reception error occurs	No reception
09	CAN data (ETACS)	Ignition switch: ON	When ETACS-ECU data is correctly received	OK
			When ETACS-ECU data reception error occurs	No reception
10	2WD SW	Ignition switch: ON	Drive mode selector: 2WD	ON
11	LOCK SW	Ignition switch: ON	Drive mode selector: LOCK	ON

ELECTRONIC CONTROL 4WD TROUBLESHOOTING

Item No.	Check items	Check conditions		Normal conditions
15	4WD mode (output)	Ignition switch: ON	Drive mode selector: 2WD	2WD
			Drive mode selector: 4WD	4WD
			Drive mode selector: 4WD LOCK	4WD LOCK
16	FL wheel speed sensor	Perform a test run of the vehicle. Check that there is difference between the right wheel speed and the left wheel speed when the vehicle turns.		The speedometer display and the M.U.T.-III display almost agree with each other.
17	FR wheel speed sensor			
18	RL wheel speed sensor			
19	RR wheel speed sensor			
21	Engine RPM	Perform a test run of the vehicle.		The tachometer display and the M.U.T.-III display almost agree with each other.
23	Ignition position	ON		ON
		START		START
24	Engine torque	Perform a test run of the vehicle.		The torque changes between 0 and 300 N·m.
26	APS	Ignition switch: ON	Release the accelerator pedal.	Approximately 0%
			Gradually depress the accelerator pedal.	0 – 100%
			Fully depress the accelerator pedal.	Approximately 100% (within 100%)
28	Limited torque (ASC required)	Ignition switch: ON	Drive mode selector: 4WD or 4WD LOCK	0 to 730 N·m

SYSTEM SHUT-DOWN

M.U.T.-III display data does not agree with the actual data when 4WD-ECU deactivates the 4WD control function by the fail-safe function.

<Incorrect>

<Replace with Attachment 8, 9>

ELECTRONIC CONTROL 4WD TROUBLESHOOTING

DATA LIST REFERENCE TABLE

M.U.T.-III can read the following items among various control data (input data from each ECU and switch) used by the electronic control 4WD system.

THE SYSTEM IS NORMAL.

<Marking area has been changed.>

<Correct>

Item No.	Check items	Check conditions	Normal conditions	
01	Vehicle speed (4WD calculated value)	Perform a test run of the vehicle.	The speedometer display and the M.U.T.-III display almost agree with each other.	
02	Ignition power supply voltage	Ignition switch: ON	0 to 16 V	
03	Coupling torque	<ul style="list-style-type: none">• Drive mode selector: 4WD• Perform a test run of the vehicle.	0 to 730 N·m	
04	Coupling current (command value)	<ul style="list-style-type: none">• Drive mode selector: 4WD• Perform a test run of the vehicle.	The current changes between 0 and 5 A. (Command value and actual value agree with each other.)	
05	Coupling current (monitor value)	<ul style="list-style-type: none">• Drive mode selector: 4WD• Perform a test run of the vehicle.	The current changes between 0 and 5 A. (Command value and actual value agree with each other.)	
06	Coupling temperature	<ul style="list-style-type: none">• Drive mode selector: 4WD• Perform a test run of the vehicle.	0 to 200°C <i>NOTE: Due to road surface condition the load to coupling varies, thus the temperature indication changes.</i>	
07	CAN system (ABS/ASC)	Ignition switch: ON	When ABS/ASC-ECU data is correctly received	OK
			When ABS/ASC-ECU data reception error occurs	No reception
08	CAN system (engine)	Ignition switch: ON	When engine-ECU data is correctly received	OK
			When engine-ECU data reception error occurs	No reception

ELECTRONIC CONTROL 4WD TROUBLESHOOTING

Item No.	Check items	Check conditions		Normal conditions
09	CAN system (ETACS)	Ignition switch: ON	When ETACS-ECU data is correctly received	OK
			When ETACS-ECU data reception error occurs	No reception
10	2WD SW	Ignition switch: ON	Drive mode selector: 2WD	ON
11	LOCK SW	Ignition switch: ON	Drive mode selector: LOCK	ON
15	4WD mode	Ignition switch: ON	Drive mode selector: 2WD	2WD
			Drive mode selector: 4WD	4WD
			Drive mode selector: LOCK	4WD LOCK
16	FL wheel speed sensor	Perform a test run of the vehicle. Check that there is difference between the right wheel speed and the left wheel speed when the vehicle turns.		The speedometer display and the M.U.T.-III display almost agree with each other.
17	FR wheel speed sensor			
18	RL wheel speed sensor			
19	RR wheel speed sensor			
21	Engine speed	Perform a test run of the vehicle.		The tachometer display and the M.U.T.-III display almost agree with each other.
23	Ignition position	ON		ON
		START		START
26	Throttle position	Ignition switch: ON	Release the accelerator pedal.	Approximately 0%
			Gradually depress the accelerator pedal.	0 – 100%
			Fully depress the accelerator pedal.	Approximately 100% (within 100%)
28	Limited torque	Perform a test run of the vehicle.	In case of traction control does not operate	–
			In case of traction control operates	0 to 730 N·m

SYSTEM SHUT-DOWN

<Correct>

M.U.T.-III display data does not agree with the actual data when 4WD-ECU deactivates the 4WD control function by the fail-safe function.

<Item No.24 has been deleted.>