



# SERVICE BULLETIN

GLOBAL AFTER SALES OFFICE, MITSUBISHI MOTORS CORPORATION

PURPOSE : CORRECTION	ISSUE NO. : MSB-11E35-501	DATE : 2011-07-05
SUBJECT : DIAGNOSIS CODE C2100 TROUBLESHOOTING PROCEDURE	<div> <div>&lt;MODEL&gt;</div> <div>(EUR/RUSSIA)</div> <div>LANCER</div> <div>(CY0A),</div> <div>OUTLANDER</div> <div>(CW0W)</div> </div> <div> <div>&lt;M/Y&gt;</div> <div>07-11</div> </div>	
GROUP : ANTI-SKID BRAKING SYSTEM (ABS)		

## 1. Description:

Some of the troubleshooting procedure steps for diagnosis code C2100 have been incorrect in the applicable Workshop Manuals. This Service Bulletin contains the corrected descriptions.

## 2. Applicable Manuals:

See Attached sheets 1 (1/2) to 1 (2/2).

There may be some attached sheets not included in this Service Bulletin because they are not applicable to your market. Their sheet numbers are not listed in the above table.

## 3. Corrected Specifications:

See Attached sheets 2, 4, 6, 8.

&lt;EUR&gt;

Manual	Pub. No.	Title (Info-ID)	Attached Sheet
2008 LANCER Workshop Manual CD-ROM	CG1E08E1-CD (English) CG1S08E1-CD (Spanish) CG1F08E1-CD (French) CG1G08E1-CD (German)	Code No.C2100 Abnormality in Battery Voltage (Low Voltage) (M352-02-900-12200-01)	Attached sheet 2
2007 OUTLANDER Workshop Manual CD-ROM	CGXE07E1-CD (English) CGXS07E1-CD (Spanish) CGXF07E1-CD (French) CGXG07E1-CD (German)	Code No.C2100 Abnormality in Battery Voltage (Low Voltage) (M352-02-900-01400-01)	Attached sheet 4
2008 OUTLANDER Workshop Manual CD-ROM	CGXE08E2-CD (English) CGXS08E2-CD (Spanish) CGXF08E2-CD (French) CGXG08E2-CD (German)	Code No.C2100 Abnormality in Battery Voltage (Low Voltage) (M352-02-900-15500-01)	Attached sheet 6
2009 OUTLANDER Workshop Manual CD-ROM	CGXE09E2-CD (English) CGXS09E2-CD (Spanish) CGXF09E2-CD (French) CGXG09E2-CD (German) CGXI09E2-CD (Italian)	Code No.C2100 Abnormality in Battery Voltage (Low Voltage) (M352-02-900-23000-01)  Code No.C2100 Abnormality in Battery Voltage (Low Voltage) (M352-02-900-23001-01)	Attached sheet 8
2010 OUTLANDER Workshop Manual CD-ROM	CGXE10E1-CD (English) CGXS10E1-CD (Spanish) CGXF10E1-CD (French) CGXG10E1-CD (German) CGXI10E1-CD (Italian)	Code No.C2100 Abnormality in Battery Voltage (Low Voltage) (M352-02-900-34800-01)	
2011 OUTLANDER Workshop Manual CD-ROM	CGXE11E1-CD (English) CGXS11E1-CD (Spanish) CGXF11E1-CD (French) CGXG11E1-CD (German) CGXI11E1-CD (Italian)	Code No.C2100 Abnormality in Battery Voltage (Low Voltage) (M352-02-900-34801-01)	

## &lt;RUSSIA&gt;

Underneath Manual	Underneath Pub. No.	Title (Info-ID)	Attached Sheet
2008 LANCER Workshop Manual	N/A	Code No.C2100 Abnormality in Battery Voltage (Low Voltage) (M352-02-900-09200-01)	Attached sheet 2

## ANTI-SKID BRAKING SYSTEM (ABS) TROUBLESHOOTING

Attached sheet 2 (1/2)

- (3) Measure the voltage between terminal No.26 and body earth.

**OK: Approximately battery voltage**

**Q: Is the check result normal?**

**YES :** Go to Step 8.

**NO :** Go to Step 7.


### STEP 7. Connector check: A-04 ABS-ECU connector

**Q: Is the check result normal?**

**YES :** The open or short circuit may be present in the power supply circuit. Repair the wiring harness between the A-04 ABS-ECU connector terminal No.26 and the fusible link No.27.

**NO :** Repair the defective connector.

### STEP 8. Resistance measurement at the A-04 ABS-ECU connector



- (1) Disconnect the ABS-ECU connector, connect

special tool ABS check harness (MB991974) to the harness-side connector, and then measure the resistance at the special tool connector side.

**NOTE:** Do not connect the special tool ABS check harness (MB991974) to ABS-ECU.

- (2) Resistance between terminal No.1 and body earth, and between terminal No.14 and body earth.

**OK: Continuity exists (2  $\Omega$  or less)**

**Q: Is the check result normal?**

**YES :** Go to Step 10.

**NO :** Go to Step 9.

### STEP 9. Connector check: A-04 ABS-ECU connector

**Q: Is the check result normal?**

**YES :** The open circuit may be present in the power supply circuit. Repair the wiring harness between the A-04 ABS-ECU connector terminal No.1 and body earth, and between the A-04 ABS-ECU connector terminal No.14 and body earth.

**NO :** Repair the defective connector.

### STEP 10. Check whether the diagnosis code is reset.

**Q: Is the diagnosis code No. C2100 set?**

**YES :** Replace the ABS-ECU (Refer to ).

**NO :** Intermittent malfunction (Refer to GROUP 00 – How to Cope with Intermittent Malfunction ).


<Incorrect>

From Attached sheet 2 (2/2)

<Incorrect>

To Attached sheet 2 (1/2)

&lt;Correct&gt;

**STEP 8. Voltage measurement at the A-04 ABS-ECU connector**

- (1) Disconnect the ABS-ECU connector, connect special tool ABS check harness (MB991974) to the harness-side connector, and then measure the voltage at the special tool connector side.

*NOTE: Do not connect the special tool ABS check harness (MB991974) to ABS-ECU.*

- (2) Turn the ignition switch to the "ON" position.  
 (3) Voltage between terminal No.7 and body earth.

**OK: Approximately system voltage**

**Q: Is the check result normal?**

**YES :** Go to Step 10.

**NO :** Go to Step 9.


**STEP 9. Connector check: A-04 ABS-ECU connector**

**Q: Is the check result normal?**

**YES :** The open circuit may be present in the power supply circuit. Repair the wiring harness between the A-04 ABS-ECU connector terminal No.7 and C-317 ETACS-ECU connector terminal No.5, fuse No.12. Or replace the ETACS-ECU (Refer to GROUP 54A – ETACS-ECU ).

**NO :** Repair the defective connector.

&lt;Correct&gt;

**STEP 10. Resistance measurement at the A-04 ABS-ECU connector**

- (1) Disconnect the ABS-ECU connector, connect special tool ABS check harness (MB991974) to the harness-side connector, and then measure the resistance at the special tool connector side.

*NOTE: Do not connect the special tool ABS check harness (MB991974) to ABS-ECU.*

- (2) Resistance between terminal No.1 and body earth, and between terminal No.14 and body earth.

**OK: Continuity exists (2 Ω or less)**

**Q: Is the check result normal?**

**YES :** Go to Step 12.

**NO :** Go to Step 11.

**STEP 11. Connector check: A-04 ABS-ECU connector**

**Q: Is the check result normal?**

**YES :** The open circuit may be present in the power supply circuit. Repair the wiring harness between the A-04 ABS-ECU connector terminal No.1 and body earth, and between the A-04 ABS-ECU connector terminal No.14 and body earth.

**NO :** Repair the defective connector.

**STEP 12. Check whether the diagnosis code is reset.**

**Q: Is the diagnosis code No. C2100 set?**

**YES :** Replace the ABS-ECU (Refer to ).

**NO :** Intermittent malfunction (Refer to GROUP 00 – How to Cope with Intermittent Malfunction ).

### OPERATION

When the power is supplied from the ignition switch (IG1) to the IG1 relay in ETACS-ECU, IG1 relay is turned on. At this time, the ABS-ECU power supply signal is sent to ABS-ECU (terminal No. 6) from the fusible link No. 33 through the multi-purpose fuse No. 12.

### DIAGNOSIS CODE SET CONDITIONS

This diagnosis code is set in the following case.

- When the ABS-ECU power supply voltage drops below  $9.7 \pm 0.3$  V during driving
- When the ABS-ECU power supply voltage drops below  $8.0 \pm 0.5$  V during driving

### PROBABLE CAUSES

- Battery failure
- Battery terminal looseness
- Charging system failed
- Damaged wiring harness and connectors
- ABS-ECU malfunction

### DIAGNOSIS PROCEDURE

#### STEP 1. M.U.T.-III CAN bus diagnosis

Use M.U.T.-III to diagnose the CAN bus lines.

**Q: Is the check result normal?**

**YES :** Go to Step 3.

**NO :** Repair the CAN bus lines (Refer to GROUP 54C – CAN Bus Diagnosis table ). On completion, go to Step 2.

#### STEP 2. Diagnosis code recheck after resetting CAN bus lines

**Q: Is the diagnosis code No. C2100 set?**

**YES :** Go to Step 3.

**NO :** This diagnosis is complete.

#### STEP 3. Battery check

Refer to GROUP 54A – Battery Test .

**Q: Is the battery in good condition?**

**YES :** Go to Step 4.

**NO :** Charge or replace the battery.

#### STEP 4. Charging system check


Refer to GROUP 16 – Charging System .

**Q: Is the charging system in good condition?**

**YES :** Go to Step 5.

**NO :** Repair or replace the charging system component(s).

#### STEP 5. Voltage measurement at the A-02 ABS-ECU connector



- (1) Disconnect the ABS-ECU connector, connect special tool ABS check harness (MB991974) to the harness-side connector, and then measure the resistance at the special tool connector side.

*NOTE: Do not connect the special tool ABS check harness (MB991974) to ABS-ECU.*

- (2) Turn the ignition switch to the ON position.
- (3) Measure the voltage between terminal No. 7 and body earth.

**OK: Battery voltage**

**Q: Is the check result normal?**

**YES :** Go to **Step 7.**

**NO :** Go to Step 6. **<Incorrect>**

**Step 8**

**<Correct>**

#### STEP 6. Connector check: A-02 ABS-ECU connector **<Added>**

**Q: Is the check result normal?**

**YES :** The open or short circuit may be present in the power supply circuit. Repair the wiring harness between the A-02 ABS-ECU connector terminal No. 7 and the fusible link No. 33.

**NO :** Repair the defective connector.

**Then go to Step 7.**

#### STEP 7. Check whether the diagnosis code is reset.

- Drive the vehicle at 20 km/h or more.

**Q: Is the diagnosis code No. C2100 set?**

MSB-

**From Attached sheet 4 (2/2)**

**ANTI-SKID BRAKING SYSTEM (ABS)  
TROUBLESHOOTING**

Attached sheet 4 (2/2)

~~YES : Replace the ABS-ECU.~~  
~~NO : Intermittent malfunction (Refer to GROUP 00 – How to Cope with Intermittent Malfunction ).~~

To Attached sheet 4 (1/2)

<Incorrect>

<Correct>

**STEP 7. Check whether the diagnosis code is reset.**

- Drive the vehicle at 20 km/h or more.

**Q: Is the diagnosis code No. C2100 set?**

**YES :** Replace the ETACS-ECU (Refer to GROUP 54A – ETACS-ECU ), and then go to Step 8.

**NO :** Intermittent malfunction (Refer to GROUP 00 – How to Cope with Intermittent Malfunction ).

**STEP 8. Check whether the diagnosis code is reset.**

- Drive the vehicle at 20 km/h or more.

**Q: Is the diagnosis code No. C2100 set?**

**YES :** Replace the ABS-ECU.

**NO :** Intermittent malfunction (Refer to GROUP 00 – How to Cope with Intermittent Malfunction ).


# **ANTI-SKID BRAKING SYSTEM (ABS) TROUBLESHOOTING**

Attached sheet 6 (1/2)

**YES :** The open or short circuit may be present in the power supply circuit. Repair the wiring harness between the A-02 ABS-ECU connector terminal No.26 and the fusible link No.27.

**NO :** Repair the defective connector.

## **STEP 8. Resistance measurement at the A-02 ABS-ECU connector**



(1) Disconnect the ABS-ECU connector, connect special tool ABS check harness (MB991974) to

the harness-side connector, and then measure the resistance at the special tool connector side.

**NOTE:** Do not connect the special tool ABS check harness (MB991974) to ABS-ECU.

(2) Resistance between terminal No.1 and body earth, and between terminal No.14 and body earth.

**OK:** Continuity exists (2  $\Omega$  or less)

**Q:** Is the check result normal?

**YES :** Go to Step 10.

**NO :** Go to Step 9.

## **STEP 9. Connector check: A-02 ABS-ECU connector**

**Q:** Is the check result normal?

**YES :** The open circuit may be present in the power supply circuit. Repair the wiring harness between the A-02 ABS-ECU connector terminal No.1 and body earth, and between the A-02 ABS-ECU connector terminal No.14 and body earth.

**NO :** Repair the defective connector.

## **STEP 10. Check whether the diagnosis code is reset.**

**Q:** Is the diagnosis code No. C2100 set?

**YES :** Replace the ABS-ECU (Refer to ).

**NO :** Intermittent malfunction (Refer to GROUP 00 – How to Cope with Intermittent Malfunction ).

<Incorrect>


<Incorrect>

From Attached sheet 6 (2/2)



To Attached sheet 6 (1/2)

&lt;Correct&gt;

**STEP 8. Voltage measurement at the A-02 ABS-ECU connector**

(1) Disconnect the ABS-ECU connector, connect special tool ABS check harness (MB991974) to the harness-side connector, and then measure the voltage at the special tool connector side.

**NOTE:** Do not connect the special tool ABS check harness (MB991974) to ABS-ECU.

(2) Turn the ignition switch to the "ON" position.

(3) Voltage between terminal No.7 and body earth.

**OK: Approximately system voltage**

**Q:** Is the check result normal?

**YES :** Go to Step 10.

**NO :** Go to Step 9.


**STEP 9. Connector check: A-02 ABS-ECU connector**

**Q:** Is the check result normal?

**YES :** The open circuit may be present in the power supply circuit. Repair the wiring harness between the A-02 ABS-ECU connector terminal No.7 and C-317 ETACS-ECU connector terminal No.5, fuse No.12. Or replace the ETACS-ECU (Refer to GROUP 54A – ETACS-ECU ).

**NO :** Repair the defective connector.

&lt;Correct&gt;

**STEP 10. Resistance measurement at the A-02 ABS-ECU connector**

(1) Disconnect the ABS-ECU connector, connect special tool ABS check harness (MB991974) to the harness-side connector, and then measure the resistance at the special tool connector side.

**NOTE:** Do not connect the special tool ABS check harness (MB991974) to ABS-ECU.

(2) Resistance between terminal No.1 and body earth, and between terminal No.14 and body earth.

**OK: Continuity exists (2 Ω or less)**

**Q:** Is the check result normal?

**YES :** Go to Step 12.

**NO :** Go to Step 11.

**STEP 11. Connector check: A-02 ABS-ECU connector**

**Q:** Is the check result normal?

**YES :** The open circuit may be present in the power supply circuit. Repair the wiring harness between the A-02 ABS-ECU connector terminal No.1 and body earth, and between the A-02 ABS-ECU connector terminal No.14 and body earth.

**NO :** Repair the defective connector.

**STEP 12. Check whether the diagnosis code is reset.**

**Q:** Is the diagnosis code No. C2100 set?

**YES :** Replace the ABS-ECU (Refer to ).

**NO :** Intermittent malfunction (Refer to GROUP 00 – How to Cope with Intermittent Malfunction ).

#### STEP 4. Charging system check

Refer to GROUP 16 – On-vehicle Service/Alternator Output Line Voltage Drop Test .

**Q: Is the charging system in good condition?**

**YES :** Go to Step 5.

**NO :** Repair or replace the charging system component(s).

#### STEP 5. Connector check: A-02 ABS-ECU connector, C-37 intermediate connector, C-210 ignition switch connector, C-309 ETACS-ECU connector, C-317 ETACS-ECU connector

**Q: Is the check result normal?**

**YES :** Go to Step 6.

**NO :** Repair the damaged connector. <Correct>

#### STEP 6. Fusible link check: Check the fusible link No.27.


**Q: Is the check result normal?**

**YES :** Go to Step 8.

**NO :** Go to Step 7.

#### STEP 7. Resistance measurement at A-02 ABS-ECU connector

(1) Removal the fusible link No.27.



(2) Disconnect the ABS-ECU connector, connect special tool ABS check harness (MB991974) to the harness-side connector, and then measure

the resistance at the special tool connector side.

*NOTE: Do not connect the special tool ABS check harness (MB991974) to ABS-ECU.*

(3) Resistance between the terminal No.26 and the body earth.

**OK: No continuity**

**Q: Is the check result normal?**


**YES :** Replace the fusible link No.27. Then go to

**Step 20.** <Incorrect>

**NO :** The short circuit may be present in the power supply circuit. Repair the wiring harness between the A-02 ABS-ECU connector terminal No.26 and the fusible link No.27, and then replace the fusible link No.27. Then go to **Step 20.** <Incorrect>

**Step 21**

#### STEP 8. Voltage measurement at the A-02 ABS-ECU connector



(1) Disconnect the **ASC-ECU** connector, connect special tool ABS check harness (MB991974) to the harness-side connector, and then measure the voltage at the special tool connector side.

*NOTE: Do not connect the special tool ABS check harness (MB991974) to **ASC-ECU**.* <Incorrect>

(2) Measure the voltage between terminal No.26 and body earth.

**OK: Approximately system voltage**

**Q: Is the check result normal?**

**ANTI-SKID BRAKING SYSTEM (ABS)  
TROUBLESHOOTING**

Attached sheet 8 (2/6)

**YES :** Go to Step 9.

**NO :** The open circuit may be present in the power supply circuit. Repair the wiring harness between the A-02 ABS-ECU connector terminal No.26 and the fusible link No.27. Then go to Step 20.

<Correct>

Step 21

<Incorrect>

**STEP 9. Check the fuse No.12.**

Visually check for open circuit in fuse No.12.


**Q: Is the check result normal?**

**YES :** Go to Step 11.

**NO :** Go to Step 10.

**STEP 10. Resistance measurement at A-02 ABS-ECU connector**

(1) Disconnect the C-317 ETACS-ECU connector.



(2) Disconnect the ABS-ECU connector, connect special tool ABS check harness (MB991974) to the harness-side connector, and then measure the resistance at the special tool connector side.

*NOTE: Do not connect the special tool ABS check harness (MB991974) to ABS-ECU.*

(3) Resistance between the terminal No.7 and the body earth.

**OK: No continuity**

**Q: Is the check result normal?**

<Incorrect>

From Attached sheet 8 (5/6),(6/6)

**YES :** Replace the fuse No.12. Then go to Step 20.

**NO :** The short circuit may be present in the power supply circuit. Repair the wiring harness between the A-02 ABS-ECU connector terminal No.7 and the C-317 ETACS-ECU connector terminal No.5, and then replace the fuse No.12. Then go to Step 20.

**STEP 11. Measure the voltage at the C-309 ETACS-ECU connector.**

- (1) Disconnect the connector, and measure at the wiring harness-side connector.
- (2) Measure the voltage between the terminal No.1 and the body earth.

**OK: Approximately system voltage**

**Q: Is the check result normal?**

**YES :** Go to Step 15.

**NO :** Go to Step 12.

**STEP 12. Fusible link check: Check the fusible link No.33.**

**Q: Is the check result normal?**

**YES :** Go to Step 14.

**NO :** Go to Step 13.

**STEP 13. Resistance measurement at C-309 ETACS-ECU connector**

- (1) Removal the fusible link No.33.
- (2) Disconnect the C-309 ETACS-ECU connector, and then measure the resistance at the harness connector side.
- (3) Resistance between the terminal No.1 and the body earth.

**OK: No continuity**

**Q: Is the check result normal?**

**YES :** Replace the fusible link No.33. Then go to Step 20.

**NO :** The short circuit may be present in the power supply circuit. Repair the wiring harness between the C-309 ETACS-ECU connector terminal No.1 and the fusible link No.33, and then replace the fusible link No.33. Then go to Step 20.

**STEP 14. Resistance measurement at fusible link No.33 and C-309 ETACS-ECU connector**

- (1) Disconnect the C-309 ETACS-ECU connector and fusible link No.33, and then measure the resistance at the harness connector side.

<Incorrect>

- (2) Resistance between the fusible link No.33 and C-309 ETACS-ECU connector terminal No.1.

**OK: Continuity exists (2  $\Omega$  or less)**


**Q: Is the check result normal?**

**YES :** Go to Step 20.

**NO :** The open circuit may be present in the power supply circuit. Repair the wiring harness between the fusible link No.33 and C-309 ETACS-ECU connector terminal No.1. Then go to Step 20.

**STEP 15. Resistance measurement at A-02 ABS-ECU connector**

- (1) Disconnect the C-317 ETACS-ECU connector.



- (2) Disconnect the A-02 ABS-ECU connector, connect special tool ABS check harness (MB991974) to the harness-side connector, and then measure the resistance at the special tool connector side.

**NOTE:** Do not connect the special tool ABS check harness (MB991974) to ABS-ECU.

- (3) Resistance between the A-02 ABS-ECU connector terminal No.7 and the C-317 ETACS-ECU connector terminal No.5.

**OK: Continuity exists (2  $\Omega$  or less)**

**Q: Is the check result normal?**

**YES :** Go to Step 16.

**NO :** The open circuit may be present in the power supply circuit. Repair the wiring harness between the A-02 ABS-ECU connector terminal No.7 and the C-317 ETACS-ECU connector terminal No.5. Then go to Step 20.

**STEP 16. Measure the voltage at the C-317 ETACS-ECU connector.**

- Measure by backprobing without disconnecting the connector.
- Turn the ignition switch to the ON position.
- Measure the voltage between the terminal No.6 and the body earth.

**OK: Approximately system voltage**

**Q: Is the check result normal?**

**YES :** Go to Step 18.

**NO :** Go to Step 17.

**STEP 17. Resistance measurement at C-317 ETACS-ECU connector and the C-210 ignition switch connector**

- Disconnect the C-317 ETACS-ECU connector and C-210 ignition switch connector, and then measure the resistance at the harness connector side.
- Resistance between the C-317 ETACS-ECU connector terminal No.6 and C-210 ignition switch connector terminal No.2.

**OK: Continuity exists (2  $\Omega$  or less)**

**Q: Is the check result normal?**

**YES :** Diagnosis the ignition switch (Refer to GROUP 54A – Ignition switch/Trouble symptom Chart ).

**NO :** The open circuit may be present in the power supply circuit. Repair the wiring harness between the C-317 ETACS-ECU connector terminal No.6 and C-210 ignition switch connector terminal No.2. Then go to Step 20.

**STEP 18. Check whether the diagnosis code is reset.**

- Erase the diagnosis code.
- Drive the vehicle at 20 km/h or higher.

**NOTE:** The ABS warning lamp does not turn OFF in some cases unless the vehicle runs at 20 km/h or higher.

**Q: Is the diagnosis code No.C2100 set?**

&lt;Incorrect&gt; ↓

**YES** : Replace the ETACS-ECU (Refer to GROUP 54A – ETACS-ECU ). Then go to Step 19.  
**NO** : Intermittent malfunction (Refer to GROUP 00 – How to Use Troubleshooting/How to Cope with Intermittent Malfunctions .)

**STEP 19. Check whether the diagnosis code is reset.**

- (1) Erase the diagnosis code.
- (2) Drive the vehicle at 20 km/h or higher.

*NOTE: The ABS warning lamp does not turn OFF in some cases unless the vehicle runs at 20 km/h or higher.*

**Q: Is the diagnosis code No.C2100 set?**

&lt;Incorrect&gt; ↑

&lt;Correct&gt;

**YES** : Replace the hydraulic unit (ABS-ECU) (Refer to ). Then go to Step 20.

**NO** : Intermittent malfunction (Refer to GROUP 00 – How to Use Troubleshooting/How to Cope with Intermittent Malfunctions .)

**STEP 20. Check whether the diagnosis code is reset.**

- (1) Erase the diagnosis code.
- (2) Drive the vehicle at 20 km/h or higher.

*NOTE: The ABS warning lamp does not turn OFF in some cases unless the vehicle runs at 20 km/h or higher.*

**Q: Is the diagnosis code No.C2100 set?**

**YES** : Return to Step 1.

**NO** : This diagnosis is complete.

&lt;Incorrect&gt; ↑

**STEP 20. Check whether the diagnosis code is reset.**

- (1) Erase the diagnosis code.
- (2) Drive the vehicle at 20 km/h or higher.

*NOTE: The ABS warning lamp does not turn OFF in some cases unless the vehicle runs at 20 km/h or higher.*

**Q: Is the diagnosis code No.C2100 set?**

**YES** : Replace the hydraulic unit (ABS-ECU) (Refer to ). Then go to Step 21.

**NO** : Intermittent malfunction (Refer to GROUP 00 - How to Use Troubleshooting/How to Cope with Intermittent Malfunctions).

**STEP 21. Check whether the diagnosis code is reset.**

- (1) Erase the diagnosis code.
- (2) Drive the vehicle at 20 km/h or higher.

*NOTE: The ABS warning lamp does not turn OFF in some cases unless the vehicle runs at 20 km/h or higher.*


**Q: Is the diagnosis code No.C2100 set?**

**YES** : Return to Step 1.

**NO** : This diagnosis is complete.

&lt;Correct&gt;

&lt;Correct&gt;

**STEP 9. Voltage measurement at the A-02 ABS-ECU connector**

- (1) Disconnect the ABS-ECU connector, connect special tool ABS check harness (MB991974) to the harness-side connector, and then measure the voltage at the special tool connector side.

*NOTE: Do not connect the special tool ABS check harness (MB991974) to ABS-ECU.*

- (2) Turn the ignition switch to the "ON" position.  
 (3) Voltage between terminal No.7 and body earth.

**OK: Approximately system voltage**

**Q: Is the check result normal?**

**YES :** Go to Step 20.

**NO :** Go to Step 10.

**STEP 10. Check the fuse No.12.**

Visually check for open circuit in fuse No.12.


**Q: Is the check result normal?**

**YES :** Go to Step 12.

**NO :** Go to Step 11.

**STEP 11. Resistance measurement at the A-02 ABS-ECU connector**

- (1) Disconnect the C-317 ETACS-ECU connector.



- (2) Disconnect the ABS-ECU connector, connect special tool ABS check harness (MB991974) to the harness-side connector, and then measure the resistance at the special tool connector side.

*NOTE: Do not connect the special tool ABS check harness (MB991974) to ABS-ECU.*

- (3) Resistance between the terminal No.7 and body earth.

**OK: No continuity**

**Q: Is the check result normal?**

**YES :** Replace the fuse No.12. Then go to Step 21.

**NO :** The short circuit may be present in the power supply circuit. Repair the wiring harness between the A-02 ABS-ECU connector terminal No.7 and the C-317 ETACS-ECU connector terminal No.5, and then replace the fuse No.12. Then go to Step 21.

**STEP 12. Measure the voltage at the C-309 ETACS-ECU connector.**

- (1) Disconnect the connector, and measure at the wiring harness-side connector.

- (2) Measure the voltage between the terminal No.1 and the body earth.

**OK: Approximately system voltage**

**Q: Is the check result normal?**

**YES :** Go to Step 15.

**NO :** Go to Step 13.

**STEP 13. Fusible link check: Check the fusible link No.33.**

**Q: Is the check result normal?**

**YES :** Go to Step 15.

**NO :** Go to Step 14.



&lt;Correct&gt;

**STEP 14. Resistance measurement at the C-309 ETACS-ECU connector**


- (1) Removal the fusible link No.33.
- (2) Disconnect the C-309 ETACS-ECU connector, and then measure the resistance at the harness connector side.
- (3) Resistance between the terminal No.1 and the body earth.

**OK: No continuity****Q: Is the check result normal?****YES :** Replace the fusible link No.33. Then go to Step 21.**NO :** The short circuit may be present in the power supply circuit. Repair the wiring harness between the C-309 ETACS-ECU connector terminal No.1 and the fusible link No.33, and then replace the fusible link No.33. Then go to Step 21.**STEP 15. Resistance measurement at fusible link No.33 and C-309 ETACS-ECU connector**

- (1) Disconnect the C-309 ETACS-ECU connector and fusible link No.33, and then measure the resistance at the harness connector side.
- (2) Resistance between the fusible link No.33 and C-309 ETACS-ECU connector terminal No.1.

**OK: Continuity exists (2 Ω or less)****Q: Is the check result normal?****YES :** Go to Step 16.**NO :** The open circuit may be present in the power supply circuit. Repair the wiring harness between the fusible link No.33 and C-309 ETACS-ECU connector terminal No.1. Then go to Step 21.**STEP 16. Resistance measurement at the A-02 ABS-ECU connector**

- (1) Disconnect the C-317 ETACS-ECU connector



- (2) Disconnect the A-02 ABS-ECU connector, connect special tool ABS check harness (MB991974) to the harness-side connector, and then measure the resistance at the special tool connector side.  
*NOTE: Do not connect the special tool ABS check harness (MB991974) to ABS-ECU.*
- (3) Resistance between the A-02 ABS-ECU connector terminal No.7 and the C-317 ETACS-ECU connector terminal No.5.

**OK: Continuity exists (2 Ω or less)****Q: Is the check result normal?****YES :** Go to Step 17.**NO :** The open circuit may be present in the power supply circuit. Repair the wiring harness between the A-02 ABS-ECU connector terminal No.7 and the C-317 ETACS-ECU connector terminal No.5. Then go to Step 21.**STEP 17. Measure the voltage at the C-317 ETACS-ECU connector.**

- (1) Measure by backprobing without disconnecting the connector.
- (2) Turn the ignition switch to the "ON" position.
- (3) Measure the voltage between the terminal No.6 and the body earth.

**OK: Approximately system voltage****Q: Is the check result normal?****YES :** Go to Step 20.**NO :** Go to Step 18.**STEP 18. Resistance measurement at the C-317 ETACS-ECU connector and the C-210 ignition switch connector**

- (1) Disconnect the C-317 ETACS-ECU connector and C-210 ignition switch connector, and then measure the resistance at the harness connector side.
- (2) Resistance between the C-317 ETACS- ECU connector terminal No.6 and C-210 ignition switch connector terminal No.2.

**OK: Continuity exists (2 Ω or less)****Q: Is the check result normal?****YES :** Diagnosis the ignition switch (Refer to GROUP 54A – Ignition switch/Trouble symptom Chart ) and then go to Step 21.**NO :** The open circuit may be present in the power supply circuit. Repair the wiring harness between the C-317 ETACS-ECU connector terminal No.6 and C-210 ignition switch connector terminal No.2. Then go to Step 19.**STEP 19. Check whether the diagnosis code is reset.**

- (1) Erase the diagnosis code.
- (2) Drive the vehicle at 20 km/h or higher.  
*NOTE: The ABS warning lamp does not turn OFF in some cases unless the vehicle runs at 20 km/h or higher.*

**Q: Is the diagnosis code No.C2100 set?****YES :** Replace the ETACS-ECU (Refer to GROUP 54A – ETACS-ECU ). Then go to Step 20.**NO :** Intermittent malfunction (Refer to GROUP 00 – How to Use Troubleshooting/How to Cope with Intermittent Malfunctions).