

SERVICE BULLETIN

GLOBAL AFTER SALES OFFICE, MITSUBISHI MOTORS CORPORATION

PURPOSE : CHANGE	ISSUE NO.: MSB-14EXL13-001	DATE: 2014-04-16	
SUBJECT: TROUBLESHOOTING REGARDING DPF		<destination model=""> (As per attached sheet 1)</destination>	<m y=""></m>
GROUP : DIESEL FUEL(G			

1. Description:

Please refer to the attached document for the information about the change of mention in the applicable service manual.(The following troubleshooting regarding DPF have been changed)

P0101: Air Flow Sensor Range/Performance Problem (Addition)

P1497: DPF System Malfunction(Correction)

P1498: Excessive Pm Accumulated In DPF (Correction) P1499: Abnormally high DPF temperature (Correction)

P2453: Exhaust Differential Pressure Sensor Range/Performance Problem (Addition)

P252F: Engine Oil Level Malfunction(Correction)

PROBLEM SYMPTOMS TABLE The DPF regeneration interval is short(Addition)

2. Affected service manuals:

Please refer to the attached document (Attached sheet 1)

3. About the details:

Please refer to the attached document (Attached sheet 2-41)

4. Effective time: From the initial vehicle

Attached sheet 1 (1/6)

EU - ASX

EU - ASX			
Applicable manual	Pub. No.	Applicable title(Info-ID)	Contents
2011 ASX	CGWE11E2-CD (English)	G13B DIAGNOSIS FUNCTION	Attached sheet 2
Workshop Manual	CGWF11E2-CD (French)	CODE (M133-00-380-76100-01)	
-	CGWG11E2-CD (German)	G13B INSPECTION CHART FOR DIAGNOSIS	Attached sheet 3
	CGWS11E2-CD (Spanish)	CODE (M133-00-400-75700-01)	
	CGWI11E2-CD (Italian)	G13B CODE No. CODE No. P0102: AIR FLOW	Attached sheet 4
	, ,	SENSOR CIRCUIT LOW INPUT [before]	
		(M133-50-390-48400-01)	
		G13B CODE No. P1497: DPF SYSTEM	Attached sheet 5
		MALFUNCTION (M133-52-470-10601-01)	7 tttdoriod oriodt o
		G13B CODE No. P1498: EXCESSIVE PM	Attached sheet 6
		ACCUMULATED IN DPF	7 tttacrica cricot c
		(M133-52-480-08400-01)	
		G13B CODE No. P1499: ABNORMALLY HIGH	Attached sheet 7
		DPF TEMPERATURE (M133-52-490-08100-01)	Allached Sheet I
		G13B CODE No. CODE No. P2454: EXHAUST	Attached sheet 8
		DIFFERENTIAL PRESSURE SENSOR CIRCUIT	Allacried Srieel o
		LOW Input [before] (M133-52-500-10000-01) G13B CODE No. P252F: ENGINE OIL LEVEL	Attached cheet 0
			Attached sheet 9
		MALFUNCTION (M133-52-520-09600-01)	A (- - - - - 4 0
		G13B INSPECTION CHART FOR TROUBLE	Attached sheet 10
		SYMPTOMS (M113300410061300)	A 1 1 1 1.4
		G13B DATA LIST REFERENCE TABLE [before]	Attached sheet 11
22/2 12/		(M133-00-420-86900-01)	
2012 ASX	CGWE12E1-CD (English)	G13B DIAGNOSIS FUNCTION	Attached sheet 2
Workshop Manual	CGWF12E1-CD (French)	CODE (M133-00-380-96500-01)	
	CGWG12E1-CD (German)	G13B INSPECTION CHART FOR DIAGNOSIS	Attached sheet 12
	CGWS12E1-CD (Spanish)	CODE (M133-00-400-97300-01)	
	CGWI12E1-CD (Italian)	G13B CODE No. CODE No. P0102: AIR FLOW	Attached sheet 4
		SENSOR CIRCUIT LOW INPUT [before]	
		(M133-50-390-48400-01)	
		G13B CODE No. P1497: DPF SYSTEM	Attached sheet 5
		MALFUNCTION (M133-52-470-10601-01)	
		G13B CODE No. P1498: EXCESSIVE PM	Attached sheet 13
		ACCUMULATED IN DPF	
		(M133-52-480-11400-01)	
		G13B CODE No. P1499: ABNORMALLY HIGH	Attached sheet 7
		DPF TEMPERATURE (M133-52-490-08100-01)	
		G13B CODE No. CODE No. P2454: EXHAUST	Attached sheet 8
		DIFFERENTIAL PRESSURE SENSOR CIRCUIT	
		LOW Input [before] (M133-52-500-10000-01)	
		G13B CODE No. P252F: ENGINE OIL LEVEL	Attached sheet 9
		MALFUNCTION (M133-52-520-09600-01)	
		G13B INSPECTION CHART FOR TROUBLE	Attached sheet 10
		SYMPTOMS (M133-00-410-61300-01)	
		G13B DATA LIST REFERENCE TABLE [before]	Attached sheet 11
		(M133-00-421-02200-01)	
2013 ASX	CGAE13E2-CD (English)	G13B CODE No. P252F: ENGINE OIL LEVEL	Attached sheet 14
Workshop Manual	CGAF13E2-CD (French)	MALFUNCTION (M133-52-520-18200-01)	
l little in the interest of th	CGAG13E2-CD (German)	G13B INSPECTION CHART FOR TROUBLE	Attached sheet 10
	CGAS13E2-CD (Spanish)	SYMPTOMS (M133-00-410-61300-01)	,aonoa onoce 10
	CGAI13E2-CD (Italian)		
		G13B DATA LIST REFERENCE TABLE [before]	Attached sheet 11
		(M133-00-421-17400-01)	
2014 ASX	CGAE14E1-CD (English)	G13B CODE No. P252F: ENGINE OIL LEVEL	Attached sheet 14
Workshop Manual	CGAF14E1-CD (English) CGAF14E1-CD (French)	MALFUNCTION (M133-52-520-18200-01)	/ macried sheet 14
vvoinsilop mailuai	CGAG14E1-CD (French) CGAG14E1-CD (German)	G13B INSPECTION CHART FOR TROUBLE	Attached sheet 10
	CGAS14E1-CD (German)	SYMPTOMS (M133-00-410-61300-01)	Allached Sheet 10
	CGAI14E1-CD (Spanish)	CTIVIL TOTALO (WITSS-00-410-01300-01)	
	CONTINUE TOD (Italian)	G13B DATA LIST REFERENCE TABLE [before]	Attached sheet 11
		(M133-00-421-17400-01)	, madrida drieet 11
	1	\miloo oo 721 11700 oij	ļ

EU - OUTLANDER (CW0W)

Applicable manual	<u> </u>	Applicable title/lefe ID)	Contento
	Pub. No.	Applicable title(Info-ID)	Contents
	CGXE11E1-CD (English)	G13F DIAGNOSIS FUNCTION	Attached sheet 15
	CGXF11E1-CD (French)	CODE (M133-00-380-83500-01)	A 1 1 1 1 0
	CGXG11E1-CD (German)	G13F INSPECTION CHART FOR DIAGNOSIS	Attached sheet 3
•	CGXS11E1-CD (Spanish)	CODE (M133-00-400-83200-01)	
'	CGXI11E1-CD (Italian)	G13F CODE No. CODE No. P0102: AIR FLOW	Attached sheet 16
		SENSOR CIRCUIT LOW INPUT [before]	
		(M133-50-390-56900-01)	
		G13F CODE No. P1497: DPF SYSTEM	Attached sheet 17
		MALFUNCTION (M133-52-470-12800-01)	
		G13F CODE No. P1498: EXCESSIVE PM	Attached sheet 18
		ACCUMULATED IN DPF	
		(M133-52-480-10300-01)	
		G13F CODE No. P1499: ABNORMALLY HIGH	Attached sheet 7
		DPF TEMPERATURE (M133-52-490-10000-01)	
		G13F CODE No. CODE No. P2454: EXHAUST	Attached sheet 8
		DIFFERENTIAL PRESSURE SENSOR CIRCUIT	
		LOW Input [before] (M133-52-500-14400-01)	
		G13F CODE No. P252F: ENGINE OIL LEVEL	Attached sheet 9
		MALFUNCTION (M133-52-520-11500-01)	7
		G13F INSPECTION CHART FOR TROUBLE	Attached sheet 19
		SYMPTOMS (M133-00-410-67900-01)	/ titadrica dricot 10
		G13F DATA LIST REFERENCE TABLE [before]	Attached sheet 20
		(M133-00-420-87000-01)	Attached Sheet 20
2012	CGXE12E1-CD (English)	G13F DIAGNOSIS FUNCTION	Attached sheet 15
	CGXF12E1-CD (French)	CODE (M133-00-380-93200-01)	Attached Sheet 15
	CGXG12E1-CD (German)	G13F INSPECTION CHART FOR DIAGNOSIS	Attached sheet 12
` '	CGXS12E1-CD (Spanish)	CODE (M133-00-400-94000-01)	Allached Sheet 12
	CGXI12E1-CD (Italian)	G13F CODE No. CODE No. P0102: AIR FLOW	Attached sheet 16
	COXITEET-CD (Italian)		Attached Sheet 16
		SENSOR CIRCUIT LOW INPUT [before]	
		(M133-50-390-56900-01)	A + + - - - - 4.7
		G13F CODE No. P1497: DPF SYSTEM	Attached sheet 17
		MALFUNCTION (M133-52-470-12800-01)	A (- - - - 4 O
		G13F CODE No. P1498: EXCESSIVE PM	Attached sheet 13
		ACCUMULATED IN DPF	
		(M133-52-480-14700-01)	
		G13F CODE No. P1499: ABNORMALLY HIGH	Attached sheet 7
		DPF TEMPERATURE (M133-52-490-10000-01)	
		G13F CODE No. CODE No. P2454: EXHAUST	Attached sheet 8
		DIFFERENTIAL PRESSURE SENSOR CIRCUIT	
		LOW Input [before] (M133-52-500-14400-01)	
		G13F CODE No. P252F: ENGINE OIL LEVEL	Attached sheet 9
		MALFUNCTION (M133-52-520-11500-01)	
		G13F INSPECTION CHART FOR TROUBLE	Attached sheet 19
1		SYMPTOMS (M133-00-410-67900-01)	
		01Wi 10W6 (W133 00 410 07300 01)	
		G13F DATA LIST REFERENCE TABLE [before]	Attached sheet 20

EU - OUTLANDER(CF0W)

Applicable manual	Pub. No.	Applicable title(Info-ID)	Contents
2013	CGFE13E1-CD (English)	G13D DIAGNOSIS FUNCTION	Attached sheet 21
OUTLANDER	CGFF13E1-CD (French)	CODE (M133-00-381-00900-01)	
(CF0W)	CGFG13E1-CD (German)	G13D INSPECTION CHART FOR DIAGNOSIS	Attached sheet 22
Workshop Manual I	CGFS13E1-CD (Spanish)	CODE (M133-00-401-02800-01)	
	CGFI13E1-CD (Italian)	G13D CODE No. CODE No. P0102: AIR FLOW	Attached sheet 23
		SENSOR CIRCUIT LOW INPUT [before]	
		(M133-50-390-64400-01)	
		G13D CODE No. P1497: DPF SYSTEM	Attached sheet 24
		MALFUNCTION (M133-52-470-16200-01)	
		G13D CODE No. P1498: EXCESSIVE PM	Attached sheet 25
		ACCUMULATED IN DPF	
		(M133-52-480-16900-01)	
		G13D CODE No. P1499: ABNORMALLY HIGH	Attached sheet 7
		DPF TEMPERATURE (M133-52-490-15500-01)	
		G13D CODE No. CODE No. P2454: EXHAUST	Attached sheet 26
		DIFFERENTIAL PRESSURE SENSOR CIRCUIT	
		LOW Input [before] (M133-52-500-15500-01)	
		G13D CODE No. P252F: ENGINE OIL LEVEL	Attached sheet 9
		MALFUNCTION (M133-52-520-15900-01)	
		G13D INSPECTION CHART FOR TROUBLE	Attached sheet 27
		SYMPTOMS (M133-00-410-76500-01)	
		G13D DATA LIST REFERENCE TABLE [before]	Attached sheet 28
		(M133-00-421-07700-01)	
2014	CGFE14E2-CD (English)	G13D CODE No. P1497: DPF SYSTEM	Attached sheet 24
OUTLANDER	CGFF14E2-CD (French)	MALFUNCTION (M133-52-470-16200-01)	
(CF0W)	CGFG14E2-CD (German)	G13D CODE No. P1499: ABNORMALLY HIGH	Attached sheet 7
Workshop Manual	CGFS14E2-CD (Spanish)	DPF TEMPERATURE (M133-52-490-15500-01)	
	CGFI14E2-CD (Italian)	G13D INSPECTION CHART FOR TROUBLE	Attached sheet 27
		SYMPTOMS (M133-00-410-76500-01)	
		G13D DATA LIST REFERENCE TABLE [before]	Attached sheet 28
		(M133-00-421-23700-01)	
2014.5	CGFE14E3-CD (English)	G13D CODE No. P1497: DPF SYSTEM	Attached sheet 24
OUTLANDER	CGFF14E3-CD (French)	MALFUNCTION (M133-52-470-16200-01)	
(CF0W)	CGFG14E3-CD (German)	G13D CODE No. P1499: ABNORMALLY HIGH	Attached sheet 7
Workshop Manual	CGFS14E3-CD (Spanish)	DPF TEMPERATURE (M133-52-490-15500-01)	
	CGFI14E3-CD (Italian)	G13D INSPECTION CHART FOR TROUBLE	Attached sheet 27
		SYMPTOMS (M133-00-410-76500-01)	
		G13D DATA LIST REFERENCE TABLE [before]	Attached sheet 28
		(M133-00-421-23700-01)	

EU - LANCER / LANCER SPORTBACK (CY0A/CX0A)

Applicable manual	Pub. No.	Applicable title(Info-ID)	Contents
2011	CG1E11E1-CD (English)	G13C DIAGNOSIS FUNCTION	Attached sheet 29
LANCER/LANCER	CG1F11E1-CD (French)	(M133-00-380-80200-01)	
SPORTBACK	CG1G11E1-CD (German)	G13C INSPECTION CHART FOR DIAGNOSIS	Attached sheet 3
(CY0A/CX0A)	CG1S11E1-CD (Spanish)	CODE (M133-00-400-80900-01)	
Workshop Manual	CG1I11E1-CD (Italian)	G13C CODE No. P0102: AIR FLOW SENSOR	Attached sheet 30
CD-ROM	,	CIRCUIT LOW INPUT [before]	7
		(M133-50-390-53600-01)	
		G13C CODE No. P1497: DPF SYSTEM	Attached sheet 5
		MALFUNCTION (M133-52-470-11700-01)	
		G13C CODE No. P1498: EXCESSIVE PM	Attached sheet 6
		ACCUMULATED IN DPF	
		(M133-52-480-12500-01)	
		G13C CODE No. P1499: ABNORMALLY HIGH	Attached sheet 7
		DPF TEMPERATURE (M133-52-490-09200-01)	
		G13C CODE No. P2454: EXHAUST	Attached sheet 31
		DIFFERENTIAL PRESSURE SENSOR CIRCUIT	
		LOW Input [before] (M133-52-500-11100-01)	
		G13C CODE No. P252F: ENGINE OIL LEVEL	Attached sheet 9
		MALFUNCTION (M133-52-520-10400-01)	
		G13C INSPECTION CHART FOR TROUBLE	Attached sheet 32
		SYMPTOMS (M133-00-410-63500-01)	
		G13C DATA LIST REFERENCE TABLE [before]	Attached sheet 11
		(M133-00-420-87000-01)	
2012	CGSE12E1-CD (English)	G13C DIAGNOSIS FUNCTION	Attached sheet 29
LANCER/LANCER	CGSF12E1-CD (French)	CODE (M133-00-380-97600-01)	
SPORTBACK	CGSG12E1-CD (German)	G13C INSPECTION CHART FOR DIAGNOSIS	Attached sheet 3
(CY0A/CX0A)	CGSS12E1-CD (Spanish)	CODE (M133-00-400-99500-01)	
Workshop Manual	CGSI12E1-CD (Italian)	G13C CODE No. P0102: AIR FLOW SENSOR	Attached sheet 30
CD-ROM		CIRCUIT LOW INPUT [before]	
		(M133-50-390-63300-01)	
		G13C CODE No. P1497: DPF SYSTEM	Attached sheet 5
		MALFUNCTION (M133-52-470-11700-01)	
		G13C CODE No. P1498: EXCESSIVE PM	Attached sheet 6
		ACCUMULATED IN DPF	
		(M133-52-480-12500-01)	
		G13C CODE No. P1499: ABNORMALLY HIGH	Attached sheet 7
		DPF TEMPERATURE (M133-52-490-09200-01)	
		G13C CODE No. P2454: EXHAUST	Attached sheet 33
		DIFFERENTIAL PRESSURE SENSOR CIRCUIT	
		LOW Input [before] (M133-52-500-14400-01)	
		G13C CODE No. P252F: ENGINE OIL LEVEL	Attached sheet 9
		MALFUNCTION (M133-52-520-10400-01)	
		G13C INSPECTION CHART FOR TROUBLE	Attached sheet 32
		SYMPTOMS (M133-00-410-63500-01)	
		G13C DATA LIST REFERENCE TABLE [before]	Attached sheet 11
		(M133-00-421-05500-01)	

EU - LANCER / LANCER SPORTBACK (CY0A/CX0A)

Applicable manual	Pub. No.	Applicable title(Info-ID)	Contents
2013	CCAE13E1-CD (English)	G13C DIAGNOSIS FUNCTION	Attached sheet 34
LANCER/LANCER	CCAF13E1-CD (French)	CODE (M133-00-381-08700-01)	
SPORTBACK	CCAG13E1-CD (German)	G13C INSPECTION CHART FOR DIAGNOSIS	Attached sheet 22
(CY0A/CX0A)	CCAS13E1-CD (Spanish)	CODE (M133-00-401-10300-01)	
Workshop Manual	CCAI13E1-CD (Italian)	G13C CODE No. P0102: AIR FLOW SENSOR	Attached sheet 30
CD-ROM		CIRCUIT LOW INPUT [before]	
		(M133-50-390-63300-01)	
		G13C CODE No. P1497: DPF SYSTEM	Attached sheet 5
		MALFUNCTION (M133-52-470-11700-01)	
		G13C CODE No. P1498: EXCESSIVE PM	Attached sheet 6
		ACCUMULATED IN DPF	
		(M133-52-480-12500-01)	
		G13C CODE No. P1499: ABNORMALLY HIGH	Attached sheet 7
		DPF TEMPERATURE (M133-52-490-09200-01)	
		G13C CODE No. P2454: EXHAUST	Attached sheet 33
		DIFFERENTIAL PRESSURE SENSOR CIRCUIT	
		LOW Input [before] (M133-52-500-14400-01)	
		G13C CODE No. P252F: ENGINE OIL LEVEL	Attached sheet 9
		MALFUNCTION (M133-52-520-10400-01)	
		G13C INSPECTION CHART FOR TROUBLE	Attached sheet 32
		SYMPTOMS (M133-00-410-63500-01)	
		G13C DATA LIST REFERENCE TABLE [before]	Attached sheet 11
		(M133-00-421-05500-01)	


G.EXP/GCC/MMAL/NZ - ASX

G.EXP/GCC/MINIAL/NZ - ASX			
Applicable manual	Pub. No.	Applicable title(Info-ID)	Contents
2011 ASX	PWPE1006R (English)	G13B DIAGNOSIS FUNCTION	Attached sheet 2
Workshop Manual	PWPS1007R (Spanish)	CODE (M133-00-380-76100-01)	
	NZ:DRAFT	G13B INSPECTION CHART FOR DIAGNOSIS	Attached sheet 3
	MMAL:AU900409	CODE (M133-00-400-75700-01)	
		G13B CODE No. CODE No. P0102: AIR FLOW	Attached sheet 4
		SENSOR CIRCUIT LOW INPUT [before]	
		(M133-50-390-48400-01)	
		G13B CODE No. P1497: DPF SYSTEM	Attached sheet 5
		MALFUNCTION (M133-52-470-10601-01)	
		G13B CODE No. P1498: EXCESSIVE PM	Attached sheet 6
		ACCUMULATED IN DPF	
		(M133-52-480-11400-01)	
		G13B CODE No. P1499: ABNORMALLY HIGH	Attached sheet 7
		DPF TEMPERATURE (M133-52-490-08100-01)	
		G13B CODE No. CODE No. P2454: EXHAUST	Attached sheet 8
		DIFFERENTIAL PRESSURE SENSOR CIRCUIT	
		LOW Input [before] (M133-52-500-10000-01)	
		G13B CODE No. P252F: ENGINE OIL LEVEL	Attached sheet 9
		MALFUNCTION (M133-52-520-09600-01)	
		G13B INSPECTION CHART FOR TROUBLE	Attached sheet 10
		SYMPTOMS (M133-00-410-61300-01)	
		G13B DATA LIST REFERENCE TABLE [before]	Attached sheet 11
		(M133-00-420-86900-01)	

MMAL / NZ - OUTLANDER(CF0W)

Applicable manual	Pub. No.	Applicable title(Info-ID)	Contents
2013 OUTLANDER	MMAL:AU900304	G13B DIAGNOSIS FUNCTION	Attached sheet 35
(CF0W)Workshop	NZ:DRAFT	CODE (M133-00-381-09800-01)	
Manual		G13B INSPECTION CHART FOR DIAGNOSIS	Attached sheet 22
		CODE (M133-00-401-11400-01)	
		G13B CODE No. P0102: AIR FLOW SENSOR	Attached sheet 36
		CIRCUIT LOW INPUT [before]	
		(M133-50-390-65500-01)	
		G13B CODE No. P1497: DPF SYSTEM	Attached sheet 37
		MALFUNCTION (M133-52-470-18400-01)	
		G13B CODE No. P1498: EXCESSIVE PM	Attached sheet 38
		ACCUMULATED IN DPF	
		(M133-52-480-20000-01)	
		G13B CODE No. P1499: ABNORMALLY HIGH	Attached sheet 39
		DPF TEMPERATURE (M133-52-490-17700-01)	
		G13B CODE No. P2454: EXHAUST	Attached sheet 40
		DIFFERENTIAL PRESSURE SENSOR CIRCUIT	
		LOW Input [before] (M133-52-500-24100-01)	
		G13B CODE No. P252F: ENGINE OIL LEVEL	Attached sheet 41
		MALFUNCTION (M133-52-520-17100-01)	
		G13B INSPECTION CHART FOR TROUBLE	Attached sheet 27
		SYMPTOMS (M133-00-410-79800-01)	
		G13 B DATA LIST REFERENCE TABLE [before]	Attached sheet 28
		(M133-00-421-15200-01)	

DIAGNOSIS FUNCTION



ENGINE WARNING LAMP (CHECK ENGINE LAMP)

When the abnormal condition occurs with respect to the items of electronically controlled fuel injection system shown in the table, the engine warning lamp is illuminated. When the lamp remains illuminated after the engine start, or when the lamp is illuminated while the engine is running, check the diagnosis code output. There are two methods for checking the indicator lamp burn out: When the ignition switch is in ON position, the indicator lamp is illuminated, and then extinguished few seconds later. When the ignition switch is in ON position and the engine starts, the indicator lamp is extinguished.

ENGINE WARNING LAMP INSPECTION ITEMS

Code No.	Diagnosis item
P0003*1	Suction control valve open
P0004*1	Suction control valve battery short
P0016 ^{*1}	Crank angle sensor/camshaft position sensor phase problem
P0047*1	Variable geometry control solenoid valve circuit low input
P0048 ^{*1}	Variable geometry control solenoid valve circuit high input
P0072	No. 1 intake air temperature sensor circuit low input
P0073	No. 1 intake air temperature sensor circuit high input
P0088*1	Common rail high pressure malfunction
P0089*1	Suction control valve stuck
P0093 ^{*1}	Fuel leak problem
P0102	Air flow sensor circuit low input
P0103	Air flow sensor circuit high input

	<u> </u>		_
	P2229	Barometric pressure sensor circuit high input]
	P2413	EGR system performance	
> >	P2427	EGR cooling valve control circuit (High)	
	P2454 ^{*1}	Exhaust differential pressure sensor circuit low input	
	P2455*1	Exhaust differential pressure sensor circuit high input	L.

P2453*1

Exhaust differential pressure sensor range/performance problem

P0102	Air flow sensor circuit low input	 restriction) The open angle of the accelerator pedal is restricted. The throttle valve is closed. (Fixed opening degree) The EGR control is stopped (fully closed). The DPF regeneration is prohibited. The AS&G control is prohibited. The control is performed using the previous value.
		 The DPF regeneration is prohibited. The throttle valve is opened. (Electrical discontinuity) The EGR control is stopped (fully closed). The AS&G control is prohibited.
P0103	Air flow sensor circuit high input	 The control is performed using the previous value. The DPF regeneration is prohibited. The throttle valve is opened. (Electrical discontinuity) The EGR control is stopped (fully closed). The AS&G control is prohibited.
P0106	Manifold absolute pressure sensor range/performance problem	 The pressure in the inlet manifold is controlled to be 100 kPa. The EGR control is stopped (fully closed). The fuel injection amount is restricted. (Output restriction) The open angle of the accelerator pedal is restricted. The DPF regeneration is prohibited. The throttle valve is opened. (Electrical discontinuity) The AS&G control is prohibited.
P0107	Manifold absolute pressure sensor circuit low input	 The pressure in the inlet manifold is controlled to be 100 kPa. The EGR control is stopped (fully closed). The fuel injection amount is restricted. (Output restriction) The turbocharger control is prohibited. The open angle of the accelerator pedal is restricted. The DPF regeneration is prohibited. The throttle valve is opened. (Electrical discontinuity) The AS&G control is prohibited.
P0101	Air flow sensor range/ performance problem	 The control is performed using the previous value. The DPF regeneration is prohibited. The throttle valve is opened. (Electrical discontinuity The EGR control is stopped (fully closed).

<Added>

 <u> </u>		
 P2427	EGR cooling valve control circuit (High)	
P2454	Exhaust differential pressure sensor circuit low input	 The throttle valve is opened. (Electrical discontinuity) The EGR control is stopped (fully closed). The DPF regeneration is prohibited. The AS&G control is prohibited.
 P2455	Exhaust differential pressure sensor circuit high input	 The throttle valve is opened. (Electrical discontinuity) The EGR control is stopped (fully closed). The DPF regeneration is prohibited. The AS&G control is prohibited.

P2453	Exhaust differential pressure sensor range/performance	 The DPF regeneration is prohibited. The AS&G control is prohibited. The EGR control is stopped (fully closed). The throttle valve is opened. (Electrical discontinuity) 	
-------	--	--	--

INSPECTION CHART FOR DIAGNOSIS CODE

Diagnosis code No.	Diagnosis item	Reference page
P0003	Suction control valve open	
P0004	Suction control valve battery short	
P0016	Crank angle sensor/camshaft position sensor phase problem	
P0047	Variable geometry control solenoid valve circuit low input	
P0048	Variable geometry control solenoid valve circuit high input	
P0072	No. 1 intake air temperature sensor circuit low input	
P0073	No. 1 intake air temperature sensor circuit high input	
P0088	Common rail high pressure malfunction	
P0089	Suction control valve stuck	
P0093	Fuel leak problem	
P0102	Air flow sensor circuit low input	
P0103	Air flow sensor circuit high input	
P0106	Manifold absolute pressure sensor range/performance problem	
P0107	Manifold absolute pressure sensor circuit low input	
P0108	Manifold absolute pressure sensor circuit high input	
P0112	No. 2 intake air temperature sensor circuit low input	
P0113	No. 2 intake air temperature sensor circuit high input	
P0117	Engine coolant temperature sensor circuit low input	
P0118	Engine coolant temperature sensor circuit high input	
P0122	Throttle position sensor circuit low input	
P0123	Throttle position sensor circuit high input	
P0182	Fuel temperature sensor circuit low input	
P0183	Fuel temperature sensor circuit high input	
P0191	Rail pressure sensor range/performance problem	
P0192	Rail pressure sensor circuit low input	
P0193	Rail pressure sensor circuit high input	
P0201	No. 1 injector circuit malfunction	
P0202	No. 2 injector circuit malfunction	
P0203	No. 3 injector circuit malfunction	
P0204	No. 4 injector circuit malfunction	
P0219	Engine over speed condition	
P0299	Turbocharger under boost condition	
P0301	No. 1 cylinder injector malfunction (No injection)	
P0302	No. 2 cylinder injector malfunction (No injection)	
P0303	No. 3 cylinder injector malfunction (No injection)	
P <u>030</u> 4	No. 4 cylinder injector malfunction (No injection)	

P0101*1	Air flow sensor range/performance problem
---------	---

<Added>

P1626	Injection quantity compensation value not coding	
P2118	Throttle valve control DC motor current malfunction	
P2122	Accelerator pedal position sensor (main) circuit low input	
P2123	Accelerator pedal position sensor (main) circuit high input	
P2124	Accelerator pedal position sensor (main) circuit high input intermittent	
P2127	Accelerator pedal position sensor (sub) circuit low input	
P2128	Accelerator pedal position sensor (sub) circuit high input	
P2138	Accelerator pedal position sensor (main and sub) range/performance problem	
P2146	Injector common 1 (cylinder No. 1and No. 4) circuit open	
P2147	Injector common 1 (cylinder No. 1and No. 4) circuit earth short	
P2148	Injector common 1 (cylinder No. 1and No. 4) circuit battery short	
P2149	Injector common 2 (cylinder No. 2 and No. 3) circuit open	
P2150	Injector common 2 (cylinder No. 2 and No. 3) circuit earth short	
P2151	Injector common 2 (cylinder No. 2 and No. 3) circuit battery short	
P2228	Barometric pressure sensor circuit low input	
P2229	Barometric pressure sensor circuit high input	
P2413	EGR system performance	
P2426	EGR cooling valve control circuit (low)	
P2427	EGR cooling valve control circuit (high)	
P2454	Exhaust differential pressure sensor circuit low input	
P2455	Exhaust differential pressure sensor circuit high input	
P252F	Engine oil level malfunction	
U0001	Bus off	
U0121	ASC-ECU time-out	
U0131	EPS-ECU time-out	
U0141	ETACS-ECU time-out	

P2453 Exhaust differential pressure sensor range/performance problem

Code No. P0102: Air flow Sensor Circuit Low Input

OPERATION ()

- Power is supplied by the engine control relay (terminal No. 2) to the air flow sensor (terminal No. 3), and the air flow sensor (terminal No. 2) is earthed through the engine-ECU (terminal No. 155).
- The air flow sensor (terminal No. 1) outputs a sensor signal, which is input into the engine-ECU (terminal No. 140).

FUNCTION ()

- The air flow sensor outputs pulse signal that varies in accordance with the intake air volume.
- In response to the signal, the engine-ECU controls EGR control, etc.

TROUBLE JUDGMENT

Check Conditions

- Battery positive voltage is 8 16 V
- 2 seconds later after the ignition switch has been

in "ON" position or the engine has started up.

Judgment Criterion

 The air flow sensor output voltage is 0.50 V or less.

FAIL-SAFE AND BACKUP FUNCTION

- The control is performed using the previous value.
- The DPF regeneration is prohibited.
- The throttle valve is opened (Electrical discontinuity).
- The EGR control is stopped (fully closed).
- The AS&G control is prohibited.

PROBABLE CAUSES

- Failed air flow sensor
- Open/short circuit or harness damage in air flow sensor circuit or loose connector contact
- · Failed engine-ECU

DIAGNOSTIC PROCEDURE

STEP 1. M.U.T.-III data list

- Refer to Data List Reference Table.
 - a. Item 114: Air flow sensor

Q: Is the check result normal?

YES: Intermittent malfunction (Refer to GROUP 00 – How to Use Troubleshooting/Inspection Service Points – How to Cope with Intermittent Malfunctions).

NO: Go to Step 2.

STEP 2. Connector check: A-07 air flow sensor connector

Q: Is the check result normal?

YES: Go to Step 3.

NO: Repair or replace the connector.

STEP 3. Perform voltage measurement at A-07 air flow sensor connector.

- Disconnect connector, and measure at harness side.
- Ignition switch: ON
- Voltage between terminal No. 3 and earth.

OK: System voltage

Q: Is the check result normal?

YES: Go to Step 5. NO: Go to Step 4.

Code No. P0101: Air Flow Sensor Range/Performance Problem

OPERATION

- Power is supplied by the engine control relay (terminal No. 2) to the air flow sensor (terminal No. 3), and the air flow sensor (terminal No. 2) is earthed through the engine-ECU (terminal No. 155).
- The air flow sensor (terminal No. 1) outputs a sensor signal, which is input into the engine-ECU (terminal No. 140).

FUNCTION

- The air flow sensor outputs pulse signal that varies in accordance with the intake air volume.
- In response to the signal, the engine-ECU controls EGR control, etc.

TROUBLE JUDGEMENT

Check Conditions

- Battery positive voltage is 8 16 V
- 1 second before the throttle valve fully openedposition value after the ignition switch has been in

"LOCK" (OFF) position.

Judgement Criterion

• The air flow sensor output voltage is threshold value or less.

or

 The air flow sensor output voltage is threshold value or more.

FAIL-SAFE AND BACKUP FUNCTION

- The control is performed using the previous value.
- The DPF regeneration is prohibited.
- The throttle valve is opened (Electrical discontinuity).
- The EGR control is stopped (fully closed).

PROBABLE CAUSES

- · Failed air flow sensor
- Harness damage in air flow sensor circuit or loose connector contact
- Failed engine-ECU

DIAGNOSIS PROCEDURE

STEP 1. Connector check: A-07 air flow sensor connector

Q: Is the check result normal?

YES: Go to Step 2.

NO: Repair or replace the connector.

STEP 2. Connector check: A-37X engine control relay connector

Q: Is the check result normal?

YES: Go to Step 3.

NO: Repair or replace the connector.

STEP 3. Check harness between A-37X (terminal No. 2) engine control relay connector and A-07 (terminal No. 3) air flow sensor connector.

Check power supply line for damage.

Q: Is the check result normal?

YES: Go to Step 4.

NO: Repair the damaged harness wire.

STEP 4. Connector check: B-10 engine-ECU connector

Q: Is the check result normal?

YES: Go to Step 5.

NO: Repair or replace the connector.

<Added>

STEP 5. Check harness between A-07 (terminal No. 1) air flow sensor connector and B-10 (terminal No. 140) engine-ECU connector.

Check output line for damage.

Q: Is the check result normal?

YES: Go to Step 6.

NO: Repair the damaged harness wire.

STEP 6. Check harness between A-07 (terminal No. 2) air flow sensor connector and B-10 (terminal No. 155) engine-ECU connector.

· Check earthing line for damage.

Q: Is the check result normal?

YES: Go to Step 7.

NO: Repair the damaged harness wire.

STEP 7. M.U.T.-III data list

• Refer to Data List Reference Table.

a. Item 114: Air flow sensor

Q: Is the check result normal?

YES: Intermittent malfunction (Refer to GROUP 00 – How to Use Troubleshooting/Inspection Service Points – How to Cope with Intermittent Malfunctions).

NO: Go to Step 8.

STEP 8. Replace the air flow sensor.

 After replacing the air flow sensor, re-check the trouble symptoms.

Q: Is the check result normal?

YES: Check end.

NO: Replace the engine-ECU.

Code No. P1497: DPF System Malfunction

FUNCTION

 The engine-ECU monitors the input signals from sensors to check if the DPF regeneration is executed normally.

TROUBLE JUDGMENT

Check Condition

On DPF regeneration

Judgement Criterion

 The DPF regeneration status continues for the predetermined time or more.

FAIL-SAFE AND BACKUP FUNCTION

The throttle valve is opened. (Electrical

discontinuity)

- The EGR control is stopped (fully closed).
- The DPF regeneration is prohibited.
- The AS&G control is prohibited.

PROBABLE CAUSES

- Failed No. 2 exhaust gas temperature sensor (catalyst temperature)
- Failed No. 3 exhaust gas temperature sensor (DPF temperature)
- Failed exhaust differential pressure sensor
- Catalytic converter inactive
- The engine oil-containing ash is loaded to the DPF inside.

DIAGNOSIS PROCEDURE

STEP 1. M.U.T.-III data list.

- Refer to Data List Reference Table.
 - a. Item 118: No. 2 exhaust gas temperature sensor (catalyst temperature)
 - b. Item 119: No. 3 exhaust gas temperature sensor (DPF temperature)
 - c. Item 120: Exhaust differential pressure sensor


Q: Are the check results normal?

YES: Go to Step 2.

NO: Perform the diagnosis code classified check procedure for the sensor that has shown an abnormal data value (Refer to Inspection Chart for Diagnosis Code).

STEP 2. Forcible DPF regeneration execution

- Initialise the DPF-related parts, and then delete the diagnosis code (Refer to GROUP 00 – Precautions before Service – Initialisation Procedure for Learning Value in Common Rail Engine <4N1>).
 - a. Item 42: DPF system malfunction service
- Carry out the forcible DPF regeneration (Refer to GROUP 17 – Diesel Particulate Filter (DPF) System – Forcible DPF Regeneration).



<Added>

Code No. P1498: Excessive Pm Accumulated In DPF

FUNCTION

- The engine-ECU monitors the input signals from sensors to estimate the PM amount loaded to the DPF inside.
- If the PM is loaded more than the specified amount, the DPF regeneration is automatically executed under certain conditions in order to eliminate the PM.
- If the PM is excessively loaded, the engine-ECU does not execute the automatic DPF regeneration. It makes the engine warning lamp illuminate and the DPF lamp blink.

TROUBLE JUDGMENT

Check Condition

• Ignition switch is in "ON" position.

The small injection quantity improperly learned.

Judgement Criterion

 Driving distance exceeds the specified value after the last DPF regeneration.

FAIL-SAFE AND BACKUP FUNCTION

- The throttle valve is opened (Electrical discontinuity).
- The EGR control is stopped (fully closed).
- The DPF regeneration is prohibited.
- The fuel injection amount is restricted (Output restriction).
- The open angle of the accelerator pedal is restricted.
- The AS&G control is prohibited.

PROBABLE CAUSE

The PM is abnormally loaded to the DPF inside.

<Added>

DIAGNOSIS PROCEDURE

STEP 1. Forcible DPF regeneration execution

 Carry out the forcible DPF regeneration (Refer to GROUP 17 – Diesel Particulate Filter (DPF) System – Forcible DPF Regeneration).

Q: Is the diagnosis code set?

YES: Inspection chart for diagnosis code.

NO: Check end.

<Added>

Carry out the small injection quantity learning procedure (Refer to GROUP 00

 Precautions before Service - Small Injection Quantity Learning Procedure

 4N1>).

Code No. P1499: Abnormally high DPF temperature

FUNCTION

- The DPF may be have melting damage if the temperature exceeds the specified value.
- The engine-ECU monitors the signals from No. 3 exhaust gas temperature sensor (DPF temperature) to check if the DPF is under the specified temperature.

TROUBLE JUDGMENT

Check Condition

On DPF regeneration

Judgement Criterion

• The No. 3 exhaust gas temperature sensor (DPF temperature) detects the abnormally high temperature.

• The estimated DPF centre temperature exceeds the specified value.

FAIL-SAFE AND BACKUP FUNCTION

- The throttle valve is opened. (Electrical discontinuity)
- The EGR control is stopped (fully closed).
- The DPF regeneration is prohibited.
- The fuel injection amount is restricted. (Output restriction)
- The open angle of the accelerator pedal is restricted.
- The AS&G control is prohibited.

PROBABLE CAUSE

Damage by the DPF with high temperature

or

DIAGNOSIS PROCEDURE

STEP 1. M.U.T.-III data list.

- Refer to Data List Reference Table.
 - a. Item 119: No. 3 exhaust gas temperature sensor (DPF temperature)

Q: Is the check result normal?

YES: Replace the DPF. When the DPF is replaced, initialise the learning value (Refer to GROUP 00 - Precautions Before Service – Initialisation Procedure For Learning Value in Common Rail Engine <4N1>).

Incorrect> NO: Perform the diagnosis code classified check procedure for the sensor that has shown an abnormal data value (Refer to Inspection Chart for Diagnosis Code).

<Correct> NO: Go to Step 2.

STEP 2. Small injection quantity learning.

 Carry out the small injection quantity learning procedure (Refer to GROUP 00 – Precautions Before Service – Small Injection Quantity Learning Procedure).

Q: Is the diagnosis code set?

YES: Inspection chart for diagnosis code.

NO: Check end.

Code No. P2454: Exhaust Differential Pressure Sensor Circuit Low Input

OPERATION

- A power voltage of 5 V is applied to the exhaust differential pressure sensor power terminal (terminal No. 1) from the engine-ECU (terminal No. 94) and earthed to the engine-ECU (terminal No. 80) from exhaust differential pressure sensor (terminal No. 3).
- The sensor signal is inputted to the engine-ECU (terminal No. 56) from the exhaust differential pressure sensor output terminal (terminal No. 2).

FUNCTION

- The exhaust differential pressure sensor outputs the voltage to the engine-ECU in accordance with the difference in the voltage between the DPF upstream area and the DPF downstream area.
- The engine-ECU anticipates the amount of PM accumulated in the DPF through this output voltage.

TROUBLE JUDGMENT

Check Conditions

- Battery positive voltage is 8 16 V
- 2 seconds later after the ignition switch has been in "ON" position or the engine has started up

Judgment Criterion

 The exhaust differential pressure sensor output voltage is 0.49 V or less.

FAIL-SAFE AND BACKUP FUNCTION

- The throttle valve is opened (Electrical discontinuity).
- The EGR control is stopped (fully closed).
- The DPF regeneration is prohibited.
- The AS&G control is prohibited.

PROBABLE CAUSES

- Failed exhaust differential pressure sensor
- Open/short circuit or harness damage in exhaust differential pressure sensor circuit or loose connector contact
- Failed engine-ECU

DIAGNOSTIC PROCEDURE

STEP 1. M.U.T.-III data list

- Refer to Data List Reference Table.
 - a. Item 120: Exhaust differential pressure sensor

Q: Is the check result normal?

YES: Intermittent malfunction (Refer to GROUP 00 – How to Use Troubleshooting/Inspection Service Points – How to Cope with Intermittent Malfunctions).

NO: Go to Step 2.

STEP 2. Connector check: A-08 exhaust differential pressure sensor connector

Q: Is the check result normal?

YES: Go to Step 3.

NO: Repair or replace the connector.

Code No. P2453: Exhaust Differential Pressure Sensor Range/Performance Problem

OPERATION

- A power voltage of 5 V is applied to the exhaust differential pressure sensor power terminal (terminal No. 3) from the engine-ECU (terminal No. 94) and earthed to the engine-ECU (terminal No. 80) from the exhaust differential pressure sensor (terminal No. 2).
- The sensor signal is inputted to the engine-ECU (terminal No. 56) from the exhaust differential pressure sensor output terminal (terminal No. 1).

FUNCTION

- The exhaust differential pressure sensor outputs the voltage to the engine-ECU in accordance with the difference in the voltage between the DPF upstream area and the DPF downstream area.
- The engine-ECU anticipates the amount of PM accumulated in the DPF through this output voltage.

TROUBLE JUDGEMENT

Check Conditions

- Battery positive voltage is 8 16 V
- · Vehicle in steady running.

Judgement Criterion

 The exhaust differential pressure sensor output voltage is less than threshold value based on exhaust gas flow for predetermined time.

Check Conditions

- Battery positive voltage is 8 16 V
- Predetermined time has passed after the engine is stopped.
- The malfunction of P2454 or P2455 is not detected.

Judgement Criterion

• The exhaust differential pressure sensor output is more than 2.75 kPa for predetermined time.

or

• The exhaust differential pressure sensor output is less than –2.75 kPa for predetermined time.

FAIL-SAFE AND BACKUP FUNCTION

- The DPF regeneration is prohibited.
- The AS&G control is prohibited.
- The EGR control is stopped (fully closed).
- The throttle valve is opened (Electrical discontinuity).

PROBABLE CAUSES

- The exhaust pressure hose or the exhaust pressure pipe is disconnected, damaged, misconnected or clogged.
- Failed exhaust differential pressure sensor
- Harness damage in exhaust differential pressure sensor circuit or loose connector contact
- Failed engine-ECU

DIAGNOSIS PROCEDURE

STEP 1. Check exhaust pressure hose and exhaust pressure pipe.

 Check the lines between the exhaust differential pressure sensor and the exhaust centre pipe (DPF) (i.e, exhaust pressure hose and exhaust pressure pipe) for disconnection, damage, wrong connection or clogging.

Q: Are the check results normal?

YES: Go to Step 2.

NO: Repair or replace the exhaust pressure hose or exhaust pressure pipe.

<Added>

STEP 2. M.U.T.-III data list

- Refer to Data List Reference Table.
 - a. Item 120: Exhaust differential pressure sensor

Q: Is the check result normal?

YES: Intermittent malfunction (Refer to GROUP 00 – How to Use Troubleshooting/Inspection Service Points – How to Cope with Intermittent Malfunctions).

NO: Go to Step 3.

STEP 3. Connector check: B-118 exhaust differential pressure sensor connector

Q: Is the check result normal?

YES: Go to Step 4.

NO: Repair or replace the connector.

STEP 4. Connector check: B-09 engine-ECU connector

Q: Is the check result normal?

YES: Go to Step 5.

NO: Repair or replace the connector.

STEP 5. Check harness between B-118 (terminal No. 3) exhaust differential pressure sensor connector and B-09 (terminal No. 94) engine-ECU connector.

• Check power supply line for damage.

Q: Is the check result normal?

YES: Go to Step 6.

NO: Repair the damaged harness wire.

STEP 6. Check harness between B-118 (terminal No. 1) exhaust differential pressure sensor connector and B-09 (terminal No. 56) engine-ECU connector.

Check output line for damage.

Q: Is the check result normal?

YES: Go to Step 7.

NO: Repair the damaged harness wire.

STEP 7. Check harness between B-118 (terminal No. 2) exhaust differential pressure sensor connector and B-09 (terminal No. 80) engine-ECU connector.

· Check earthing line for damage.

Q: Is the check result normal?

YES: Go to Step 8.

NO: Repair the damaged harness wire.

STEP 8. Replace the exhaust differential pressure sensor

 After replacing the exhaust differential pressure sensor, carry out the forcible DPF regeneration. (Refer to GROUP 17 – Emission Control <DIESEL> – Diesel Particulate Filter (DPF) System – Forcible DPF Regeneration). After carrying out the forcible DPF regeneration, re-check the trouble symptoms.

Q:Is the check result normal?

YES: Check end.

NO: Replace the engine-ECU.

Code No. P252F: Engine Oil Level Malfunction

FUNCTION

- The engine oil level may ascend if the fuel runs into the engine oil on the DPF regeneration.
- The engine-ECU monitors the engine driving conditions to estimate the ascend of engine oil level.

TROUBLE JUDGMENT

Check Condition

• Ignition switch is in "ON" position.

Judgement Criterion

• The estimated increased amount of the engine oil exceeds the 1,800 cc.

<Incorrect>

<Correct> 2,000

FAIL-SAFE AND BACKUP FUNCTION

• The DPF regeneration is prohibited.

PROBABLE CAUSE

• The engine oil is increased.

DIAGNOSIS PROCEDURE

<Incorrect> STEP 1. Replace the engine oil.

 Replace the engine oil, When the engine oil is replaced, initialise the learning value (Refer to GROUP 00 -Precautions before Service – Initialisation Procedure for Learning Value in Common Pail Engine <4N1>). After initialising the learning value, reconfirm diagnosis code.

Q: Is the diagnosis code set?

YES: Replace the engine-ECU.

NO: Check end.

<Correct>

STEP 1. Replace the engine oil.

- 1. Replace the engine oil, When the engine oil is replaced, initialise the learning value (Refer to GROUP 00 -Precautions before Service – Initialisation Procedure for Learning Value in Common Rail Engine <4N1>). After initialising the learning value, reconfirm diagnosis code.
- 2. Carry out the small injection quantity learning procedure (Refer to GROUP 00 - Precautions before Service - Small Injection Quantity Learning Procedure <4N1>).
- 3. Reconfirmation of diagnosis code.
- Q: Is the diagnosis code set?

YES: Replace the engine-ECU.

NO: Check end.

INSPECTION CHART FOR TROUBLE SYMPTOMS

Items	Trouble symptom		Inspection procedure No.
Communication with M.U.TIII	Communication with engine-ECU is not possible		1
Engine warning lamp	The engine warning lamp does not is turned to the "ON" position	illuminate right after the ignition switch	2
	The engine warning lamp remains	illuminating and never goes out	3
Starting	Starter impossible (Starter not operative)	The starter not operative	4
	Starting impossible (Starter operative but no initial combustion)	The starter is operative and cranks the engine, but none of initial combustion is in the cylinders and the engine is not started.	5
	Improper starting (Long time to start)	It is long cranking to start the engine.	6
Improper idling	The proper idling speed is not satis	fied.	7
Engine stalls	The engine stalls when decelerating	The engine stalls at the deceleration.	8
Driving	Poor acceleration	The engine cannot obtain the acceleration corresponding to the degree of throttle opening although the engine is smooth at the constant speed.	9
	A large amount of fuel consumption	Compared with before, the fuel consumption is dramatically increased.	10
Knocking, Abnormal noise	Knocking	Sharp sound like a hammer striking on the cylinder walls during the driving can be heard and wrongly affects the driving.	11
	Abnormal noise	Abnormal noise during the engine operation. (It is presumed that this is caused by malfunction over the wide range.)	
Exhaust gas	White smoke	Exhaust gases are extraordinarily white.	12
	Black smoke, state of exhaust gas purification deteriorated	The exhaust gases are extraordinarily black. The state of the exhaust gas purification is deteriorated.	13
Charging performance	Battery rundown	The battery is soon rundown or the charging ability of battery is small.	14
Cooling performance	Overheating	The temperature of engine cooling water is extremely high.	15

<added></added>	The DPF regeneration interval is	The DPF lamp illuminates more	22
		frequently before.	

PROBLEM SYMPTOMS TABLE

Inspection procedure No.	Trouble symptom	Reference page
1	Communication with engine-ECU is not possible	
2	The engine warning lamp does not illuminate right after the ignition switch is turned to the "ON" position	
3	The engine warning lamp remains illuminating and never goes out	
4	Starter impossible (Starter not operative)	<vehicles without<br="">AS&G system>, <vehicles as&g<br="" with="">system></vehicles></vehicles>
5	Starting impossible (Starter operative but no initial combustion)	
6	Improper starting (Long time to start)	
7	Improper idling	
8	The engine stalls when decelerating	
9	Poor acceleration	
10	A large amount of fuel consumption	
11	Knocking, Abnormal noise	
12	White smoke	
13	Black smoke, state of exhaust gas purification deteriorated	
14	Battery rundown	
15	Overheating	
16	Engine-ECU power supply system	
17	Engine-ECU battery back-up system	
18	A/C compressor relay system	
19	Fuel pump system	
20	Engine oil pressure switch system	
21	Water level switch system	

22	The DPF regeneration interval is short	
	<u> </u>	

<Added>

DATA LIST REFERENCE TABLE

Item No.	Check item			Value to be determined as normal	Code No. or inspection procedure No.	Reference page
1	Battery voltage	Ignition switch: ON		System voltage	Procedure No. 14	
2	Engine revolution	Engine: Cranking Tachometer: Connected	Compare engine speed on tachometer with the value displayed on M.U.TIII	Matched	Code No. P0335	
		Engine: Idle operation Transmission:	When the engine coolant temperature: –20 °C	870 – 930 r/min		
		Neutral • A/C switch: OFF	When the engine	770 – 830 r/min	†	

Inspection Procedure 22: The DPF regeneration interval is short

PROBABLE CAUSES

- Injector leaking or clogged
- Failed injector
- · Small injection quantity incorrectly learning
- Failed air flow sensor connector
- Failed exhaust differential pressure sensor
- Failed exhaust gas temperature sensor

DIAGNOSIS PROCEDURE

STEP 1. M.U.T.-III diagnosis code.

Q: Is the diagnosis code set?

YES: Inspection chart for diagnosis code.

NO: Go to Step 2.

STEP 2. M.U.T.-III data list.

- Refer to Data List Reference Table.
 - a. Item 117: No. 1 exhaust gas temperature sensor
 - b. Item 118: No. 2 exhaust gas temperature sensor (catalyst temperature)
 - c. Item 119: No. 3 exhaust gas temperature sensor (DPF temperature)
 - d. Item 120: Exhaust differential pressure sensor

Q: Are the check results normal?

YES: Go to Step 3.

NO: Replace a defective sensor(s).

STEP 3. M.U.T.-III data list

- Refer to Data List Reference Table.
 - a. Item 114: Air flow sensor

Q: Is the check result normal?

YES: Go to Step 4.

NO: Replace the air flow sensor.

STEP 4. Check injector identification code.

 Check injector identification code (Refer to GROUP 00 – Precautions Before Service – Injector Identification code Registration Procedure).

Q: Is the check result normal?

YES: Go to Step 5.

NO: Register the injector ID.

STEP 5. M.U.T.-III actuator test.

• Refer to Actuator Test Reference Table.

a. Item 15: Injector No. 1

b. Item 16: Injector No. 2

c. Item 17: Injector No. 3

d. Item 18: Injector No. 4

Q: Is the check result normal?

YES: Go to Step 6.

NO: Replace the injector at the failed cylinder. After replacing the Injector, register the injector identification code and learn fuel injection (Refer to GROUP 00 – Precautions Before Service – What The Common Rail Engine Learns).

STEP 6. Check injector itself.

Check injector itself.

Q: Is the check result normal?

YES: Execute the small injection quantity learning (Refer to GROUP 00 – Precautions Before Service – Small Injection Quantity Learning Procedure).

NO: Replace the injector at the failed cylinder. After replacing the Injector, register the injector identification code and learn fuel injection (Refer to GROUP 00 – Precautions Before Service – What The Common Rail Engine Learns).

INSPECTION CHART FOR DIAGNOSIS CODE

Diagnosis code No.	Diagnosis item	Reference page
P0003	Suction control valve open	
P0004	Suction control valve battery short	
P0016	Crank angle sensor/camshaft position sensor phase problem	
P0047	Variable geometry control solenoid valve circuit low input	
P0048	Variable geometry control solenoid valve circuit high input	
P0072	No. 1 intake air temperature sensor circuit low input	
P0073	No. 1 intake air temperature sensor circuit high input	
P0088	Common rail high pressure malfunction	
P0089	Suction control valve stuck	
P0093	Fuel leak problem	
P0102	Air flow sensor circuit low input	
P0103	Air flow sensor circuit high input	
P0106	Manifold absolute pressure sensor range/performance problem	
P0107	Manifold absolute pressure sensor circuit low input	
P0108	Manifold absolute pressure sensor circuit high input	
P0112	No. 2 intake air temperature sensor circuit low input	
P0113	No. 2 intake air temperature sensor circuit high input	
P0117	Engine coolant temperature sensor circuit low input	
P0118	Engine coolant temperature sensor circuit high input	
P0122	Throttle position sensor circuit low input	
P0123	Throttle position sensor circuit high input	
D0400	Final tamparatura capaar circuit lauring	

Diagnosis code No.	Diagnosis item	Reference page
P1274	Supply pump protection	
P1275	Supply pump exchange	
P1298	Variable geometry turbocharger control system malfunction (high pressure)	
P1299	Variable geometry turbocharger control system malfunction (low pressure)	
P1427	No. 3 exhaust gas temperature sensor (DPF temperature) circuit low input	
P1428	No. 3 exhaust gas temperature sensor (DPF temperature) circuit high input	
P1497	DPF system malfunction	
P1498	Excessive PM accumulated in DPF	
P1499	Abnormally high DPF temperature	
P1608	Battery current sensor system	
P1625	Injection quantity compensation value error	
P1626	Injection quantity compensation value not coding	
P2118	Throttle valve control DC motor current malfunction	
P2122	Accelerator pedal position sensor (main) circuit low input	
P2123	Accelerator pedal position sensor (main) circuit high input	
P2124	Accelerator pedal position sensor (main) circuit high input intermittent	
P2127	Accelerator pedal position sensor (sub) circuit low input	
P2128	Accelerator pedal position sensor (sub) circuit high input	
P2138	Accelerator pedal position sensor (main and sub) range/performance problem	
P2146	Injector common 1 (cylinder No. 1and No. 4) circuit open	
P2147	Injector common 1 (cylinder No. 1and No. 4) circuit earth short	
P2148	Injector common 1 (cylinder No. 1and No. 4) circuit battery short	
P2149	Injector common 2 (cylinder No. 2 and No. 3) circuit open	
P2150	Injector common 2 (cylinder No. 2 and No. 3) circuit earth short	
P2151	Injector common 2 (cylinder No. 2 and No. 3) circuit battery short	
P2228	Barometric pressure sensor circuit low input	
P2229	Barometric pressure sensor circuit high input	
P2413	EGR system performance	
P2426	EGR cooling valve control circuit (low)	
P2427	EGR cooling valve control circuit (high)	
P2454	Exhaust differential pressure sensor circuit low input	
P2455	Exhaust differential pressure sensor circuit high input	
P2463	No chance of forcible regeneration of DPF	
P252F	Engine oil level malfunction	<u> </u>

P2453 Exhaust differential pressure sensor range/performance problem

Code No. P1498: Excessive PM Accumulated In DPF

FUNCTION

- The engine-ECU monitors the input signals from sensors to estimate the PM amount loaded to the DPF inside.
- If the PM is loaded more than the specified amount, the DPF regeneration is automatically executed under certain conditions in order to eliminate the PM.
- If the PM is excessively loaded, the engine-ECU does not execute the automatic DPF regeneration. It makes the engine warning lamp illuminate and allow the DPF warning mark to be shown.

<Added>

Judgement Criterion

The estimated amount of accumulated PM exceeds more than specified amount.

FAIL-SAFE AND BACKUP FUNCTION

- The EGR control is stopped (fully closed).
- The cruise control is prohibited.
- The fuel injection amount is restricted (Output restriction).
- The open angle of the accelerator pedal is restricted.
- The AS&G control is prohibited.

TROUBLE JUDGMENT

Check Condition

• Ignition switch is in "ON" position.

PROBABLE CAUSE

• The PM is abnormally loaded to the DPF inside.

DIAGNOSIS PROCEDURE

The small injection quantity improperly learned.

STEP 1. M.U.T.-III diagnosis code.

 Check whether the diagnosis code P2463 is set together with P1498 or not.

Q: Is the diagnosis code P2463 set?

YES: Troubleshoot the diagnosis code P2463.

NO: Go to Step 2.

STEP 2. Forcible DPF regeneration execution

 Carry out the forcible DPF regeneration (Refer to GROUP 17 – Diesel Particulate Filter (DPF) System – Forcible DPF Regeneration).

Q: Is the diagnosis code set?

YES: Inspection chart for diagnosis code.

NO: Check end.

<Added>

Carry out the small injection quantity learning procedure (Refer to GROUP 00

 Precautions before Service - Small Injection Quantity Learning Procedure
 4N1>).

Code No. P252F: Engine Oil Level Malfunction

FUNCTION

- The engine oil level may ascend if the fuel runs into the engine oil on the DPF regeneration.
- The engine-ECU monitors the engine driving conditions to estimate the ascend of engine oil level.

TROUBLE JUDGEMENT

Check Condition

• Ignition switch is in "ON" position.

Judgement Criterion

 The estimated increased amount of the engine oil exceeds the 1,800 cc.

<Incorrect>

2,000

FAIL-SAFE AND BACKUP FUNCTION < Correct>

• The DPF regeneration is prohibited.

PROBABLE CAUSE

• The engine oil is increased.

DIAGNOSIS PROCEDURE

STEP 1. Replace the engine oil.


- Replace the engine oil, When the engine oil is replaced, initialise the learning value (Refer to GROUP 00 Precautions before Service Initialisation Procedure for Learning Value in Common Rail Engine <4N1>). After initialising the learning value, reconfirm diagnosis code.
- 2. Carry out the small injection quantity learning procedure (Refer to GROUP 00 Precautions before Service Small Injection Quantity Learning Procedure <4N1>).
- 3. Reconfirmation of diagnosis code.

Q: Is the diagnosis code stored?

YES: Replace the engine-ECU.

NO: Check end.

DIAGNOSIS FUNCTION



ENGINE WARNING LAMP (CHECK ENGINE LAMP)

When the abnormal condition occurs with respect to the items of electronically controlled fuel injection system shown in the table, the engine warning lamp is illuminated. When the lamp remains illuminated after the engine start, or when the lamp is illuminated while the engine is running, check the diagnosis code output. There are two methods for checking the indicator lamp burn out: When the ignition switch is in ON position, the indicator lamp is illuminated, and then extinguished few seconds later. When the ignition switch is in ON position and the engine starts, the indicator lamp is extinguished.

ENGINE WARNING LAMP INSPECTION ITEMS

Code No.	Diagnosis item	
P0003 ^{*1}	Suction control valve open	
P0004 ^{*1}	Suction control valve battery short	
P0016 ^{*1}	Crank angle sensor/camshaft position sensor phase problem	
P0047*1	Variable geometry control solenoid valve circuit low input	
P0048 ^{*1}	Variable geometry control solenoid valve circuit high input	
P0072	No. 1 intake air temperature sensor circuit low input	
P0073	No. 1 intake air temperature sensor circuit high input	
P0088*1	Common rail high pressure malfunction	
P0089 ^{*1}	Suction control valve stuck	
P0093 ^{*1}	Fuel leak problem	
P0102	Air flow sensor circuit low input	
P0103	Air flow sensor circuit high input	
P0106 ^{*1}	Manifold absolute pressure sensor range/performance problem	
P0107 ^{*1}	Manifold absolute pressure sensor circuit low input	
P0108 ^{*1}	Manifold absolute pressure sensor circuit high input	
P0112	No. 2 intake air temperature sensor circuit low input	
P0113	No. 2 intake air temperature sensor circuit high input	
P0117	Engine coolant temperature sensor circuit low input	
P0118	Engine coolant temperature sensor circuit high input	
P0122	Throttle position sensor circuit low input	
P0123	Throttle position sensor circuit high input	
P0182	Fuel temperature sensor circuit low input	

	- <u></u>
P2228	Barometric pressure sensor circuit low input
P2229	Barometric pressure sensor circuit high input
P2413	EGR system performance
P2427	EGR cooling valve control circuit (High)
P2454*	Exhaust differential pressure sensor circuit low input
P2455*	Exhaust differential pressure sensor circuit high input

NOTE:

• After the engine-ECU has detected a malfunction, the engine warning lamp illuminates when the engine is next turned on and the same malfunction is re-detected. However, for items marked with a "*1" in the

_P2453*1	Exhaust differential pressure sensor range/performance problem
----------	--

<Added>

<u> </u>	P0102	Air flow sensor circuit low input	 I ne ruei injection amount is restricted. (Output restriction) The open angle of the accelerator pedal is restricted. The throttle valve is closed. (Fixed opening degree) The EGR control is stopped (fully closed). The DPF regeneration is prohibited. The AS&G control is prohibited. The control is performed using the previous value.
			 The DPF regeneration is prohibited. The throttle valve is opened. (Electrical discontinuity) The EGR control is stopped (fully closed). The AS&G control is prohibited.
	P0103	Air flow sensor circuit high input	 The control is performed using the previous value. The DPF regeneration is prohibited. The throttle valve is opened. (Electrical discontinuity) The EGR control is stopped (fully closed). The AS&G control is prohibited.
	P0106	Manifold absolute pressure sensor range/performance problem	 The pressure in the inlet manifold is controlled to be 100 kPa. The EGR control is stopped (fully closed). The fuel injection amount is restricted. (Output restriction) The open angle of the accelerator pedal is restricted. The DPF regeneration is prohibited. The throttle valve is opened. (Electrical discontinuity) The AS&G control is prohibited.
	P0107	Manifold absolute pressure sensor circuit low input	 The pressure in the inlet manifold is controlled to be 100 kPa. The EGR control is stopped (fully closed). The fuel injection amount is restricted. (Output restriction) The turbocharger control is prohibited. The open angle of the accelerator pedal is restricted. The DPF regeneration is prohibited. The throttle valve is opened. (Electrical discontinuity) The AS&G control is prohibited.

performance problem • The DPF regeneration is prohibited.	P0101	Air flow sensor range/ performance problem	• The throttle valve is opened. (Electrical discontinuity)
--	-------	---	--


	م_	
P2229	Barometric pressure sensor circuit high input	 The EGR control is stopped (fully closed). The throttle valve is opened. (Electrical discontinuity) The DPF regeneration is prohibited. The turbocharger control is prohibited. The AS&G control is prohibited.
P2413	EGR system performance	 The EGR control is stopped (fully closed). The DPF regeneration is prohibited. The throttle valve is opened. (Electrical discontinuity) The AS&G control is prohibited.
P2426	EGR cooling valve control circuit (Low)	The EGR control is stopped (fully closed).
P2427	EGR cooling valve control circuit (High)	The EGR control is stopped (fully closed).
P2454	Exhaust differential pressure sensor circuit low input	 The throttle valve is opened. (Electrical discontinuity) The EGR control is stopped (fully closed). The DPF regeneration is prohibited. The AS&G control is prohibited.
P2455	Exhaust differential pressure sensor circuit high input	 The throttle valve is opened. (Electrical discontinuity) The EGR control is stopped (fully closed). The DPF regeneration is prohibited. The AS&G control is prohibited.
P252F	Engine oil level malfunction	The DPF regeneration is prohibited.
U0001	Bus Off	None
U0121	ASC-ECU time-out	None
U0141	ETACS-ECU time-out	None
U1004	AS&G-ECU time-out	None

<Added>

P2453	Exhaust differential pressure sensor range/performance	 The DPF regeneration is prohibited. The AS&G control is prohibited. The EGR control is stopped (fully closed). The throttle valve is opened. (Electrical discontinuity)
-------	--	--

Code No. P0102: Air flow Sensor Circuit Low Input

Air flow sensor circuit




Wire colour code

B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Grey R: Red P: Pink V: Violet PU: Purple SI: Silver

AK802733 AC

Code No. P0101: Air Flow Sensor Performance


Air flow sensor circuit





Wire colour code

B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Grey R: Red P: Pink V: Violet PU: Purple SI: Silver

AK802733 AC







OPERATION

- Power is supplied by the engine control relay (terminal No. 2) to the air flow sensor (terminal No. 3), and the air flow sensor (terminal No. 2) is earthed through the engine-ECU (terminal No. 155).
- The air flow sensor (terminal No. 1) outputs a sensor signal, which is input into the engine-ECU (terminal No. 140).

FUNCTION

- The air flow sensor outputs pulse signal that varies in accordance with the intake air volume.
- In response to the signal, the engine-ECU controls EGR control, etc.

TROUBLE JUDGEMENT

Check Conditions

- Battery positive voltage is 8 16 V
- 1 second before the throttle valve fully openedposition value after the ignition switch has been in

"LOCK" (OFF) position.

Judgement Criterion

 The air flow sensor output voltage is threshold value or less.

or

 The air flow sensor output voltage is threshold value or more.

FAIL-SAFE AND BACKUP FUNCTION

- The control is performed using the previous value
- The DPF regeneration is prohibited.
- The throttle valve is opened (Electrical discontinuity).
- The EGR control is stopped (fully closed).

PROBABLE CAUSES

- · Failed air flow sensor
- Harness damage in air flow sensor circuit or loose connector contact
- Failed engine-ECU

DIAGNOSIS PROCEDURE

STEP 1. Connector check: A-08 air flow sensor connector

Q: Is the check result normal?

YES: Go to Step 2.

NO: Repair or replace the connector.

<Added>

STEP 2. Connector check: A-33X engine control relay connector

Q: Is the check result normal?

YES: Go to Step 3.

NO: Repair or replace the connector.

STEP 3. Check harness between A-33X (terminal No. 2) engine control relay connector and A-08 (terminal No. 3) air flow sensor connector.

• Check power supply line for damage.

Q: Is the check result normal?

YES: Go to Step 4.

NO: Repair the damaged harness wire.

STEP 4. Connector check: B-50 engine-ECU connector

Q: Is the check result normal?

YES: Go to Step 5.

NO: Repair or replace the connector.

STEP 5. Check harness between A-08 (terminal No. 1) air flow sensor connector and B-50 (terminal No. 140) engine-ECU connector.

· Check output line for damage.

Q: Is the check result normal?

YES: Go to Step 6

NO: Repair the damaged harness wire.

STEP 6. Check harness between A-08 (terminal No. 2) air flow sensor connector and B-50 (terminal No. 155) engine-ECU connector.

· Check earthing line for damage.

Q: Is the check result normal?

YES: Go to Step 7.

NO: Repair the damaged harness wire.

STEP 7. M.U.T.-III data list

• Refer to Data List Reference Table.

a. Item 114: Air flow sensor

Q: Is the check result normal?

YES: Intermittent malfunction (Refer to GROUP 00 – How to Use Troubleshooting/Inspection Service Points – How to Cope with Intermittent Malfunctions).

NO: Go to Step 8.

STEP 8. Replace the air flow sensor.

 After replacing the air flow sensor, re-check the trouble symptoms.

Q: Is the check result normal?

YES: Check end.

NO: Replace the engine-ECU.

Code No. P1497: DPF System Malfunction

FUNCTION

 The engine-ECU monitors the input signals from sensors to check if the DPF regeneration is executed normally.

TROUBLE JUDGMENT

Check Condition

On DPF regeneration

Judgement Criterion

 The DPF regeneration status continues for the predetermined time or more.

FAIL-SAFE AND BACKUP FUNCTION

The throttle valve is opened. (Electrical

discontinuity)

- The EGR control is stopped (fully closed).
- The DPF regeneration is prohibited.
- The AS&G control is prohibited.

PROBABLE CAUSES

- Failed No. 2 exhaust gas temperature sensor (catalyst temperature)
- Failed No. 3 exhaust gas temperature sensor (DPF temperature)
- Failed exhaust differential pressure sensor
- Catalytic converter inactive
- The engine oil-containing ash is loaded to the DPF inside.

DIAGNOSIS PROCEDURE

STEP 1. M.U.T.-III data list.

- Refer to Data List Reference Table.
 - a. Item 118: No. 2 exhaust gas temperature sensor (catalyst temperature)
 - b. Item 119: No. 3 exhaust gas temperature sensor (DPF temperature)
 - c. Item 120: Exhaust differential pressure sensor

Q: Are the check results normal?

YES: Go to Step 2.

NO: Perform the diagnosis code classified check procedure for the sensor that has shown an abnormal data value (Refer to Inspection Chart for Diagnosis Code).

STEP 2. Forcible DPF regeneration execution

- Initialise the DPF-related parts, and then delete the diagnosis code (Refer to GROUP 00 – Precautions before Service – Initialisation Procedure for Learning Value in Common Rail Engine <4N1>).
 - a. Item 42: DPF system malfunction service
- Carry out the forcible DPF regeneration (Refer to GROUP 17 – Diesel Particulate Filter (DPF) System <4N1> – Regeneration).

 Carry out the small injection quantity learning procedure (Refer to GROUP 00 – Precautions before Service – Small Injection Quantity Learning Procedure <4N1>).

Code No. P1498: Excessive PM Accumulated In DPF

FUNCTION

- The engine-ECU monitors the input signals from sensors to estimate the PM amount loaded to the DPF inside.
- If the PM is loaded more than the specified amount, the DPF regeneration is automatically executed under certain conditions in order to eliminate the PM.
- If the PM is excessively loaded, the engine-ECU does not execute the automatic DPF regeneration. It makes the engine warning lamp illuminate and allow the DPF warning mark to be shown.

TROUBLE JUDGMENT

Check Condition

• Ignition switch is in "ON" position.

 The small injection quantity improperly learned.

<Added>

Judgement Criterion

 Driving distance exceeds the specified value after the last DPF regeneration.

FAIL-SAFE AND BACKUP FUNCTION

- The throttle valve is opened (Electrical discontinuity).
- The EGR control is stopped (fully closed).
- The DPF regeneration is prohibited.
- The fuel injection amount is restricted (Output restriction).
- The open angle of the accelerator pedal is restricted.
- The AS&G control is prohibited.

PROBABLE CAUSE

The PM is abnormally loaded to the DPF inside.

DIAGNOSIS PROCEDURE

STEP 1. Forcible DPF regeneration execution

 Carry out the forcible DPF regeneration (Refer to GROUP 17 – Diesel Particulate Filter (DPF) System <4N1> – Forcible DPF Regeneration).

Q: Is the diagnosis code set?

YES: Inspection chart for diagnosis code.

NO: Check end.

- Carry out the small injection quantity learning procedure (Refer to GROUP 00)
 - Precautions before Service Small Injection Quantity Learning Procedure
 4N1>).

INSPECTION CHART FOR TROUBLE SYMPTOMS

Items	Trouble symptom		Inspection procedure No.
Communication with M.U.TIII	Communication with engine-ECU is	s not possible	1
Engine warning lamp	The engine warning lamp does not is turned to the "ON" position	illuminate right after the ignition switch	2
	The engine warning lamp remains	illuminating and never goes out	3
Starting	Starter impossible (Starter not operative)	The starter not operative	4
	Starting impossible (Starter operative but no initial combustion)	The starter is operative and cranks the engine, but none of initial combustion is in the cylinders and the engine is not started.	5
	Improper starting (Long time to start)	It is long cranking to start the engine.	6
Improper idling	The proper idling speed is not satis	fied.	7
Engine stalls	The engine stalls when decelerating	The engine stalls at the deceleration.	8
Driving	Poor acceleration	The engine cannot obtain the acceleration corresponding to the degree of throttle opening although the engine is smooth at the constant speed.	9
	A large amount of fuel consumption	Compared with before, the fuel consumption is dramatically increased.	10
Knocking, Abnormal noise	Knocking	Sharp sound like a hammer striking on the cylinder walls during the driving can be heard and wrongly affects the driving.	11
	Abnormal noise	Abnormal noise during the engine operation. (It is presumed that this is caused by malfunction over the wide range.)	
Exhaust gas	White smoke	Exhaust gases are extraordinarily white.	12
	Black smoke, state of exhaust gas purification deteriorated	The exhaust gases are extraordinarily black. The state of the exhaust gas purification is deteriorated.	13
Charging performance	Battery rundown	The battery is soon rundown or the charging ability of battery is small.	14
Cooling performance	Overheating	The temperature of engine cooling water is extremely high.	15

<Added> The DPF regeneration interval is short The DPF lamp illuminates more frequently before. 23

PROBLEM SYMPTOMS TABLE

Inspection procedure No.	Trouble symptom	Reference page
1	Communication with engine-ECU is not possible	
2	The engine warning lamp does not illuminate right after the ignition switch is turned to the "ON" position	
3	The engine warning lamp remains illuminating and never goes out	
4	Starter impossible (Starter not operative)	<vehicles without<br="">AS&G system>, <vehicles as&g<br="" with="">system></vehicles></vehicles>
5	Starting impossible (Starter operative but no initial combustion)	
6	Improper starting (Long time to start)	
7	Improper idling	
8	The engine stalls when decelerating	
9	Poor acceleration	
10	A large amount of fuel consumption	
11	Knocking, Abnormal noise	
12	White smoke	
13	Black smoke, state of exhaust gas purification deteriorated	
14	Battery rundown	
15	Overheating	
16	Engine-ECU power supply system	
17	Engine-ECU battery back-up system	
18	A/C compressor relay system	
19	Fuel pump system	
20	Oil pressure switch system	
21	Water level switch system	
22	Power steering fluid pressure switch system	

	23	The DPF regeneration interval is short
--	----	--

DATA LIST REFERENCE TABLE

Item No.	Check item	Inspection condition	ns .	Value to be determined as normal	Code No. or inspection procedure No.	Reference page	
1	Battery voltage	Ignition switch: ON		System voltage	Procedure No. 14		
2	Engine revolution	Engine: Cranking Tachometer: Connected	Compare engine speed on tachometer with the value displayed on M.U.TIII	Matched	Code No. P0335		
		Engine: Idle operationTransmission:	When the engine coolant temperature: –20 °C	870 – 930 r/min			
		Neutral • A/C switch: OFF	When the engine coolant temperature: 0 °C	770 – 830 r/min			
			When the engine coolant temperature: 25 °C	620 – 680 r/min			
			When the engine coolant temperature: 40 °C	620 – 680 r/min			
			When the engine coolant temperature: 80 °C	620 – 680 r/min			
3	Target Idle speed	Engine: Idle operationTransmission:	When the engine coolant temperature: –20 °C	870 – 930 r/min	_	_	
			Neutral • A/C switch: OFF	When the engine coolant temperature: 0 °C	770 – 830 r/min		
			When the engine coolant temperature: 25 °C	620 – 680 r/min			
			When the engine coolant temperature: 40 °C	620 – 680 r/min			
			When the engine coolant temperature: 80 °C	620 – 680 r/min			
4	Vehicle speed sensor	Running at 40 km/h		Approximately 40 km/h	Code No. P0500		

Inspection Procedure 23: The DPF regeneration interval is short

PROBABLE CAUSES

- Injector leaking or clogged
- Failed injector
- · Small injection quantity incorrectly learning
- Failed air flow sensor connector
- Failed exhaust differential pressure sensor
- Failed exhaust gas temperature sensor

DIAGNOSIS PROCEDURE

STEP 1. M.U.T.-III diagnosis code.

Q: Is the diagnosis code set?

YES: Inspection chart for diagnosis code.

NO: Go to Step 2.

STEP 2. M.U.T.-III data list.

- Refer to Data List Reference Table.
 - a. Item 117: No. 1 exhaust gas temperature sensor
 - b. Item 118: No. 2 exhaust gas temperature sensor (catalyst temperature)
 - c. Item 119: No. 3 exhaust gas temperature sensor (DPF temperature)
 - d. Item 120: Exhaust differential pressure sensor

Q: Are the check results normal?

YES: Go to Step 3.

NO: Replace a defective sensor(s).

STEP 3. M.U.T.-III data list

- Refer to Data List Reference Table.
 - a. Item 114: Air flow sensor

Q: Is the check result normal?

YES: Go to Step 4.

NO: Replace the air flow sensor.

STEP 4. Check injector identification code.

 Check injector identification code (Refer to GROUP 00 – Precautions Before Service – Injector Identification code Registration Procedure).

Q: Is the check result normal?

YES: Go to Step 5.

NO: Register the injector ID.

<Added>

STEP 5. M.U.T.-III actuator test.

- Refer to Actuator Test Reference Table.
 - a. Item 15: Injector No. 1
 - b. Item 16: Injector No. 2
 - c. Item 17: Injector No. 3
 - d. Item 18: Injector No. 4

Q: Is the check result normal?

YES: Go to Step 6.

NO: Replace the injector at the failed cylinder. After replacing the Injector, register the injector identification code and learn fuel injection (Refer to GROUP 00 – Precautions Before Service – What The Common Rail Engine Learns).

STEP 6. Check injector itself.


· Check injector itself.

Q: Is the check result normal?

YES: Execute the small injection quantity learning (Refer to GROUP 00 – Precautions Before Service – Small Injection Quantity Learning Procedure).

NO: Replace the injector at the failed cylinder. After replacing the Injector, register the injector identification code and learn fuel injection (Refer to GROUP 00 – Precautions Before Service – What The Common Rail Engine Learns).

DIAGNOSIS FUNCTION



ENGINE WARNING LAMP (CHECK ENGINE LAMP)

When the abnormal condition occurs with respect to the items of electronically controlled fuel injection system shown in the table, the engine warning lamp is illuminated. When the lamp remains illuminated after the engine start, or when the lamp is illuminated while the engine is running, check the diagnosis code output. There are two methods for checking the indicator lamp burn out: When the ignition switch is in ON position, the indicator lamp is illuminated, and then extinguished few seconds later. When the ignition switch is in ON position and the engine starts, the indicator lamp is extinguished.

ENGINE WARNING LAMP INSPECTION ITEMS

Code No.	Diagnosis item
P0003 ^{*1}	Suction control valve open
P0004*1	Suction control valve battery short
P0016*1	Crank angle sensor/camshaft position sensor phase problem
P0047*1	Variable geometry control solenoid valve circuit low input
P0048*1	Variable geometry control solenoid valve circuit high input
P0072	Intake air temperature sensor circuit low input
P0073	Intake air temperature sensor circuit high input
P0088 ^{*1}	Common rail high pressure malfunction
P0089*1	Suction control valve stuck
P0093*1	Fuel leak problem
P0102	Air flow sensor circuit low input
P0103	Air flow sensor circuit high input
P0106*1	Manifold absolute pressure sensor range/performance problem
P0107*1	Manifold absolute pressure sensor circuit low input
P0108 ^{*1}	Manifold absolute pressure sensor circuit high input
P0112	EGR gas temperature sensor circuit low input
P0113	EGR gas temperature sensor circuit high input
P0117	Engine coolant temperature sensor circuit low input
P0118	Engine coolant temperature sensor circuit high input
P0122	Throttle position sensor circuit low input
P0123	Throttle position sensor circuit high input
P0182	Fuel temperature sensor circuit low input
P0183	Fuel temperature sensor circuit high input
P0191 ^{*1}	Rail pressure sensor range/performance problem
P0192 ^{*1}	Rail pressure sensor circuit low input

P0101*1 | Air flow sensor range/performance problem

	<u> </u>	
_	P2454 ^{*1}	Exhaust differential pressure sensor circuit low input
//	P2455 ^{*1}	Exhaust differential pressure sensor circuit high input
	P2463 ^{*1}	No chance of forcible regeneration of DPF

NOTE:

• After the engine-ECU has detected a malfunction, the

P2453*1 Exhaust differential pressure sensor range/performance problem

Code No.	Diagnosis item	Control contents during malfunction
P0093	Fuel leak problem	 The rail pressure is controlled to be 100 MPa or less. The fuel injection amount is restricted. (Output restriction) The open angle of the accelerator pedal is restricted. The throttle valve is closed. (Fixed opening degree) The EGR control is stopped (fully closed). The DPF regeneration is prohibited. The AS&G control is prohibited.
P0102	Air flow sensor circuit low input	 The control is performed using the previous value. The DPF regeneration is prohibited. The throttle valve is opened. (Electrical discontinuity) The EGR control is stopped (fully closed). The AS&G control is prohibited.
P0103	Air flow sensor circuit high input	 The control is performed using the previous value. The DPF regeneration is prohibited. The throttle valve is opened. (Electrical discontinuity) The EGR control is stopped (fully closed). The AS&G control is prohibited.
P0106	Manifold absolute pressure sensor range/performance problem	 The pressure in the inlet manifold is controlled to be 100 kPa. The EGR control is stopped (fully closed). The fuel injection amount is restricted. (Output restriction) The open angle of the accelerator pedal is restricted. The DPF regeneration is prohibited. The throttle valve is opened. (Electrical discontinuity) The AS&G control is prohibited.
P0107	Manifold absolute pressure sensor circuit low input	 The pressure in the inlet manifold is controlled to be 100 kPa. The EGR control is stopped (fully closed). The fuel injection amount is restricted. (Output restriction) The turbocharger control is prohibited. The open angle of the accelerator pedal is restricted. The DPF regeneration is prohibited. The throttle valve is opened. (Electrical discontinuity) The AS&G control is prohibited.

rformance problem	The DPF regeneration is prohibited.
•	p the Dri regeneration is prombited.
	The throttle valve is opened. (Electrical
	discontinuity)
	• The EGR control is stopped (fully closed).

Code No.	Diagnosis item	Control contents during malfunction
P2151	Injector common 2 (cylinder No. 2 and No. 3) circuit battery short	 The engine is stopped (The fuel injection and pump pressure feed are stopped). The throttle valve is opened. (Electrical discontinuity) The EGR control is stopped (fully closed). The DPF regeneration is prohibited. The AS&G control is prohibited.
P2228	Barometric pressure sensor circuit low input	 The EGR control is stopped (fully closed). The throttle valve is opened. (Electrical discontinuity) The DPF regeneration is prohibited. The turbocharger control is prohibited. The AS&G control is prohibited.
P2229	Barometric pressure sensor circuit high input	 The EGR control is stopped (fully closed). The throttle valve is opened. (Electrical discontinuity) The DPF regeneration is prohibited. The turbocharger control is prohibited. The AS&G control is prohibited.
P2413	EGR system performance	 The EGR control is stopped (fully closed). The DPF regeneration is prohibited. The throttle valve is opened. (Electrical discontinuity) The AS&G control is prohibited. The NPG/SPG control is stopped. The small injection quantity learning is prohibited.
P2426	EGR cooling valve control circuit (Low)	The EGR control is stopped (fully closed).
P2427	EGR cooling valve control circuit (High)	The EGR control is stopped (fully closed).
P244A	DPF differential pressure too low	The DPF regeneration is prohibited.
P2454	Exhaust differential pressure sensor circuit low input	 The throttle valve is opened. (Electrical discontinuity) The EGR control is stopped (fully closed). The DPF regeneration is prohibited. The AS&G control is prohibited.


P2453	Exhaust differential pressure sensor range/performance	The DPF regeneration is prohibited.The AS&G control is prohibited.
		The EGR control is stopped (fully closed).
		The throttle valve is opened. (Electrical
		discontinuity)

INSPECTION CHART FOR DIAGNOSIS CODE

Diagnosis code No.	Diagnosis item	Reference page
P0003	Suction control valve open	
P0004	Suction control valve battery short	
P0016	Crank angle sensor/camshaft position sensor phase problem	
P0047	Variable geometry control solenoid valve circuit low input	
P0048	Variable geometry control solenoid valve circuit high input	
P0072	Intake air temperature sensor circuit low input	
P0073	Intake air temperature sensor circuit high input	
P0088	Common rail high pressure malfunction	
P0089	Suction control valve stuck	
P0093	Fuel leak problem	
P0102	Air flow sensor circuit low input	
P0103	Air flow sensor circuit high input	
P0106	Manifold absolute pressure sensor range/performance problem	
P0107	Manifold absolute pressure sensor circuit low input	
P0108	Manifold absolute pressure sensor circuit high input	
P0112	EGR gas temperature sensor circuit low input	
P0113	EGR gas temperature sensor circuit high input	
P0117	Engine coolant temperature sensor circuit low input	
P0118	Engine coolant temperature sensor circuit high input	
P0122	Throttle position sensor circuit low input	
P0123	Throttle position sensor circuit high input	
P0182	Fuel temperature sensor circuit low input	
P0183	Fuel temperature sensor circuit high input	
P0191	Rail pressure sensor range/performance problem	
P0192	Rail pressure sensor circuit low input	
P0193	Rail pressure sensor circuit high input	
P0201	No. 1 injector circuit malfunction	
P0202	No. 2 injector circuit malfunction	
P0203	No. 3 injector circuit malfunction	
P0204	No. 4 injector circuit malfunction	
P0219	Engine over speed condition	
P0299	Turbocharger under boost condition	
P0301	No. 1 cylinder injector malfunction (No injection)	
P0302	No. 2 cylinder injector malfunction (No injection)	
P0303	No. 3 cylinder injector malfunction (No injection)	
P0304	No. 4 cylinder injector malfunction (No injection)	
DUSSE	Crank andle cencor cyctem	

P0101*1

Air flow sensor range/performance problem



Diagnosis code No.	Diagnosis item	Reference page
P1275	Supply pump exchange	
P1298	Variable geometry turbocharger control system malfunction (high pressure)	
P1299	Variable geometry turbocharger control system malfunction (low pressure)	
P1427	No. 3 exhaust gas temperature sensor (DPF temperature) circuit low input	
P1428	No. 3 exhaust gas temperature sensor (DPF temperature) circuit high input	
P1497	DPF system malfunction	
P1498	Excessive PM accumulated in DPF	
P1499	Abnormally high DPF temperature	
P1608	Battery current sensor system	
P1625	Injection quantity compensation value error	
P1626	Injection quantity compensation value not coding	
P2118	Throttle valve control DC motor current malfunction	
P2122	Accelerator pedal position sensor (main) circuit low input	
P2123	Accelerator pedal position sensor (main) circuit high input	
P2124	Accelerator pedal position sensor (main) circuit high input intermittent	
P2127	Accelerator pedal position sensor (sub) circuit low input	
P2128	Accelerator pedal position sensor (sub) circuit high input	
P2138	Accelerator pedal position sensor (main and sub) range/performance problem	
P2146	Injector common 1 (cylinder No. 1 and No. 4) circuit open	
P2147	Injector common 1 (cylinder No. 1 and No. 4) circuit earth short	
P2148	Injector common 1 (cylinder No. 1 and No. 4) circuit battery short	
P2149	Injector common 2 (cylinder No. 2 and No. 3) circuit open	
P2150	Injector common 2 (cylinder No. 2 and No. 3) circuit earth short	
P2151	Injector common 2 (cylinder No. 2 and No. 3) circuit battery short	
P2228	Barometric pressure sensor circuit low input	
P2229	Barometric pressure sensor circuit high input	
P2413	EGR system performance	
P2426	EGR cooling valve control circuit (low)	
P2427	EGR cooling valve control circuit (high)	
P244A	DPF differential pressure too low	
P2454	Exhaust differential pressure sensor circuit low input	
P2455	Exhaust differential pressure sensor circuit high input	
P2463	No chance of forcible regeneration of DPF	
P252F	Engine oil level malfunction	
U0001	Bus off	<u> </u>

P2453

Exhaust differential pressure sensor range/performance problem

Code No. P0102: Air flow Sensor Circuit Low Input

OPERATION

- Power is supplied by the engine control relay connector terminal to the air flow sensor connector terminal, and the air flow sensor connector terminal is earthed through the engine-ECU connector terminal AFSE&ECBE.
- The air flow sensor connector terminal outputs a sensor signal, which is input into the engine-ECU connector terminal AFS.

FUNCTION

- The air flow sensor outputs pulse signal that varies in accordance with the intake air volume.
- In response to the signal, the engine-ECU controls EGR control, etc.

TROUBLE JUDGMENT

Check Conditions

- Battery positive voltage is 8 16 V
- 2 seconds later after the ignition switch has been

in "ON" position or the engine has started up.

Judgment Criterion

 The air flow sensor output voltage is 0.50 V or less.

FAIL-SAFE AND BACKUP FUNCTION

- The control is performed using the previous value.
- The DPF regeneration is prohibited.
- The throttle valve is opened (Electrical discontinuity).
- The EGR control is stopped (fully closed).
- The AS&G control is prohibited.

PROBABLE CAUSES

- · Failed air flow sensor
- Open/short circuit or harness damage in air flow sensor circuit or loose connector contact
- Failed engine-ECU

DIAGNOSTIC PROCEDURE

STEP 1. M.U.T.-III data list (

- Refer to Data List Reference Table.
 - a. Item 114: Air flow sensor

Q: Is the check result normal?

YES: Intermittent malfunction (Refer to GROUP 00 – How to Use Troubleshooting/Inspection Service Points – How to Cope with Intermittent Malfunctions).

NO: Go to Step 2.

STEP 2. Perform voltage measurement at air flow sensor connector.

- Disconnect connector, and measure at harness side.
- Ignition switch: ON
- Voltage between terminal power supply line and body earth.

OK: System voltage

Q: Is the check result normal?

YES: Go to Step 3.

NO: Repair or replace the connector, or check and repair harness between engine control relay connector terminal and air flow sensor connector terminal.

• Check power supply line for open/short circuit.

STEP 3. Perform resistance measurement at air flow sensor connector.

- Disconnect connector, and measure at harness side.
- Resistance between terminal engine-ECU AFSE&ECBE

Code No. P0101: Air Flow Sensor Range/Performance Problem

OPERATION

- Power is supplied by the engine control relay (terminal No. 2) to the air flow sensor (terminal No. 3), and the air flow sensor (terminal No. 2) is earthed through the engine-ECU AFSE & ECBE.
- The air flow sensor (terminal No. 1) outputs a sensor signal, which is input into the engine-ECU AFS.

FUNCTION

- The air flow sensor outputs pulse signal that varies in accordance with the intake air volume.
- In response to the signal, the engine-ECU controls EGR control, etc.

TROUBLE JUDGEMENT

Check Conditions

- Battery positive voltage is 8 16 V
- 1 second before the throttle valve fully openedposition value after the ignition switch has been in "LOCK" (OFF) position.

Judgement Criterion

• The air flow sensor output voltage is threshold value or less.

or

 The air flow sensor output voltage is threshold value or more.

FAIL-SAFE AND BACKUP FUNCTION

- The control is performed using the previous value.
- The DPF regeneration is prohibited.
- The throttle valve is opened (Electrical discontinuity).
- The EGR control is stopped (fully closed).

PROBABLE CAUSES

- Failed air flow sensor
- Harness damage in air flow sensor circuit or loose connector contact
- Failed engine-ECU

DIAGNOSIS PROCEDURE

STEP 1. Check harness between engine control relay connector (terminal No. 2) and air flow sensor connector (terminal No. 3).

• Check power supply line for damage.

Q: Is the check result normal?

YES: Go to Step 2.

NO: Repair the damaged harness wire.

STEP 2. Check harness between air flow sensor connector (terminal No. 1) and engine-ECU connector terminal AFS.

· Check output line for damage.

Q: Is the check result normal?

YES: Go to Step 3.

NO: Repair the damaged harness wire.

STEP 3. Check harness between air flow sensor connector (terminal No. 2) and engine-ECU connector terminal AFSE & ECBE.

· Check earthing line for damage.

Q: Is the check result normal?

YES: Go to Step 4.

NO: Repair the damaged harness wire.

STEP 4. M.U.T.-III data list

• Refer to Data List Reference Table.

a. Item 114: Air flow sensor

Q: Is the check result normal?

YES: Intermittent malfunction (Refer to GROUP 00 – How to Use Troubleshooting/Inspection Service Points – How to Cope with Intermittent Malfunctions).

NO: Go to Step 5.

STEP 5. Replace the air flow sensor.

• After replacing the air flow sensor, re-check the trouble symptoms.

Q: Is the check result normal?

YES: Check end.

NO: Replace the engine-ECU.

Code No. P1497: DPF System Malfunction

FUNCTION ()

 The engine-ECU monitors the input signals from sensors to check if the DPF regeneration is executed normally.

TROUBLE JUDGMENT

Check Condition

On DPF regeneration

Judgement Criterion

 The DPF regeneration status continues for the predetermined time or more.

FAIL-SAFE AND BACKUP FUNCTION

The throttle valve is opened. (Electrical

discontinuity)

- The EGR control is stopped (fully closed).
- The DPF regeneration is prohibited.
- The AS&G control is prohibited.

PROBABLE CAUSES

- Failed No. 2 exhaust gas temperature sensor (catalyst temperature)
- Failed No. 3 exhaust gas temperature sensor (DPF temperature)
- Failed exhaust differential pressure sensor
- Catalytic converter inactive
- The engine oil-containing ash is loaded to the DPF inside.

DIAGNOSIS PROCEDURE

STEP 1. M.U.T.-III data list.

- Refer to Data List Reference Table.
 - a. Item 118: No. 2 exhaust gas temperature sensor (catalyst temperature)
 - b. Item 119: No. 3 exhaust gas temperature sensor (DPF temperature)
 - c. Item 120: Exhaust differential pressure sensor

Q: Are the check results normal?

YES: Go to Step 2.

NO: Perform the diagnosis code classified check procedure for the sensor that has shown an abnormal data value (Refer to Inspection Chart for Diagnosis Code).

STEP 2. Forcible DPF regeneration execution (S2)

- Initialise the DPF-related parts, and then delete the diagnosis code (Refer to GROUP 00 – Precautions before Service – Initialisation Procedure for Learning Value in Common Rail Engine <4N1).
 - a. Item 42: DPF system malfunction service
- Carry out the forcible DPF regeneration (Refer to GROUP 17 – Emission Control <DIESEL> – Diesel Particulate Filter (DPF) System Forcible DPF Regeneration).

Carry out the small injection quantity learning procedure (Refer to GROUP 00 – Precautions before Service – Small Injection Quantity Learning Procedure <4N1>).

Code No. P1498: Excessive PM Accumulated In DPF

FUNCTION

- The engine-ECU monitors the input signals from sensors to estimate the PM amount loaded to the DPF inside.
- If the PM is loaded more than the specified amount, the DPF regeneration is automatically executed under certain conditions in order to eliminate the PM.
- If the PM is excessively loaded, the engine-ECU does not execute the automatic DPF regeneration. It makes the engine warning lamp illuminate and allow the DPF warning mark to be shown.

TROUBLE JUDGMENT

Check Condition

• Ignition switch is in "ON" position.

Judgement Criterion

 Driving distance exceeds the specified value after the last DPF regeneration.

FAIL-SAFE AND BACKUP FUNCTION

- The throttle valve is opened (Electrical discontinuity).
- The EGR control is stopped (fully closed).
- The DPF regeneration is prohibited.
- The fuel injection amount is restricted (Output restriction).
- The open angle of the accelerator pedal is restricted.
- The AS&G control is prohibited.

PROBABLE CAUSE

The PM is abnormally loaded to the DPF inside.

The small injection quantity improperly learned.

DIAGNOSIS PROCEDURE

<Added>

STEP 1. M.U.T.-III diagnosis code.

 Check whether the diagnosis code P2463 is set together with P1498 or not.

Q: Is the diagnosis code P2463 set?

YES: Troubleshoot the diagnosis code P2463.

NO: Go to Step 2.

STEP 2. Forcible DPF regeneration execution

 Carry out the forcible DPF regeneration (Refer to GROUP 17 – Emission Control <DIESEL> – Diesel Particulate Filter (DPF) System – Forcible DPF Regeneration).

Q: Is the diagnosis code set?

YES: Inspection chart for diagnosis code.

NO: Check end.

<Added>

Carry out the small injection quantity learning procedure (Refer to GROUP 00

 Precautions before Service - Small Injection Quantity Learning Procedure
 4N1>).

Code No. P2454: Exhaust Differential Pressure Sensor Circuit Low Input

OPERATION

- A power voltage of 5 V is applied to the exhaust differential pressure sensor power terminal from the engine-ECU connector terminal DDP5 and earthed to the engine-ECU connector terminal DDPE from the exhaust differential pressure sensor connector terminal.
- The sensor signal is inputted to the engine-ECU connector terminal DDPS from the exhaust differential pressure sensor output terminal.

FUNCTION

- The exhaust differential pressure sensor outputs the voltage to the engine-ECU in accordance with the difference in the voltage between the DPF upstream area and the DPF downstream area.
- The engine-ECU anticipates the amount of PM accumulated in the DPF through this output voltage.

TROUBLE JUDGMENT

Check Conditions

- Battery positive voltage is 8 16 V
- 2 seconds later after the ignition switch has been in "ON" position or the engine has started up

Judgment Criterion

• The exhaust differential pressure sensor output voltage is 0.49 V or less.

FAIL-SAFE AND BACKUP FUNCTION

- The throttle valve is opened (Electrical discontinuity).
- The EGR control is stopped (fully closed).
- The DPF regeneration is prohibited.
- The AS&G control is prohibited.

PROBABLE CAUSES

- Failed exhaust differential pressure sensor
- Open/short circuit or harness damage in exhaust differential pressure sensor circuit or loose connector contact
- Failed engine-ECU

DIAGNOSTIC PROCEDURE

STEP 1. M.U.T.-III data list

- Refer to Data List Reference Table.
 - a. Item 120: Exhaust differential pressure sensor

Q: Is the check result normal?

YES: Intermittent malfunction (Refer to GROUP 00 – How to Use Troubleshooting/Inspection Service Points – How to Cope with Intermittent Malfunctions).

NO: Go to Step 2.

STEP 2. Perform voltage measurement at exhaust differential pressure sensor connector.

- Disconnect connector, and measure at harness side.
- Ignition switch: ON
- Voltage between terminal engine-ECU DDP5 line and body earth.

OK: 4.9 - 5.1 V

Q: Is the check result normal?

YES: Go to Step 6. **NO**: Go to Step 3.

STEP 3. Perform voltage measurement at engine-ECU connector.

 Disconnect engine-ECU harness, and connect special tool power plant ECU check harness (MB992291) to measure at

Code No. P2453: Exhaust Differential Pressure Sensor Range/Performance Problem

OPERATION

- A power voltage of 5 V is applied to the exhaust differential pressure sensor power terminal (terminal No. 3) from the engine-ECU DDP5 and earthed to the engine-ECU DDPE from the exhaust differential pressure sensor (terminal No. 2).
- The sensor signal is inputted to the engine-ECU DDPS from the exhaust differential pressure sensor output terminal (terminal No. 1).

FUNCTION

- The exhaust differential pressure sensor outputs the voltage to the engine-ECU in accordance with the difference in the voltage between the DPF upstream area and the DPF downstream area.
- The engine-ECU anticipates the amount of PM accumulated in the DPF through this output voltage.

TROUBLE JUDGEMENT

Check Conditions

- Battery positive voltage is 8 16 V
- · Vehicle in steady running.

Judgement Criterion

 The exhaust differential pressure sensor output voltage is less than threshold value based on exhaust gas flow for predetermined time.

Check Conditions

- Battery positive voltage is 8 16 V
- Predetermined time has passed after the engine is stopped.
- The malfunction of P2454 or P2455 is not detected.

Judgement Criterion

• The exhaust differential pressure sensor output is more than 2.75 kPa for predetermined time.

or

• The exhaust differential pressure sensor output is less than –2.75 kPa for predetermined time.

FAIL-SAFE AND BACKUP FUNCTION

- The DPF regeneration is prohibited.
- The AS&G control is prohibited.
- The EGR control is stopped (fully closed).
- The throttle valve is opened (Electrical discontinuity).

PROBABLE CAUSES

- The exhaust pressure hose or the exhaust pressure pipe is disconnected, damaged, misconnected or clogged.
- Failed exhaust differential pressure sensor
- Harness damage in exhaust differential pressure sensor circuit or loose connector contact
- Failed engine-ECU

DIAGNOSIS PROCEDURE

STEP 1. Check exhaust pressure hose and exhaust pressure pipe.

 Check the lines between the exhaust differential pressure sensor and the exhaust centre pipe (DPF) (i.e, exhaust pressure hose and exhaust pressure pipe) for disconnection, damage, wrong connection or clogging.

Q: Are the check results normal?

YES: Go to Step 2.

NO: Repair or replace the exhaust pressure hose or exhaust pressure pipe.

STEP 2. M.U.T.-III data list

- Refer to Data List Reference Table.
 - a. Item 120: Exhaust differential pressure sensor

Q: Is the check result normal?

YES: Intermittent malfunction (Refer to GROUP 00 – How to Use Troubleshooting/Inspection Service Points – How to Cope with Intermittent Malfunctions).

NO: Go to Step 3.

STEP 3. Check harness between exhaust differential pressure (terminal No. 3) sensor connector and engine-ECU connector DDP5.

Check power supply line for damage.

Q: Is the check result normal?

YES: Go to Step 4.

NO: Repair the damaged harness wire.

STEP 4. Check harness between exhaust differential pressure sensor connector (terminal No. 1) and engine-ECU connector terminal DDPS.

· Check output line for damage.

Q: Is the check result normal?

YES: Go to Step 5.

NO: Repair the damaged harness wire.

STEP 5. Check harness between exhaust differential pressure sensor connector (terminal No. 2) and engine-ECU connector terminal DDPE.

Check earthing line for damage.

Q: Is the check result normal?

YES: Go to Step 6.

NO: Repair the damaged harness wire.

STEP 6. Replace the exhaust differential pressure sensor

 After replacing the exhaust differential pressure sensor, carry out the forcible DPF regeneration. (Refer to GROUP 17 – Emission Control <DIESEL> – Diesel Particulate Filter (DPF) System – Forcible DPF Regeneration). After carrying out the forcible DPF regeneration, re-check the trouble symptoms.

Q: Is the check result normal?

YES: Check end.

NO: Replace the engine-ECU.

INSPECTION CHART FOR TROUBLE SYMPTOMS

Items	Trouble symptom		Inspection procedure No.
Communication with M.U.TIII	Communication with engine-ECU is not possible		1
Engine warning lamp	The engine warning lamp does not illuminate right after the ignition switch is turned to the "ON" position		2
	The engine warning lamp remains	illuminating and never goes out	3
Starting	Starter impossible (Starter not operative)	The starter not operative	4
	Starting impossible (Starter operative but no initial combustion)	The starter is operative and cranks the engine, but none of initial combustion is in the cylinders and the engine is not started.	5
	Improper starting (Long time to start)	It is long cranking to start the engine.	6
Improper idling	The proper idling speed is not satis	fied.	7
Engine stalls	The engine stalls when decelerating	The engine stalls at the deceleration.	8
Driving	Poor acceleration	The engine cannot obtain the acceleration corresponding to the degree of throttle opening although the engine is smooth at the constant speed.	9
	A large amount of fuel consumption	Compared with before, the fuel consumption is dramatically increased.	10
Knocking, Abnormal noise	Knocking	Sharp sound like a hammer striking on the cylinder walls during the driving can be heard and wrongly affects the driving.	11
	Abnormal noise	Abnormal noise during the engine operation. (It is presumed that this is caused by malfunction over the wide range.)	
Exhaust gas	White smoke	Exhaust gases are extraordinarily white.	12
	Black smoke, state of exhaust gas purification deteriorated	The exhaust gases are extraordinarily black. The state of the exhaust gas purification is deteriorated.	13
Charging performance	Battery rundown	The battery is soon rundown or the charging ability of battery is small.	14
Cooling performance	Overheating	The temperature of engine cooling water is extremely high.	15

<added></added>	The DPF regeneration interval is	The DPF lamp illuminates more	22
	short	frequently before.	

PROBLEM SYMPTOMS TABLE

		1	
5	Starting impossible (Starter operative but no initial combustion)		
6	Improper starting (Long time to start)		
7	Improper idling		
8	The engine stalls when decelerating		
9	Poor acceleration		
10	A large amount of fuel consumption		
11	Knocking, Abnormal noise		
12	White smoke		
13	Black smoke, state of exhaust gas purification deteriorated		
14	Battery rundown		
15	Overheating		
16	Engine-ECU power supply system		
17	Engine-ECU battery back-up system		
18	A/C compressor relay system		
19	Fuel pump system		
20	Engine oil pressure switch system		
21	Water level switch system		

22 The DPF regeneration interval is short

DATA LIST REFERENCE TABLE

Item No.	Check item	Inspection conditions		Value to be determined as normal	
1	Battery voltage	Ignition switch: ON		System voltage	
2	Engine revolution	Engine: Cranking Tachometer: Connected	Compare engine speed on tachometer with the value displayed on M.U.TIII	Matched	
		Engine: Idle operationTransmission: Neutral	When the engine coolant temperature: –20 °C	870 – 930 r/min	

Inspection Procedure 22: The DPF regeneration interval is short

PROBABLE CAUSES

- Injector leaking or clogged
- Failed injector
- · Small injection quantity incorrectly learning
- Failed air flow sensor connector
- Failed exhaust differential pressure sensor
- Failed exhaust gas temperature sensor

DIAGNOSIS PROCEDURE

STEP 1. M.U.T.-III diagnosis code.

Q: Is the diagnosis code set?

YES: Inspection chart for diagnosis code.

NO: Go to Step 2.

STEP 2. M.U.T.-III data list.

- Refer to Data List Reference Table.
 - a. Item 117: No. 1 exhaust gas temperature sensor
 - b. Item 118: No. 2 exhaust gas temperature sensor (catalyst temperature)
 - c. Item 119: No. 3 exhaust gas temperature sensor (DPF temperature)
 - d. Item 120: Exhaust differential pressure sensor

Q: Are the check results normal?

YES: Go to Step 3.

NO: Replace a defective sensor(s).

STEP 3. M.U.T.-III data list

- Refer to Data List Reference Table.
 - a. Item 114: Air flow sensor

Q: Is the check result normal?

YES: Go to Step 4.

NO: Replace the air flow sensor.

STEP 4. Check injector identification code.

 Check injector identification code (Refer to GROUP 00 – Precautions Before Service – Injector Identification code Registration Procedure).

Q: Is the check result normal?

YES: Go to Step 5.

NO: Register the injector ID.

<Added>

STEP 5. M.U.T.-III actuator test.

- Refer to Actuator Test Reference Table.
 - a. Item 15: Injector No. 1
 - b. Item 16: Injector No. 2
 - c. Item 17: Injector No. 3
 - d. Item 18: Injector No. 4

Q: Is the check result normal?

YES: Go to Step 6.

NO: Replace the injector at the failed cylinder. After replacing the Injector, register the injector identification code and learn fuel injection (Refer to GROUP 00 – Precautions Before Service – What The Common Rail Engine Learns).

STEP 6. Check injector itself.


· Check injector itself.

Q: Is the check result normal?

YES: Execute the small injection quantity learning (Refer to GROUP 00 – Precautions Before Service – Small Injection Quantity Learning Procedure).

NO: Replace the injector at the failed cylinder. After replacing the Injector, register the injector identification code and learn fuel injection (Refer to GROUP 00 – Precautions Before Service – What The Common Rail Engine Learns).

DIAGNOSIS FUNCTION



ENGINE WARNING LAMP (CHECK ENGINE LAMP)

When the abnormal condition occurs with respect to the items of electronically controlled fuel injection system shown in the table, the engine warning lamp is illuminated. When the lamp remains illuminated after the engine start, or when the lamp is illuminated while the engine is running, check the diagnosis code output. There are two methods for checking the indicator lamp burn out: When the ignition switch is in ON position, the indicator lamp is illuminated, and then extinguished few seconds later. When the ignition switch is in ON position and the engine starts, the indicator lamp is extinguished.

ENGINE WARNING LAMP INSPECTION ITEMS

Code No.	Diagnosis item
P0003 ^{*1}	Suction control valve open
P0004 ^{*1}	Suction control valve battery short
P0016 ^{*1}	Crank angle sensor/camshaft position sensor phase problem
P0047*1	Variable geometry control solenoid valve circuit low input
P0048 ^{*1}	Variable geometry control solenoid valve circuit high input
P0072	No. 1 intake air temperature sensor circuit low input
P0073	No. 1 intake air temperature sensor circuit high input
P0088 ^{*1}	Common rail high pressure malfunction
P0089 ^{*1}	Suction control valve stuck
P0093 ^{*1}	Fuel leak problem
P0102	Air flow sensor circuit low input
P0103	Air flow sensor circuit high input
P0106 ^{*1}	Manifold absolute pressure sensor range/performance problem
P0107 ^{*1}	Manifold absolute pressure sensor circuit low input
P0108 ^{*1}	Manifold absolute pressure sensor circuit high input
P0112	No. 2 intake air temperature sensor circuit low input
P0113	No. 2 intake air temperature sensor circuit high input
P0117	Engine coolant temperature sensor circuit low input
P0118	Engine coolant temperature sensor circuit high input
P0122	Throttle position sensor circuit low input
P0123	Throttle position sensor circuit high input
P0182	Fuel temperature sensor circuit low input
P0183	Fuel temperature sensor circuit high input
P0191*1	Rail pressure sensor range/performance problem
P0192*1	Rail pressure sensor circuit low input

P0101*1 Air flow sensor range/performance problem

Code No.	Diagnosis item	
P2229	Barometric pressure sensor circuit high input	
P2413	EGR system performance	
P2427	EGR cooling valve control circuit (High)	
P2454 ^{*1}	Exhaust differential pressure sensor circuit low input	
P2455 ^{*1}	Exhaust differential pressure sensor circuit high input	

NOTE:

 After the engine-ECU has detected a malfunction, the engine warning lamp illuminates when the engine is next turned on and the same malfunction is re-detected. However, for items marked with a "*1" in the diagnosis code number column, the engine warning lamp illuminates only on the first detection of the malfunction.

P2453*1

Exhaust differential pressure sensor range/performance problem


		 The fuel injection amount is restricted. (Output restriction) The open angle of the accelerator pedal is restricted. The throttle valve is closed. (Fixed opening degree) The EGR control is stopped (fully closed). The DPF regeneration is prohibited. The AS&G control is prohibited.
P0102	Air flow sensor circuit low input	 The control is performed using the previous value. The DPF regeneration is prohibited. The throttle valve is opened. (Electrical discontinuity) The EGR control is stopped (fully closed). The AS&G control is prohibited.
P0103	Air flow sensor circuit high input	 The control is performed using the previous value. The DPF regeneration is prohibited. The throttle valve is opened. (Electrical discontinuity) The EGR control is stopped (fully closed). The AS&G control is prohibited.
P0106	Manifold absolute pressure sensor range/performance problem	 The pressure in the inlet manifold is controlled to be 100 kPa. The EGR control is stopped (fully closed). The fuel injection amount is restricted. (Output restriction) The open angle of the accelerator pedal is restricted. The DPF regeneration is prohibited. The throttle valve is opened. (Electrical discontinuity) The AS&G control is prohibited.
P0107	Manifold absolute pressure sensor circuit low input	The pressure in the inlet manifold is controlled to be 100 kPa.
		
P0101	Air flow sensor range/ performance problem	 The control is performed using the previous value. The DPF regeneration is prohibited. The throttle valve is opened. (Electrical discontinuit) The EGR control is stopped (fully closed).

		THE ASAG CONTROL IS PROBIDITED.
P2413	EGR system performance	 The EGR control is stopped (fully closed). The DPF regeneration is prohibited. The throttle valve is opened. (Electrical discontinuity) The AS&G control is prohibited.
P2426	EGR cooling valve control circuit (Low)	The EGR control is stopped (fully closed).
P2427	EGR cooling valve control circuit (High)	The EGR control is stopped (fully closed).
P2454	Exhaust differential pressure sensor circuit low input	 The throttle valve is opened. (Electrical discontinuity) The EGR control is stopped (fully closed). The DPF regeneration is prohibited. The AS&G control is prohibited.
P2455	Exhaust differential pressure sensor circuit high input	 The throttle valve is opened. (Electrical discontinuity) The EGR control is stopped (fully closed). The DPF regeneration is prohibited. The AS&G control is prohibited.

P2453	Exhaust differential pressure sensor range/performance	 The DPF regeneration is prohibited. The AS&G control is prohibited. The EGR control is stopped (fully closed).
MSB-14EXL13-00	1(14CD030)	• The throttle valve is opened. (Electrical discontinuity)

Code No. P0102: Air flow Sensor Circuit Low Input

Air flow sensor circuit




Wire colour code
B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Grey R: Red P: Pink V: Violet PU: Purple SI: Silver

AK802733AB


Code No. P0101: Air Flow Sensor Range/Performance Problem


Air flow sensor circuit




Wire colour code
B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Grey R: Red P: Pink V: Violet PU: Purple SI: Silver

AK802733AE







OPERATION

- Power is supplied by the engine control relay (terminal No. 2) to the air flow sensor (terminal No. 3), and the air flow sensor (terminal No. 2) is earthed through the engine-ECU (terminal No. 155).
- The air flow sensor (terminal No. 1) outputs a sensor signal, which is input into the engine-ECU (terminal No. 140).

FUNCTION

- The air flow sensor outputs pulse signal that varies in accordance with the intake air volume.
- In response to the signal, the engine-ECU controls EGR control, etc.

TROUBLE JUDGEMENT

Check Conditions

- Battery positive voltage is 8 16 V
- 1 second before the throttle valve fully openedposition value after the ignition switch has been in "LOCK" (OFF) position.

Judgement Criterion

 The air flow sensor output voltage is 0.573 V or less.

or

 The air flow sensor output voltage is 0.973 V or more.

FAIL-SAFE AND BACKUP FUNCTION

- The control is performed using the previous value.
- The DPF regeneration is prohibited.
- The throttle valve is opened (Electrical discontinuity).
- The EGR control is stopped (fully closed).
- The AS&G control is prohibited.

PROBABLE CAUSES

- Failed air flow sensor
- Open/short circuit or harness damage in air flow sensor circuit or loose connector contact
- Failed engine-ECU

DIAGNOSTIC PROCEDURE

STEP 1. Connector check: A-06 air flow sensor connector

Q: Is the check result normal?

YES: Go to Step 2.

NO: Repair or replace the connector.

STEP 2. Connector check: A-33X engine control relay connector

Q: Is the check result normal?

YES: Go to Step 3.

NO: Repair or replace the connector.

STEP 3. Check harness between A-33X (terminal No. 2) engine control relay connector and A-06 (terminal No. 3) air flow sensor connector.

• Check power supply line for open/short circuit.

Q: Is the check result normal?

YES: Go to Step 4.

NO: Repair the damaged harness wire.

STEP 4. Connector check: B-40 engine-ECU connector

Q: Is the check result normal?

YES: Go to Step 5.

NO: Repair or replace the connector.

STEP 5. Check harness between A-06 (terminal No. 1) air flow sensor connector and B-40 (terminal No. 140) engine-ECU connector.

• Check output line for open/short circuit and damage.

Q: Is the check result normal?

YES: Go to Step 6.

NO: Repair the damaged harness wire.

STEP 6. Check harness between A-06 (terminal No. 2) air flow sensor connector and B-40 (terminal No. 155) engine-ECU connector.

• Check earthing line for damage.

Q: Is the check result normal?

YES: Go to Step 7.

NO: Repair the damaged harness wire.

STEP 7. M.U.T.-III data list

- Refer to Data List Reference Table .
 - a. Item 114: Air flow sensor

Q: Is the check result normal?

YES: Intermittent malfunction (Refer to GROUP 00 – How to Use Troubleshooting/Inspection Service Points – How to Cope with Intermittent Malfunctions M10010139).

NO: Go to Step 8.

STEP 8. Replace the air flow sensor.

 After replacing the air flow sensor, re-check the trouble symptoms.


Q: Is the check result normal?

YES: Check end.

NO: Replace the engine-ECU.

Code No. P2454: Exhaust Differential Pressure Sensor Circuit Low Input


Exhaust differential pressure sensor circuit



Wire colour code


B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Grey R: Red P: Pink V: Violet PU: Purple SI: Silver

AK802776 AB



OPERATION

 A power voltage of 5 V is applied to the exhaust differential pressure sensor power terminal (terminal No. 1) from the engine-ECU (terminal No. 94) and earthed to the engine-ECU (terminal No. 80) from exhaust differential pressure sensor (terminal No. 3).




 The sensor signal is inputted to the engine-ECU (terminal No. 56) from the exhaust differential pressure sensor output terminal (terminal No. 2).

FUNCTION

 The exhaust differential pressure sensor outputs the voltage to the engine-ECU in accordance with


Code No. P2453: Exhaust Differential Pressure Sensor Range/Performance Problem

Exhaust differential pressure sensor circuit




Wire colour code
B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Grey R: Red P: Pink V: Violet PU: Purple SI: Silver

AK802776 AB



OPERATION

 A power voltage of 5 V is applied to the exhaust differential pressure sensor power terminal (terminal No. 1) from the engine-ECU (terminal No. 94) and earthed to the engine-ECU (terminal No. 80) from exhaust differential pressure sensor (terminal No. 3).



 The sensor signal is inputted to the engine-ECU (terminal No. 56) from the exhaust differential pressure sensor output terminal (terminal No. 2).

FUNCTION

 The exhaust differential pressure sensor outputs the voltage to the engine-ECU in accordance with the difference in the voltage between the DPF upstream area and the DPF downstream area.

 The engine-ECU anticipates the amount of PM accumulated in the DPF through this output voltage.

TROUBLE JUDGEMENT

Check Conditions

- Battery positive voltage is 8 16 V
- · Vehicle in steady running.

Judgement Criterion

 The exhaust differential pressure sensor output voltage is less than threshold value based on exhaust gas flow for predetermined time.

Check Conditions

- Battery positive voltage is 8 16 V
- Predetermined time has passed after the engine is stopped.
- The malfunction of P2454 or P2455 is not detected.

Judgement Criterion

• The exhaust differential pressure sensor output is more than 2.75 kPa for predetermined time.

or

 The exhaust differential pressure sensor output is less than -2.75 kPa for predetermined time.

FAIL-SAFE AND BACKUP FUNCTION

- The throttle valve is opened (Electrical discontinuity).
- The EGR control is stopped (fully closed).
- The DPF regeneration is prohibited.
- The AS&G control is prohibited.

PROBABLE CAUSES

- The exhaust pressure hose or the exhaust pressure pipe is disconnected, damaged, misconnected or clogged.
- Failed exhaust differential pressure sensor
- Open/short circuit or harness damage in exhaust differential pressure sensor circuit or loose connector contact
- Failed engine-ECU

DIAGNOSTIC PROCEDURE

STEP 1. Check exhaust pressure hose and exhaust pressure pipe.

 Check the lines between the exhaust differential pressure sensor and the DPF (i.e, exhaust pressure hose and exhaust pressure pipe) for disconnection, damage, wrong connection or clogging.

Q: Are the check results normal?

YES: Go to Step 2.

NO: Repair or replace the exhaust pressure hose or exhaust pressure pipe.

STEP 2. M.U.T.-III data list

- Refer to Data List Reference Table.
 - a. Item 120: Exhaust differential pressure sensor

Q: Is the check result normal?

YES: Intermittent malfunction (Refer to GROUP 00 – How to Use Troubleshooting/Inspection Service Points – How to Cope with Intermittent Malfunctions).

NO: Go to Step 3.

STEP 3. Connector check: A-75 exhaust differential pressure sensor connector

Q: Is the check result normal?

YES: Go to Step 4.

NO: Repair or replace the connector.

STEP 4. Connector check: B-39 engine-ECU connector

Q: Is the check result normal?

YES: Go to Step 5.

NO: Repair or replace the connector.

STEP 5. Check harness between A-75 (terminal No. 1) exhaust differential pressure sensor connector and B-39 (terminal No. 94) engine-ECU connector.

NOTE: Before checking harness, check intermediate connector A-10, and repair if necessary.

• Check power supply line for short circuit.

Q: Is the check result normal?

YES: Go to Step 6.

NO: Repair the damaged harness wire.

STEP 6. Check harness between A-75 (terminal No. 2) exhaust differential pressure sensor connector and B-39 (terminal No. 56) engine-ECU connector.

NOTE: Before checking harness, check intermediate connector A-10, and repair if necessary.

• Check output line for open/short circuit and damage.

Q: Is the check result normal?

YES: Go to Step 7.

NO: Repair the damaged harness wire.

STEP 7. Check harness between A-75 (terminal No. 3) exhaust differential pressure sensor connector and B-39 (terminal No. 80) engine-ECU connector.

NOTE: Before checking harness, check intermediate connector A-10, and repair if necessary.

• Check earthing line for open circuit and damage.

Q: Is the check result normal?

YES: Go to Step 8.

NO: Repair the damaged harness wire.

STEP 8. Replace the exhaust differential pressure sensor

 After replacing the exhaust differential pressure sensor, carry out the forcible DPF regeneration. (Refer to GROUP 17 – Emission Control <DIESEL> – Diesel Particulate Filter (DPF) System – Forcible DPF regeneration).

Q: Is the check result normal?

YES: Check end.

NO: Replace the engine-ECU.

INSPECTION CHART FOR TROUBLE SYMPTOMS

Items	Trouble symptom		Inspection procedure No.
Communication with M.U.TIII	Communication with engine-ECU is not possible		1
Engine warning lamp			2
	The engine warning lamp remains	illuminating and never goes out	3
Starting	Starter impossible (Starter not operative)	The starter not operative	4
	Starting impossible (Starter operative but no initial combustion)	The starter is operative and cranks the engine, but none of initial combustion is in the cylinders and the engine is not started.	5
	Improper starting (Long time to start)	It is long cranking to start the engine.	6
Improper idling	The proper idling speed is not satis	fied.	7
Engine stalls	The engine stalls when decelerating	The engine stalls at the deceleration.	8
Driving	Poor acceleration	The engine cannot obtain the acceleration corresponding to the degree of throttle opening although the engine is smooth at the constant speed.	9
	A large amount of fuel consumption	Compared with before, the fuel consumption is dramatically increased.	10
Knocking, Abnormal noise	Knocking	Sharp sound like a hammer striking on the cylinder walls during the driving can be heard and wrongly affects the driving.	11
	Abnormal noise	Abnormal noise during the engine operation. (It is presumed that this is caused by malfunction over the wide range.)	
Exhaust gas	White smoke	Exhaust gases are extraordinarily white.	12
	Black smoke, state of exhaust gas purification deteriorated	The exhaust gases are extraordinarily black. The state of the exhaust gas purification is deteriorated.	13
Charging performance	Battery rundown	The battery is soon rundown or the charging ability of battery is small.	14
Cooling performance	Overheating	The temperature of engine cooling water is extremely high.	15

The DPF regeneration interval	The DPF lamp illuminates more	22
is short	frequently before.	


PROBLEM SYMPTOMS TABLE

Inspection procedure No.	Trouble symptom	Reference page
1	Communication with engine-ECU is not possible	
2	The engine warning lamp does not illuminate right after the ignition switch is turned to the "ON" position	
3	The engine warning lamp remains illuminating and never goes out	
4	Starter impossible (Starter not operative)	<pre><vehicles as&g="" system="" without="">, <vehicles as&g="" system="" with=""></vehicles></vehicles></pre>
5	Starting impossible (Starter operative but no initial combustion)	
6	Improper starting (Long time to start)	
7	Improper idling	
8	The engine stalls when decelerating	
9	Poor acceleration	
10	A large amount of fuel consumption	
11	Knocking, Abnormal noise	
12	White smoke	
13	Black smoke, state of exhaust gas purification deteriorated	
14	Battery rundown	
15	Overheating	
16	Engine-ECU power supply system	
17	Engine-ECU battery back-up system	
18	A/C compressor relay system	
19	Fuel pump system	
20	Oil pressure switch system	
21	Water level switch system	

22 | The DPF regeneration interval is short

Code No. P2454: Exhaust Differential Pressure Sensor Circuit Low Input


Exhaust differential pressure sensor circuit



Wire colour code


B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Grey R: Red P: Pink V: Violet PU: Purple SI: Silver

AK802776 AD



OPERATION ()

• A power voltage of 5 V is applied to the exhaust differential pressure sensor power terminal (terminal No. 1) from the engine-ECU (terminal No. 94) and earthed to the engine-ECU (terminal No. 80) from exhaust differential pressure sensor (terminal No. 3).




• The sensor signal is inputted to the engine-ECU (terminal No. 56) from the exhaust differential pressure sensor output terminal (terminal No. 2).

FUNCTION

• The exhaust differential pressure sensor outputs the voltage to the engine-ECU in accordance with

Code No. P2453: Exhaust Differential Pressure Sensor Range/Performance Problem


Exhaust differential pressure sensor circuit



Wire colour code

B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Grey R: Red P: Pink V: Violet PU: Purple SI: Silver


AK802776 AD



B-39

OPERATION

 A power voltage of 5 V is applied to the exhaust differential pressure sensor power terminal (terminal No. 1) from the engine-ECU (terminal No. 94) and earthed to the engine-ECU (terminal No. 80) from exhaust differential pressure sensor (terminal No. 3).



 The sensor signal is inputted to the engine-ECU (terminal No. 56) from the exhaust differential pressure sensor output terminal (terminal No. 2).

FUNCTION

 The exhaust differential pressure sensor outputs the voltage to the engine-ECU in accordance with

the difference in the voltage between the DPF upstream area and the DPF downstream area.

 The engine-ECU anticipates the amount of PM accumulated in the DPF through this output voltage.

TROUBLE JUDGEMENT

Check Conditions

- Battery positive voltage is 8 16 V
- · Vehicle in steady running.

Judgement Criterion

 The exhaust differential pressure sensor output voltage is less than threshold value based on exhaust gas flow for predetermined time.

Check Conditions

- Battery positive voltage is 8 16 V
- Predetermined time has passed after the engine is stopped.
- The malfunction of P2454 or P2455 is not detected.

Judgement Criterion

• The exhaust differential pressure sensor output is more than 2.75 kPa for predetermined time.

or

 The exhaust differential pressure sensor output is less than -2.75 kPa for predetermined time.

FAIL-SAFE AND BACKUP FUNCTION

- The throttle valve is opened (Electrical discontinuity).
- The EGR control is stopped (fully closed).
- The DPF regeneration is prohibited.
- The AS&G control is prohibited.

PROBABLE CAUSES

- The exhaust pressure hose or the exhaust pressure pipe is disconnected, damaged, misconnected or clogged.
- Failed exhaust differential pressure sensor
- Open/short circuit or harness damage in exhaust differential pressure sensor circuit or loose connector contact
- Failed engine-ECU

DIAGNOSTIC PROCEDURE

STEP 1. Check exhaust pressure hose and exhaust pressure pipe.

 Check the lines between the exhaust differential pressure sensor and the DPF (i.e, exhaust pressure hose and exhaust pressure pipe) for disconnection, damage, wrong connection or clogging.

Q: Are the check results normal?

YES: Go to Step 2.

NO: Repair or replace the exhaust pressure hose or exhaust pressure pipe.

STEP 2. M.U.T.-III data list

- Refer to Data List Reference Table.
 - a. Item 120: Exhaust differential pressure sensor

Q: Is the check result normal?

YES: Intermittent malfunction (Refer to GROUP 00 – How to Use Troubleshooting/Inspection Service Points – How to Cope with Intermittent Malfunctions).

NO: Go to Step 3.

STEP 3. Connector check: A-75 exhaust differential pressure sensor connector

Q: Is the check result normal?

YES: Go to Step 4.

NO: Repair or replace the connector.

STEP 4. Connector check: B-39 engine-ECU connector (A4)

Q: Is the check result normal?

YES: Go to Step 5.

NO: Repair or replace the connector.

STEP 5. Check harness between A-75 (terminal No. 1) exhaust differential pressure sensor connector and B-39 (terminal No. 94) engine-ECU connector.

NOTE: Before checking harness, check intermediate connector A-10, and repair if necessary.

• Check power supply line for short circuit.

Q: Is the check result normal?

YES: Go to Step 6.

NO: Repair the damaged harness wire.

STEP 6. Check harness between A-75 (terminal No. 2) exhaust differential pressure sensor connector and B-39 (terminal No. 56) engine-ECU connector.

NOTE: Before checking harness, check intermediate connector A-10, and repair if necessary.

Check output line for open/short circuit and damage.

Q: Is the check result normal?

YES: Go to Step 7.

NO: Repair the damaged harness wire.

STEP 7. Check harness between A-75 (terminal No. 3) exhaust differential pressure sensor connector and B-39 (terminal No. 80) engine-ECU connector.

NOTE: Before checking harness, check intermediate connector A-10, and repair if necessary.

• Check earthing line for open circuit and damage.

Q: Is the check result normal?

YES: Go to Step 8.

NO: Repair the damaged harness wire.

STEP 8. Replace the exhaust differential pressure sensor


 After replacing the exhaust differential pressure sensor, carry out the forcible DPF regeneration. (Refer to GROUP 17 – Emission Control <DIESEL> – Diesel Particulate Filter (DPF) System – Forcible DPF regeneration).

Q: Is the check result normal?

YES: Check end.

NO: Replace the engine-ECU.

DIAGNOSIS FUNCTION



ENGINE WARNING LAMP (CHECK ENGINE LAMP)

When the abnormal condition occurs with respect to the items of electronically controlled fuel injection system shown in the table, the engine warning lamp is illuminated. When the lamp remains illuminated after the engine start, or when the lamp is illuminated while the engine is running, check the diagnosis code output. There are two methods for checking the indicator lamp burn out: When the ignition switch is in ON position, the indicator lamp is illuminated, and then extinguished few seconds later. When the ignition switch is in ON position and the engine starts, the indicator lamp is extinguished.

ENGINE WARNING LAMP INSPECTION ITEMS

Code No.	Diagnosis item
P0003*1	Suction control valve open
P0004*1	Suction control valve battery short
P0016*1	Crank angle sensor/camshaft position sensor phase problem
P0047*1	Variable geometry control solenoid valve circuit low input
P0048 ^{*1}	Variable geometry control solenoid valve circuit high input
P0072	No. 1 intake air temperature sensor circuit low input
P0073	No. 1 intake air temperature sensor circuit high input
P0088*1	Common rail high pressure malfunction
P0089*1	Suction control valve stuck
P0093 ^{*1}	Fuel leak problem
P0102	Air flow sensor circuit low input
P0103	Air flow sensor circuit high input
P0106*1	Manifold absolute pressure sensor range/performance problem
P0107*1	Manifold absolute pressure sensor circuit low input
P0108 ^{*1}	Manifold absolute pressure sensor circuit high input
P0112	No. 2 intake air temperature sensor circuit low input
P0113	No. 2 intake air temperature sensor circuit high input
P0117	Engine coolant temperature sensor circuit low input
P0118	Engine coolant temperature sensor circuit high input
P0122	Throttle position sensor circuit low input
P0123	Throttle position sensor circuit high input
P0182	Fuel temperature sensor circuit low input
P0183	Fuel temperature sensor circuit high input
P0191 ^{*1}	Rail pressure sensor range/performance problem
P0192 ^{*1}	Rail pressure sensor circuit low input

P0101*1 Air flow sensor range/performance problem

	P2413	EGR system performance
	P2427	EGR cooling valve control circuit (High)
٠.	P244A	Diesel particulate filter differential pressure too low
-	P2454 ^{*1}	Exhaust differential pressure sensor circuit low input
	P2455 ^{*1}	Exhaust differential pressure sensor circuit high input
	P2463 ^{*1}	No chance of forcible regeneration of DPF

NOTE:

- After the engine-ECU has detected a malfunction, the engine warning lamp illuminates when the engine is next turned on and the same malfunction is re-detected. However, for items marked with a "*1" in the diagnosis code number column, the engine warning lamp illuminates only on the first detection of the malfunction.
- When the fuel runs out, the engine warning lamp would illuminate possibly. Supplying the fuel turns off the engine warning lamp, but the diagnosis code Nos. P1272 are stored.

P2453*1	Exhaust differential pressure sensor range/performance problem
---------	--


		restricted. The throttle valve is closed. (Fixed opening degree) The EGR control is stopped (fully closed). The DPF regeneration is prohibited. The AS&G control is prohibited.
P010	Air flow sensor circuit low input	 The control is performed using the previous value. The DPF regeneration is prohibited. The throttle valve is opened. (Electrical discontinuity) The EGR control is stopped (fully closed). The AS&G control is prohibited.
P010	Air flow sensor circuit high inpu	 The control is performed using the previous value. The DPF regeneration is prohibited. The throttle valve is opened. (Electrical discontinuity) The EGR control is stopped (fully closed). The AS&G control is prohibited.
P010	Manifold absolute pressure sensor range/performance problem	 The pressure in the inlet manifold is controlled to be 100 kPa. The EGR control is stopped (fully closed). The fuel injection amount is restricted. (Output restriction) The open angle of the accelerator pedal is restricted. The DPF regeneration is prohibited. The throttle valve is opened. (Electrical discontinuity) The AS&G control is prohibited.
P010	7 Manifold absolute pressure sensor circuit low input	 The pressure in the inlet manifold is controlled to be 100 kPa. The EGR control is stopped (fully closed). The fuel injection amount is restricted. (Output restriction)

P0101	Air flow sensor range/ performance problem	 The control is performed using the previous value. The DPF regeneration is prohibited. The throttle valve is opened. (Electrical discontinuity) The EGR control is stopped (fully closed).
-------	---	---

sensor range/performance • The AS& • The EGR	Fregeneration is prohibited. AG control is prohibited. A control is stopped (fully closed). Ottle valve is opened. (Electrical inuity)
--	--

			 The DPF regeneration is prohibited. The turbocharger control is prohibited. The AS&G control is prohibited.
P24	13	EGR system performance	 The EGR control is stopped (fully closed). The DPF regeneration is prohibited. The throttle valve is opened. (Electrical discontinuity) The AS&G control is prohibited.
P24	26	EGR cooling valve control circuit (Low)	The EGR control is stopped (fully closed).
P24	27	EGR cooling valve control circuit (High)	The EGR control is stopped (fully closed).
P24	4A	Diesel particulate filter differential pressure too low	The DPF regeneration is prohibited.
P24	54	Exhaust differential pressure sensor circuit low input	 The throttle valve is opened. (Electrical discontinuity) The EGR control is stopped (fully closed). The DPF regeneration is prohibited. The AS&G control is prohibited.
P24	55	Exhaust differential pressure sensor circuit high input	 The throttle valve is opened. (Electrical discontinuity) The EGR control is stopped (fully closed). The DPF regeneration is prohibited. The AS&G control is prohibited.

DIAGNOSIS FUNCTION



ENGINE WARNING LAMP (CHECK ENGINE LAMP)

When the abnormal condition occurs with respect to the items of electronically controlled fuel injection system shown in the table, the engine warning lamp is illuminated. When the lamp remains illuminated after the engine start, or when the lamp is illuminated while the engine is running, check the diagnosis code output. There are two methods for checking the indicator lamp burn out: When the ignition switch is in ON position, the indicator lamp is illuminated, and then extinguished few seconds later. When the ignition switch is in ON position and the engine starts, the indicator lamp is extinguished.

ENGINE WARNING LAMP INSPECTION ITEMS

Code No.	Diagnosis item
P0003 ^{*1}	Suction control valve open
P0004 ^{*1}	Suction control valve battery short
P0016 ^{*1}	Crank angle sensor/camshaft position sensor phase problem
P0047 ^{*1}	Variable geometry control solenoid valve circuit low input
P0048 ^{*1}	Variable geometry control solenoid valve circuit high input
P0072	Intake air temperature sensor circuit low input
P0073	Intake air temperature sensor circuit high input
P0088 ^{*1}	Common rail high pressure malfunction
P0089 ^{*1}	Suction control valve stuck
P0093 ^{*1}	Fuel leak problem
P0102	Air flow sensor circuit low input
P0103	Air flow sensor circuit high input
P0106 ^{*1}	Manifold absolute pressure sensor range/performance problem
P0107 ^{*1}	Manifold absolute pressure sensor circuit low input
P0108 ^{*1}	Manifold absolute pressure sensor circuit high input
P0112	EGR gas temperature sensor circuit low input
P0113	EGR gas temperature sensor circuit high input
P0117	Engine coolant temperature sensor circuit low input
P0118	Engine coolant temperature sensor circuit high input
P0122	Throttle position sensor circuit low input
P0123	Throttle position sensor circuit high input
P0182	Fuel temperature sensor circuit low input
P0183	Fuel temperature sensor circuit high input

P0101*1

Air flow sensor range/performance problem

Code No.	Diagnosis item	
P2454 ^{*1}	Exhaust differential pressure sensor circuit low input	
P2455*1	Exhaust differential pressure sensor circuit high input	
P2463*1	No chance of forcible regeneration of DPF	

NOTE:

- After the engine-ECU has detected a malfunction, the engine warning lamp illuminates when the engine is next turned on and the same malfunction is re-detected. However, for items marked with a "*1" in the diagnosis code number column, the engine warning lamp illuminates only on the first detection of the malfunction.
- When the fuel runs out, the engine warning lamp would illuminate possibly. Supplying the fuel turns off the engine warning lamp, but the diagnosis code No. P1272 is stored.
- Even if the malfunction is not detected when the engine-ECU monitors the malfunction three consecutive times* after the engine warning lamp illuminates, turn off the engine warning lamp when the engine starts next time.
 - *: In this case, "one time" in monitoring the malfunction means the period from the time of the current engine start to the time of the next engine start.

METHOD OF READING AND ERASING DIAGNOSIS CODES

Refer to GROUP 00 – How to Use Troubleshooting/Inspection Service Points – Diagnosis Function ${\tt M1001013401040}.$

P2453*1

| Exhaust differential pressure sensor range/performance problem

P0101	Air flow sensor range/ performance problem	 The control is performed using the previous value. The DPF regeneration is prohibited. The throttle valve is opened. (Electrical discontinuity) The EGR control is stopped (fully closed).
-------	---	---

			 The DPF regeneration is prohibited. The fuel injection amount is restricted. (output restriction) The EGR control is stopped (fully closed). The open angle of the accelerator pedal is restricted. 		
	P0089	Suction control valve stuck	 The rail pressure is controlled in the range between 50 and 100 MPa. The fuel injection amount is restricted. (output restriction) The open angle of the accelerator pedal is restricted. The throttle valve is closed. (fixed opening degree) The EGR control is stopped (fully closed). The DPF regeneration is prohibited. 		
~	P0093	Fuel leak problem	 The rail pressure is controlled to be 100 MPa or less. The fuel injection amount is restricted. (output restriction) The open angle of the accelerator pedal is restricted. The throttle valve is closed. (fixed opening degree) The EGR control is stopped (fully closed). The DPF regeneration is prohibited. 		
//	P0102	Air flow sensor circuit low input	 The control is performed using the previous value. The DPF regeneration is prohibited. The throttle valve is opened. (electrical discontinuity) The EGR control is stopped (fully closed). 		

P2453 Exhaust differential pressure sensor range/performance	 The DPF regeneration is prohibited. The AS&G control is prohibited. The EGR control is stopped (fully closed). The throttle valve is opened. (Electrical discontinuity)
--	--

 -		The EGR control is stopped (fully closed). The DPF regeneration is prohibited.
P2228	Barometric pressure sensor circuit low input	 The EGR control is stopped (fully closed). The throttle valve is opened. (electrical discontinuity) The DPF regeneration is prohibited. The turbocharger control is prohibited.
P2229	Barometric pressure sensor circuit high input	 The EGR control is stopped (fully closed). The throttle valve is opened. (electrical discontinuity) The DPF regeneration is prohibited. The turbocharger control is prohibited.
P2413	EGR system performance	 The EGR control is stopped (fully closed). The DPF regeneration is prohibited. The throttle valve is opened. (electrical discontinuity) The NPG/SPG control is stopped. The small injection quantity learning is prohibited.
P2426	EGR cooling valve control circuit (Low)	The EGR control is stopped (fully closed).
P2427	EGR cooling valve control circuit (High)	The EGR control is stopped (fully closed).
P244A	DPF differential pressure too low	The DPF regeneration is prohibited.
P2454	Exhaust differential pressure sensor circuit low input	 The throttle valve is opened. (electrical discontinuity) The EGR control is stopped (fully closed). The DPF regeneration is prohibited.

Code No. P0102: Air flow Sensor Circuit Low Input

OPERATION

- Power is supplied by the engine control relay connector terminal to the air flow sensor connector terminal, and the air flow sensor connector terminal is earthed through the engine-ECU connector terminal AFSE&ECBE.
- The air flow sensor connector terminal outputs a sensor signal, which is input into the engine-ECU connector terminal AFS.

FUNCTION

- The air flow sensor outputs pulse signal that varies in accordance with the intake air volume.
- In response to the signal, the engine-ECU controls EGR control, etc.

TROUBLE JUDGEMENT

Check Conditions

• Battery positive voltage is 8 – 16 V

• 2 seconds later after the ignition switch has been in "ON" position or the engine has started up.

Judgement Criterion

 The air flow sensor output voltage is 0.50 V or less.

FAIL-SAFE AND BACKUP FUNCTION

- The control is performed using the previous value.
- The DPF regeneration is prohibited.
- The throttle valve is opened (Electrical discontinuity).
- The EGR control is stopped (fully closed).

PROBABLE CAUSES

- Failed air flow sensor
- Open/short circuit or harness damage in air flow sensor circuit or loose connector contact
- Failed engine-ECU

DIAGNOSTIC PROCEDURE

STEP 1. M.U.T.-III data list

- Refer to Data List Reference Table.
 - a. Item 114: Air flow sensor

Q: Is the check result normal?

YES: Intermittent malfunction (Refer to GROUP 00 – How to Use Troubleshooting/Inspection Service Points – How to Cope with Intermittent Malfunctions).

NO: Go to Step 2.

STEP 2. Voltage measurement at air flow sensor connector (power supply line).

- (1) Disconnect the connector, and measure at the wiring harness side.
- (2) Ignition switch: ON
- (3) Check the voltage between the air flow sensor connector (power supply line) and body earth.

OK: System voltage

Q: Is the check result normal?

YES: Go to Step 3.

NO: Repair power supply line between engine control relay connector and air flow sensor connector.

Code No. P0101: Air Flow Sensor Range/Performance Problem

OPERATION

- Power is supplied by the engine control relay (terminal No. 2) to the air flow sensor (terminal No. 3), and the air flow sensor (terminal No. 2) is earthed through the engine-ECU AFSE & ECBE.
- The air flow sensor (terminal No. 1) outputs a sensor signal, which is input into the engine-ECU AFS.

FUNCTION

- The air flow sensor outputs pulse signal that varies in accordance with the intake air volume.
- In response to the signal, the engine-ECU controls EGR control, etc.

TROUBLE JUDGEMENT

Check Conditions

- Battery positive voltage is 8 16 V
- 1 second before the throttle valve fully openedposition value after the ignition switch has been in "LOCK" (OFF) position.

Judgement Criterion

• The air flow sensor output voltage is threshold value or less.

OI

 The air flow sensor output voltage is threshold value or more.

FAIL-SAFE AND BACKUP FUNCTION

- The control is performed using the previous value.
- The DPF regeneration is prohibited.
- The throttle valve is opened (Electrical discontinuity).
- The EGR control is stopped (fully closed).

PROBABLE CAUSES

- Failed air flow sensor
- Harness damage in air flow sensor circuit or loose connector contact
- Failed engine-ECU

DIAGNOSIS PROCEDURE

STEP 1. Check harness between engine control relay connector (terminal No. 2) and air flow sensor connector (terminal No. 3).

· Check power supply line for damage.

Q: Is the check result normal?

YES: Go to Step 2.

NO: Repair the damaged harness wire.

STEP 2. Check harness between air flow sensor connector (terminal No. 1) and engine-ECU connector terminal AFS.

· Check output line for damage.

Q: Is the check result normal?

YES: Go to Step 3.

NO: Repair the damaged harness wire.

STEP 3. Check harness between air flow sensor connector (terminal No. 2) and engine-ECU connector terminal AFSE & ECBE.

· Check earthing line for damage.

Q: Is the check result normal?

YES: Go to Step 4.

NO: Repair the damaged harness wire.

STEP 4. M.U.T.-III data list

• Refer to Data List Reference Table.

a. Item 114: Air flow sensor

Q: Is the check result normal?

YES: Intermittent malfunction (Refer to GROUP 00 – How to Use Troubleshooting/Inspection Service Points – How to Cope with Intermittent Malfunctions).

NO: Go to Step 5.

STEP 5. Replace the air flow sensor.

• After replacing the air flow sensor, re-check the trouble symptoms.

Q: Is the check result normal?

YES: Check end.

NO: Replace the engine-ECU.

Code No. P1497: DPF System Malfunction

FUNCTION

 The engine-ECU monitors the input signals from sensors to check if the DPF regeneration is executed normally.

TROUBLE JUDGEMENT

Check Condition

On DPF regeneration

Judgement Criterion

 The DPF regeneration status continues for the predetermined time or more.

FAIL-SAFE AND BACKUP FUNCTION

- The throttle valve is opened. (electrical discontinuity)
- The EGR control is stopped (fully closed).
- The DPF regeneration is prohibited.

PROBABLE CAUSES

- Failed No. 2 exhaust gas temperature sensor (catalyst temperature)
- Failed No. 3 exhaust gas temperature sensor (DPF temperature)
- Failed exhaust differential pressure sensor
- Catalytic converter inactive
- The engine oil-containing ash is loaded to the DPF inside.

DIAGNOSIS PROCEDURE

STEP 1. M.U.T.-III data list.

- Refer to Data List Reference Table.
 - a. Item 118: No. 2 exhaust gas temperature sensor (catalyst temperature)
 - b. Item 119: No. 3 exhaust gas temperature sensor (DPF temperature)
 - c. Item 120: Exhaust differential pressure sensor

Q: Are the check results normal?

YES: Go to Step 2.

NO: Perform the diagnosis code classified check procedure for the sensor that has shown an abnormal data value (Refer to Inspection Chart for Diagnosis Code).

STEP 2. Forcible DPF regeneration execution

- Initialise the DPF-related parts, and then delete the diagnosis code (Refer to GROUP 00 – Precautions before Service – Initialisation Procedure for Learning Value in Common Rail Engine <4N1>).
 - a. Item 42: DPF system malfunction service
- Carry out the forcible DPF regeneration (Refer to GROUP 17 – Emission Control <DIESEL> – Diesel Particulate Filter (DPF) System Forcible DPF Regeneration).

Carry out the small injection quantity learning procedure (Refer to GROUP 00 – Precautions before Service – Small Injection Quantity Learning Procedure <4N1>).

Code No. P1498: Excessive PM Accumulated In DPF

FUNCTION

- The engine-ECU monitors the input signals from sensors to estimate the PM amount loaded to the DPF inside.
- If the PM is loaded more than the specified amount, the DPF regeneration is automatically executed under certain conditions in order to eliminate the PM.
- If the PM is excessively loaded, the engine-ECU does not execute the automatic DPF regeneration. It makes the engine warning lamp illuminate and allow the DPF warning mark to be shown.

TROUBLE JUDGEMENT

Check Condition

• Ignition switch is in "ON" position.

Judgement Criterion

 Driving distance exceeds the specified value after the last DPF regeneration.

FAIL-SAFE AND BACKUP FUNCTION

- The throttle valve is opened (electrical discontinuity).
- The EGR control is stopped (fully closed).
- The DPF regeneration is prohibited.
- The fuel injection amount is restricted (output restriction).
- The open angle of the accelerator pedal is restricted.

PROBABLE CAUSE

• The PM is abnormally loaded to the DPF inside.

The small injection quantity improperly learned.

DIAGNOSIS PROCEDURE

<Added>

STEP 1. M.U.T.-III diagnosis code.

 Check whether the diagnosis code P2463 is stored together with P1498 or not.

Q: Is the diagnosis code P2463 stored?

YES: Troubleshoot the diagnosis code P2463.

NO: Go to Step 2.

STEP 2. Forcible DPF regeneration execution

 Carry out the forcible DPF regeneration (Refer to GROUP 17 – Emission Control <DIESEL> – Diesel Particulate Filter (DPF) System – Forcible DPF Regeneration).

Q: Is the diagnosis code stored?

YES: Inspection chart for diagnosis code.

NO: Check end.

<Added>

Carry out the small injection quantity learning procedure (Refer to GROUP 00

 Precautions before Service – Small Injection Quantity Learning Procedure
 4N1>).

Code No. P1499: Abnormally high DPF temperature

FUNCTION

- The DPF may be have melting damage if the temperature exceeds the specified value.
- The engine-ECU monitors the signals from No. 3 exhaust gas temperature sensor (DPF temperature) to check if the DPF is under the specified temperature.

TROUBLE JUDGEMENT

Check Condition

• On DPF regeneration

Judgement Criterion

 The No. 3 exhaust gas temperature sensor (DPF temperature) detects the abnormally high temperature. or

• The estimated DPF centre temperature exceeds the specified value.

FAIL-SAFE AND BACKUP FUNCTION

- The throttle valve is opened. (Electrical discontinuity)
- The EGR control is stopped (fully closed).
- The DPF regeneration is prohibited.
- The fuel injection amount is restricted. (output restriction)
- The open angle of the accelerator pedal is restricted.

PROBABLE CAUSE

• Damage by the DPF with high temperature

DIAGNOSIS PROCEDURE

STEP 1. M.U.T.-III data list.

- Refer to Data List Reference Table.
 - a. Item 119: No. 3 exhaust gas temperature sensor (DPF temperature)

Q: Is the check result normal?

YES: Replace the DPF. When the DPF is replaced, initialise the learning value (Refer to GROUP 00 – Precautions Before Service – Initialisation Procedure For Learning Value in Common Rail Engine <4N1>).

<Incorrect>

NO: Perform the diagnosis code classified check procedure for the sensor that has shown an abnormal data value (Refer to Inspection Chart for Diagnosis Code).

<Correct>

NO: Go to Step 2.

STEP 2. Small injection quantity learning.

 Carry out the small injection quantity learning procedure (Refer to GROUP 00 – Precautions Before Service – Small Injection Quantity Learning Procedure).

Q: Is the diagnosis code set?

YES: Inspection chart for diagnosis code.

NO: Check end.

Code No. P2454: Exhaust Differential Pressure Sensor Circuit Low Input

OPERATION

- A power voltage of 5 V is applied to the exhaust differential pressure sensor power terminal from the engine-ECU connector terminal DDP5 and earthed to the engine-ECU connector terminal DDPE from the exhaust differential pressure sensor connector terminal.
- The sensor signal is inputted to the engine-ECU connector terminal DDPS from the exhaust differential pressure sensor output terminal.

FUNCTION

- The exhaust differential pressure sensor outputs the voltage to the engine-ECU in accordance with the difference in the voltage between the DPF upstream area and the DPF downstream area.
- The engine-ECU anticipates the amount of PM accumulated in the DPF through this output voltage.

TROUBLE JUDGEMENT

Check Conditions

- Battery positive voltage is 8 16 V
- 2 seconds later after the ignition switch has been in "ON" position or the engine has started up

Judgement Criterion

• The exhaust differential pressure sensor output voltage is 0.49 V or less.

FAIL-SAFE AND BACKUP FUNCTION

- The throttle valve is opened (electrical discontinuity).
- The EGR control is stopped (fully closed).
- The DPF regeneration is prohibited.

PROBABLE CAUSES

- Failed exhaust differential pressure sensor
- Open/short circuit or harness damage in exhaust differential pressure sensor circuit or loose connector contact
- Failed engine-ECU

DIAGNOSTIC PROCEDURE

STEP 1. M.U.T.-III data list

- Refer to Data List Reference Table.
 - a. Item 120: Exhaust differential pressure sensor

Q: Is the check result normal?

YES: Intermittent malfunction (Refer to GROUP 00 – How to Use Troubleshooting/Inspection Service Points – How to Cope with Intermittent Malfunctions).

NO: Go to Step 2.

STEP 2. Voltage measurement at exhaust differential pressure sensor connector (DDP5 line).

- (1) Disconnect the connector, and measure at the wiring harness side.
- (2) Ignition switch: ON
- (3) Check the voltage between the exhaust differential pressure sensor connector (DDP5 line) and body earth.

OK: 4.9 - 5.1 V

Q: Is the check result normal?

YES: Go to Step 6. **NO**: Go to Step 3.

Code No. P2453: Exhaust Differential Pressure Sensor Range/Performance Problem

OPERATION

- A power voltage of 5 V is applied to the exhaust differential pressure sensor power terminal (terminal No. 3) from the engine-ECU DDP5 and earthed to the engine-ECU DDPE from the exhaust differential pressure sensor (terminal No. 2).
- The sensor signal is inputted to the engine-ECU DDPS from the exhaust differential pressure sensor output terminal (terminal No. 1).

FUNCTION

- The exhaust differential pressure sensor outputs the voltage to the engine-ECU in accordance with the difference in the voltage between the DPF upstream area and the DPF downstream area.
- The engine-ECU anticipates the amount of PM accumulated in the DPF through this output voltage.

TROUBLE JUDGEMENT

Check Conditions

- Battery positive voltage is 8 16 V
- · Vehicle in steady running.

Judgement Criterion

 The exhaust differential pressure sensor output voltage is less than threshold value based on exhaust gas flow for predetermined time.

Check Conditions

- Battery positive voltage is 8 16 V
- Predetermined time has passed after the engine is stopped.
- The malfunction of P2454 or P2455 is not detected.

Judgement Criterion

• The exhaust differential pressure sensor output is more than 2.75 kPa for predetermined time.

or

 The exhaust differential pressure sensor output is less than -2.75 kPa for predetermined time.

FAIL-SAFE AND BACKUP FUNCTION

- The DPF regeneration is prohibited.
- The EGR control is stopped (fully closed).
- The throttle valve is opened (Electrical discontinuity).

PROBABLE CAUSES

- The exhaust pressure hose or the exhaust pressure pipe is disconnected, damaged, misconnected or clogged.
- Failed exhaust differential pressure sensor
- Harness damage in exhaust differential pressure sensor circuit or loose connector contact
- Failed engine-ECU

DIAGNOSIS PROCEDURE

STEP 1. Check exhaust pressure hose and exhaust pressure pipe.

 Check the lines between the exhaust differential pressure sensor and the exhaust centre pipe (DPF) (i.e, exhaust pressure hose and exhaust pressure pipe) for disconnection, damage, wrong connection or clogging.

Q: Are the check results normal?

YES: Go to Step 2.

NO: Repair or replace the exhaust pressure hose or exhaust pressure pipe.

STEP 2. M.U.T.-III data list

- Refer to Data List Reference Table.
 - a. Item 120: Exhaust differential pressure sensor

Q: Is the check result normal?

YES: Intermittent malfunction (Refer to GROUP 00 – How to Use Troubleshooting/Inspection Service Points – How to Cope with Intermittent Malfunctions).

NO: Go to Step 3.

STEP 3. Check harness between exhaust differential pressure (terminal No. 3) sensor connector and engine-ECU connector DDP5.

Check power supply line for damage.

Q: Is the check result normal?

YES: Go to Step 4.

NO: Repair the damaged harness wire.

STEP 4. Check harness between exhaust differential pressure sensor connector (terminal No. 1) and engine-ECU connector terminal DDPS.

· Check output line for damage.

Q: Is the check result normal?

YES: Go to Step 5.

NO: Repair the damaged harness wire.

STEP 5. Check harness between exhaust differential pressure sensor connector (terminal No. 2) and engine-ECU connector terminal DDPE.

Check earthing line for damage.

Q: Is the check result normal?

YES: Go to Step 6.

NO: Repair the damaged harness wire.

STEP 6. Replace the exhaust differential pressure sensor

 After replacing the exhaust differential pressure sensor, carry out the forcible DPF regeneration. (Refer to GROUP 17 – Emission Control <DIESEL> – Diesel Particulate Filter (DPF) System – Forcible DPF Regeneration). After carrying out the forcible DPF regeneration, re-check the trouble symptoms.

Q: Is the check result normal?

YES: Check end.

NO: Replace the engine-ECU.

Code No. P252F: Engine Oil Level Malfunction

FUNCTION

- The engine oil level may ascend if the fuel runs into the engine oil on the DPF regeneration.
- The engine-ECU monitors the engine driving conditions to estimate the ascend of engine oil level.

Judgement Criterion

• The estimated increased amount of the engine oil exceeds the 200 cc.

<Incorrect>

2.000 <Correct>

FAIL-SAFE AND BACKUP FUNCTION

• The DPF regeneration is prohibited.

PROBABLE CAUSE TROUBLE JUDGEMENT

Check Condition

• Ignition switch is in "ON" position.

• The engine oil is increased.

DIAGNOSIS PROCEDURE

<Incorrect>

STEP 1. Replace the engine oil.

 Replace the engine oil, When the engine oil is replaced, initialise the learning value (Refer to GROUP 00 -Precautions before Service – Initialisation Procedure for Learning Value in Common Rail Engine <4N1>). After initialising the learning value, reconfirm diagnosis code.

Q: Is the diagnosis code stored?

YES: Replace the engine-ECU.

NO: Check end.

<Correct>

STEP 1. Replace the engine oil.

- 1. Replace the engine oil, When the engine oil is replaced, initialise the learning value (Refer to GROUP 00 -Precautions before Service – Initialisation Procedure for Learning Value in Common Rail Engine <4N1>). After initialising the learning value, reconfirm diagnosis code.
- 2. Carry out the small injection quantity learning procedure (Refer to GROUP 00 - Precautions before Service - Small Injection Quantity Learning Procedure <4N1>).
- 3. Reconfirmation of diagnosis code.
- Q: Is the diagnosis code set?

YES: Replace the engine-ECU.

NO: Check end.