9

FUSIBLE LINK ②

5R

1 D-240

5R

1 D-404

J/B

15

15A

12 D-405

W-R

ENGINE-ECU D-215

ASTC-ECU D-223

109 108 84 83

<T> (L-B) *1 <T> (GR) *2

<T> (L-R) *1 <T> (SB) *2

<T> (R-G)

<T> (BR-B)

16 5 12 1

J/C (CAN2) D-22

22 11

<T> (G-Y) <T> (L-Y)

12 13 D-230

<T> (G-Y) <T> (L-Y)

22 11

J/C (CAN1) D-03

12 *1 14 *2 1 *1 3 *2

<T> (B-Y) <T> (LG)

16 14 6

DIAGNOSIS CONNECTOR D-127

4 5

B B

16 5

<T> (L) <T> (GR-B)

4 3

IMMOBILIZER-ECU D-126

4

·APPROACH LAMP
·AUDIO SYSTEM
·AUTOMATIC AIR CONDITIONER
·CENTRAL DOOR LOCKING SYSTEM
·CENTRE DISPLAY
·DOOR AJAR WARNING BUZZER
·DOOR LAMP
·ELECTRIC RETRACTABLE REMOTE CONTROLLED MIRROR
·FOOT LAMP AND CEILING LAMP
·FORGOTTEN KEY PREVENTION FUNCTION
·FRONT FOG LAMP
·HANDS-FREE INTERFACE SYSTEM
·HBB, EBD, ABS AND ASTC
·HEADLAMP
·HEADLAMP WASHER
·MMCS
·POWER WINDOWS
·REAR FOG LAMP
·REAR SEAT ENTERTAINMENT SYSTEM
·REAR WIPER AND WASHER
·ROOM LAMP, PERSONAL LAMP, LUGGAGE COMPARTMENT LAMP AND IGNITION KEY CYLINDER ILLUMINATION LAMP
·SEAT BELT WARNING BUZZER
·SECURITY ALARM
·SPARE CONNECTOR (FOR ACCESSORY)
·SPARE CONNECTOR (FOR AUDIO)
·SPARE CONNECTOR (FOR REAR DISPLAY)
·SUNROOF
·TAIL LAMP, POSITION LAMP, LICENCE PLATE LAMP AND LIGHTING MONITOR BUZZER
·TURN-SIGNAL LAMP AND HAZARD WARNING LAMP
·USB BOX
·VANITY MIRROR LAMP
·WINDSHIELD WIPER AND WASHER

FUSIBLE LINK ①

J/B (FUSE ②)

2

RELAY BOX

18

15A

·FRONT FOG LAMP
·HEADLAMP
·HEADLAMP WASHER
·SECURITY ALARM
·TAIL LAMP, POSITION LAMP, LICENCE PLATE LAMP AND LIGHTING MONITOR BUZZER
·WINDSHIELD WIPER AND WASHER

0.85R-B

15 D-241

0.85R-B (W-B)

2

R-B

D-02 31 42

COMBINATION METER

CHECK ENGINE

CPU

23 24 15 D-04

W-L

16 *1 12 *2

J/C (7) D-37

15 *1 16 *2

(W-L)

2 C

41 52

B B

16

NOTE
*1 : LHD
*2 : RHD

10

D-02
MU801515

D-03
MU801516

D-04

D-22
MU801516

D-37

D-126
AMP

D-127
MU803797
FRONT SIDE

D-215

D-223

D-230

D-240
MU801405

D-241

D-404
MU801403

D-405