

ASX / OUTLANDER SPORT / RVR FLOOR MAT INSTALLATION AND HANDLING INSTRUCTIONS

Applicable Models	Part No.
ASX (right-hand drive, manual transmission)	MZ360327EX
ASX (right-hand drive, CVT)	MZ360328EX
OUTLANDER SPORT (left-hand drive, CVT or manual transmission)	MZ360329EX
ASX (left-hand drive, with fire extinguisher, CVT or manual transmission)	MZ360341EX
RVR (left-hand drive, CVT or manual transmission)	MZ360350EX
ASX (left-hand drive, CVT or manual transmission)	MZ360357EX

Thank you for purchasing the Mitsubishi Genuine Accessory.
To install and use the product correctly with proper knowledge of it, read this publication carefully.
Keep this publication for reference when maintenance is required.

Attention

- This publication gives precautionary instructions in the boxes titled as follows.
Read through these instructions thoroughly.



Caution

Describes precautions that should be observed in order to prevent injury or damage to the vehicle or its components, which may occur if sufficient care is not taken.



Note


Provides additional information that facilitates installation work.

- Failure to follow these instructions not only prevents the product from working properly but may lead to trouble with the vehicle. Be sure to follow all instructions carefully.
- If there is anything unclear about the installation, handling and/or usage of the product, contact your Mitsubishi Motors dealer for clarification.
- Mitsubishi Motors Corporation is not responsible for any defects or difficulties caused by or resulting from the failure to follow given instructions.
- We recommend you to have the installation performed at an authorized Mitsubishi Motors dealer.


To the dealer:
Be sure that the customer receives this publication.

■ **COMPONENTS** (Make sure that all of the following components were included in the kit.)


ASX (right-hand drive, manual transmission): MZ360327EX




ASX (right-hand drive, CVT): MZ360328EX




OUTLANDER SPORT
(left-hand drive, CVT or manual transmission): MZ360329EX




RVR
(left-hand drive, CVT or manual transmission): MZ360350EX



ASX (left-hand drive, with fire extinguisher, CVT or manual transmission): MZ360341EX



ASX
(left-hand drive, CVT or manual transmission): MZ360357EX




*Hook fastener is attached to the position shown by the broken line at the back of the mat.

■ **PRECAUTIONS**

- Be sure to apply the parking brake securely. Remove the ignition key from the key cylinder.

INSTALLATION PROCEDURES

A. INSTALLING THE FRONT FLOOR MATS



- 1) Slide the driver's and front passenger's seats to their rearmost positions.
- 2) For the front passenger's floor mat, position the mat properly to fit the shape of the floor.
- 3) For the driver's floor mat, fit the two mounting holes of the floor mat on the fixing hooks as shown and position the mat properly to fit the shape of the floor.

Warning


If the movement of the pedals is obstructed by the floor mat (or some other thing) during driving, it may result in a fatal accident.

To prevent this:

- Always secure the floor mat with the hooks on the floor.
- Never place this floor mat on top of or under another floor mat.

Check

B. INSTALLING THE REAR FLOOR MATS



- 1) Slide the driver's and front passenger's seats to their foremost positions.
- 2) Position the rear floor mats properly to fit the shape of the floor. Fix each mat with hook fastener at the back.

Check

CARE AND HANDLING

- When removing the driver's floor mat, be careful not to damage the hooks on the floor.
- The floor mats are not resistible to oil products such as kerosene. Take care that the mats do not contact them.

Material...Surface: PP
Back side: SBS

- To clean the mats, use lukewarm water or properly diluted neutral detergent.