


Power Amplifier 6 ch
CV-0MW8C21 (8701A240)
CV-0MW9C21 (8701A268)
CV-0MW0C21 (8701A308)




Power supply and Speakers 18P Connector



Pin	Signal	Pin	Signal
1	Speaker Rear Left (+)	9	Speaker Rear Left (-)
2	Speaker Rear Right (+)	10	Speaker Rear Right (-)
3	GND (Power)	11	-
4	GND (Power)	12	-
		13	-
		14	-
5	Battery (+)	15	-
6	Battery (+)	16	-
7	Speaker Front Right (+)	17	Speaker Front Right (-)
8	Speaker Front Left (+)	18	Speaker Front Left (-)

Audio Input 18P Connector



Pin	Signal	Pin	Signal
21	Rear Left In (+)	30	Rear Left In (-)
22	Rear Right In (+)	31	Rear Right In (-)
23	Tweeter Front Right (-)	32	-
24	Tweeter Front Right (+)	33	GND (Signal)
25	Power On (Radio)	34	GND (Signal, for RHD)
26	Tweeter Front Left (-)	35	Power On (MMCS)
27	Tweeter Front Left (+)	36	-
28	Front Right In (+)	37	Front Right In (-)
29	Front Left In (+)	38	Front Left In (-)