

Power Amplifier 6 ch 8701A633



Power supply and Speakers 18P Connector

1	2	3	4	5	6	7	8		
9	10	11	12	13	14	15	16	17	18

Pin	Signal	Pin	Signal
1	Speaker Rear Left (+)	9	Speaker Rear Left (-)
2	Speaker Rear Right (+)	10	Speaker Rear Right (-)
3	GND (Power)	11	GND (Power)
4	GND (Power)	12	-
		13	-
		14	-
5	Battery (+)	15	-
6	Battery (+)	16	Battery (+)
7	Speaker Front Right (+)	17	Speaker Front Right (-)
8	Speaker Front Left (+)	18	Speaker Front Left (-)

Audio Input 18P Connector

21	22	23	24	25	26	27	28	29
30	31	32	33	34	35	36	37	38

Pin	Signal	Pin	Signal
21	-	30	-
22	Rear Right In (+)	31	Rear Right In (-)
23	Tweeter Front Right (-)	32	-
24	Tweeter Front Right (+)	33	IE-BUS (-)
25	-	34	IE-BUS (+)
26	Tweeter Front Left (-)	35	Power On (MMCS)
27	Tweeter Front Left (+)	36	-
28	Front Right In (+)	37	Front Right In (-)
29	Front Left In (+)	38	Front Left In (-)