
No connection or dead lock relay
Fusible link
Blower relay
To instrument panel wiring harness
To front wiring harness
C-302
1
C-303
C-317
C-304
To roof wiring harness
To instrument panel wiring harness
2
3
4
5
6
C-315
C-316
C-307
7
8
9
10
Fuse
To front wiring harness
11
12
13
C-314
14
15
16
C-309
To floor wiring harness
17
18
19
C-311
C-310
20
C-313
C-312
To instrument panel wiring harness
C-301
To front wiring harness
Fusible link
No connection
AC904474AV