3

FRONT IMPACT SENSOR (LH) A-24

FRONT IMPACT SENSOR (RH) A-37

NOTE
*1 : CONNECTOR LOCK SWITCH (CONNECTOR COUPLED: ON, CONNECTOR UNCOUPLED: OFF)
*2 : LHD
*3 : RHD
*4 : 4M41
*5 : 6G7

SRS-ECU D-24

CONNECTOR LOCK DETECTING CIRCUIT

CLOCK SPRING D-306

DRIVER'S AIR BAG MODULE (SQUIB) D-304

J/B (FUSE 2)

FUSIBLE LINK 1

RELAY BOX

- FRONT FOG LAMP
- HEADLAMP
- HEADLAMP WASHER
- SECURITY ALARM
- TAIL LAMP, POSITION LAMP, LICENCE PLATE LAMP AND LIGHTING MONITOR BUZZER
- WINDSHIELD WIPER AND WASHER

- APPROACH LAMP
- AUDIO SYSTEM
- AUTOMATIC AIR CONDITIONER
- CENTRAL DOOR LOCKING SYSTEM
- CENTRE DISPLAY
- DOOR AJAR WARNING BUZZER
- DOOR LAMP
- ELECTRIC RETRACTABLE REMOTE CONTROLLED MIRROR
- FOOT LAMP AND CEILING LAMP
- FORGOTTEN KEY PREVENTION FUNCTION
- FRONT FOG LAMP
- HANDS-FREE INTERFACE SYSTEM
- HBB, EBD, ABS AND ASTC
- HEADLAMP
- HEADLAMP WASHER
- MMCS
- POWER WINDOWS
- REAR FOG LAMP
- REAR SEAT ENTERTAINMENT SYSTEM
- REAR WIPER AND WASHER
- ROOM LAMP, PERSONAL LAMP, LUGGAGE COMPARTMENT LAMP AND IGNITION KEY CYLINDER ILLUMINATION LAMP
- SEAT BELT WARNING BUZZER
- SECURITY ALARM
- SPARE CONNECTOR (FOR ACCESSORY)
- SPARE CONNECTOR (FOR AUDIO)
- SPARE CONNECTOR (FOR REAR DISPLAY)
- SUNROOF
- TAIL LAMP, POSITION LAMP, LICENCE PLATE LAMP AND LIGHTING MONITOR BUZZER
- TURN-SIGNAL LAMP AND HAZARD WARNING LAMP
- USB BOX
- VANITY MIRROR LAMP
- WINDSHIELD WIPER AND WASHER

COMBINATION METER

CPU

J/C (CAN2) D-22

J/C (CAN1) D-03

DIAGNOSIS CONNECTOR D-127

FUSIBLE LINK 2

J/B

4

HBB15E00BC